



SERVICE MANUAL

BG-3S_{CHASSIS}

<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>	<u>MODEL</u>	<u>COMMANDER</u>	<u>DEST.</u>	<u>CHASSIS NO.</u>
<i>KV-PF21P40</i>	<i>RM-952</i>	<i>Thailand</i>	<i>SCC-U18N-A</i>				
<i>KV-TF21M60</i>	<i>RM-952</i>	<i>Thailand</i>	<i>SCC-U18L-A</i>				
<i>KV-TF21P50</i>	<i>RM-952</i>	<i>Thailand</i>	<i>SCC-U18M-A</i>				



(KV-TF21M60)
(KV-TF21P50)



(KV-PF21P40)



SPECIFICATIONS

		Note
Power requirements	220-240V AC, 50/60Hz	
Power consumption (W)	Indicated on the rear of the TV	
Television system	B/G, I, D/K, M	KV-TF21M60 only
	B/G	KV-PF21P40/TF21P50 only
Color system	PAL, PAL60, SECAM, NTSC4.43, NTSC3.58	KV-TF21M60 only
	PAL, PAL60, NTSC4.43, NTSC3.58 (AV IN)	KV-PF21P40/TF21P50 only
Stereo/Bilingual system	NICAM Stereo/Bilingual B/G, I; A2 Stereo/Bilingual (German) B/G	KV-TF21M60 only
	A2 Bilingual B/G	KV-PF21P40/TF21P50 only
Channel coverage		
B/G	VHF : E2 to E12/ UHF : E21 to E69/ CATV : S01 to S03, S1 to S41	
I	UHF : B21 to B68/ CATV : S01 to S03, S1 to S41	KV-TF21M60 only
D/K	VHF : C1 to C12, R1 to R12/ UHF : C13 to C57, R21 to R60 CATV: S01 to S03, S1 to S41, Z1 to Z39	KV-TF21M60 only
M	VHF : A2 to A13/ UHF : A14 to A79/ CATV : A-8 to A-2, A to W+4, W+6 to W+84	KV-TF21M60 only
㏄ (Antenna)	75-ohm external terinal	
Audio output	3W + 3W	KV-TF21M60/TF21P50 only
	3W	KV-PF21P40 only
Number of terminal		
 (Video)	Input : 2 Output : 1 Phono jacks; 1 Vp-p, 75 ohms	
 (Audio)	Input : 2 Output : 1 Phono jacks; 500 mVrms	
 (Earphone)	Output : 1 Minijack	KV-PF21P40 only
 (Headphone)	Output : 1 Minijack	KV-TF21M60/TF21P50 only
Picture tube	21 inch	
Tube size (cm)	54	Measured diagonally
Screen size (cm)	51	Measured diagonally
Dimension (w/h/d, mm)	490 x 458 x 487	
Mass (kg)	25	

Design and specifications are subject to change without notice.

CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
	SELF DIAGNOSIS FUNCTION	4			
1. GENERAL		8	5. DIAGRAMS		
2. DISASSEMBLY			5-1	Block Diagram	47
2-1.	Rear Cover Removal	30	5-2	Frame Schematic Diagram	50
2-2.	Chassis Assy Removal	30	5-3	Circuit Boards Location	52
2-3.	F Bracket Removal	30	5-4	Schematic Diagrams and Printed Wiring Boards ...	53
2-4.	Service Position	31	(1)	Schematic Diagram of A(1/2) Board	55
2-5.	Replacement of Parts	31	(2)	Schematic Diagram of A(2/2) Board	59
2-5-1.	Replacement of Control Button	31	(3)	Schematic Diagram of C3 Board	67
2-5-2.	Replacement of Bar Control	31	(4)	Schematic Diagram of F Board	69
2-6.	Terminal Bracket Removal	31	5-5	Semiconductors	71
2-7.	Degauss Coil Removal	32			
2-8.	Picture Tube Removal	32	6. EXPLODED VIEWS		
			6-1.	Chassis (KV-PF21P40)	74
3. SET-UP ADJUSTMENTS			7. ELECTRICAL PARTS LIST		76
3-1.	Beam Landing	34			
3-2.	Convergence	35			
3-3.	Focus Adjustment	37			
3-4.	G2 (Screen) and White Balance Adjustments	37			
4. CIRCUIT ADJUSTMENTS					
4-1.	Adjustments with Commander	38			
4-2.	Adjustment Method	39			
4-3.	Picture Quality Adjustments	44			
4-4.	A Board Adjustment After IC003 (Memory) Replacement	44			
4-5.	Picture Distortion Adjustment	45			

SELF DIAGNOSTIC FUNCTION

The units in this manual contain a self-diagnostic function. If an error occurs, the STANDBY/TIMER lamp will automatically begin to flash.

The number of times the lamp flashes translates to a probable source of the problem. A definition of the STANDBY/TIMER lamp flash indicators is listed in the instruction manual for the user's knowledge and reference. If an error symptom cannot be reproduced, the remote commander can be used to review the failure occurrence data stored in memory to reveal past problems and how often these problems occur.

1. DIAGNOSTIC TEST INDICATORS

When an errors occurs, the STANDBY/TIMER lamp will flash a set number of times to indicate the possible cause of the problem. If there is more than one error, the lamp will identify the first of the problem areas.

Result for all of the following diagnostic items are displayed on screen. No error has occurred if the screen displays a "0".



Diagnostic Item Description	No. of times STANDBY/TIMER lamp flashes	Self-diagnostic display/Diagnostic result	Probable Cause Location	Detected Symptoms
• Power does not turn on	Does not light	—	• Power cord is not plugged in. • Fuse is burned out F4601 (F Board)	• Power does not come on. • No power is supplied to the TV. • AC power supply is faulty.
• +B overcurrent (OCP) or overvoltage (OVP) • Vertical deflection stopped • Horizontal deflection overdrive	2 times	002:000 or 002:001~255 003:001~255 004:001~255 at the same time	• H.OUT Q511 is shorted. (A board) • IC1800 is shorted. (C3 Board). • -13V is not supplied. (A board) • IC 503 faulty (A board) • IC 301 faulty (A board)	• Power does not come on. • Load on power line is shorted. • Has entered standby state after horizontal raster. • Vertical deflection pulse is stopped. • Power line is shorted or power supply is stopped.
• White balance failure (no PICTURE)	5 times	005:000 or 005:001~225	• G2 is improperly adjusted. (Note 2) • CRT problem. • Video OUT IC701 is faulty. (C3 board) • IC301 is faulty. (A board) • No connection A board to C5/C3 boards.	• No raster is generated. • CRT cathode current detection reference pulse output is small.
• Micro reset	—	101:00 or 101:001~225	• Discharge CRT (C3 Board) • Static discharge • External noise	• Power is shut down shortly, after this return back to normal. • Detect Micro latch up.

Note 1: If a + B overcurrent is detected, stoppage of the vertical deflection is detected simultaneously.

The symptom that is diagnosed first by the microcontroller is displayed on the screen.

Note 2: Refer to screen (G2) Adjustment in section 3-4 of this manual.

2. DISPLAY OF STANDBY/TIMER LIGHT FLASH COUNT



<u>Diagnostic Item</u>	<u>Flash Count*</u>
+B overcurrent/overvoltage Vertical deflection stopped	2 times
White balance failure	5 times

* One flash count is not used for self-diagnostic.

3. STOPPING THE STANDBY/TIMER FLASH

Turn off the power switch on the TV main unit or unplug the power cord from the outlet to stop the STANDBY/TIMER lamp from flashing.

4. SELF-DIAGNOSTIC SCREEN DISPLAY

For errors with symptoms such as “power sometimes shuts off” or “screen sometimes goes out” that cannot be confirmed, it is possible to bring up past occurrences of failure for confirmation on the screen:

[To Bring Up Screen Test]

In standby mode, press buttons on the remote commander sequentially in rapid succession as shown below:

Screen display ➡ channel 5 ➡ Sound volume - ➡ Power ON
↑

Note that this differs from entering the service mode (mode volume +).

Self-Diagnosis screen display

SELF DIAGNOSTIC

002 : 000 ←

003 : 000

004 : 000

005 : 001 ←

101 : 000

Numeral "0" means that no fault has been detected.

Numeral "1" means a fault has been detected.

5. HANDLING OF SELF-DIAGNOSTIC SCREEN DISPLAY

Since the diagnostic results displayed on the screen are not automatically cleared, always check the self-diagnostic screen during repairs. When you have completed the repairs, clear the result display to “0”.

Unless the result display is cleared to “0”, the self-diagnostic function will not be able to detect subsequent faults after completion of the repairs.

[Clearing the result display]


To clear the result display to “0”, press buttons on the remote commander sequentially as shown below when the diagnostic screen is being displayed.

Channel 8 ➡ 0

[Quitting Self-diagnostic screen]

To quit the entire self-diagnostic screen, turn off the power switch on the remote commander or the main unit.

6. SELF-DIAGNOSTIC CIRCUIT

**+B overcurrent (OCP)**

Occurs when an overcurrent on the +B(135) line is detected by Q604. If Q604 go to ON and the voltage to pin 18 of IC301 should go down when V.SYNC is more than seven verticals in a period, the unit will automatically turn off.

Vertical deflection stopped

Occurs when an absence of the vertical deflection pulse is detected by Q509 and IC001 shut down the power supply.

Vertical deflection overcurrent

Occurs when an overcurrent on V drive line is detected by Q507. Power supply will be shut down when detect this by IC001.

White balance failure

If the RGB levels* do not balance or become low level within 5 seconds, this error will be detected by IC301. TV will stay on, but there will be no picture.










* (Refers to the RGB levels of the AKB detection Ref pulse that detects IK.)

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

SECTION 1 GENERAL (KV-PF21P40)

WARNING

- Dangerously high voltages are present inside the TV.
- TV operating voltage: 220 – 240 V AC.

 Do not open the cabinet and the rear cover of the TV. Refer servicing to qualified personnel.	 Install the TV in a stable position. Do not allow children to climb onto it.
 To prevent fire or shock hazard, do not expose the TV to rain or moisture.	 Do not operate the TV if any liquid or solid object falls into it. Have it checked immediately by qualified personnel only.
 Do not install the TV in a confined space, such as a bookcase or built-in cabinet. Do not block the ventilation openings of the TV.	 Clean the TV with a dry and soft cloth. Do not use benzine, thinner, or any other chemicals to clean the TV. Do not scratch the picture tube.
 Do not pull the power cord to disconnect the TV. Pull it out by the plug.	 Do not plug in too many appliances to the same power socket. Do not damage the power cord.
 Disconnect the power cord if you are not going to use the TV for several days.	 Do not install the TV in hot, humid or excessively dusty places.


Using Your New TV

Getting Started

Step 1


Connect the antenna

If you wish to connect a VCR, see the “Connecting a VCR” diagram below.



Connecting a VCR

To watch the video, press   (see page 12).



Notes


- If you connect a stereo VCR, connect the yellow plug to (the yellow jack) and the white plug to (the black jack).
- If you connect a VCR to the 1 (antenna) terminal, preset the signal output from the VCR to the program number 0 on the TV.
- When no signal is input to the connected video equipment, the TV screen becomes blue.

CAUTION

Do not connect the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.

Step 2

Insert the batteries into the remote




Note

- Do not use old batteries nor use different types of batteries together.

Step 3

Preset the channels automatically



Tips

- If you want to stop automatic channel presetting, press SELECT twice.
- If your TV has preset an unwanted channel or cannot preset a particular channel, then preset your TV manually (see page 9).

Now You Are Ready. . .

To watch your TV, see page 11.




Using Your New TV

Connecting optional components

You can connect optional video components, such as a VCR, multi disc player, camcorder or video game.

To watch the picture of the connected equipment, press (see page 12).


Connecting a camcorder/video game equipment using the (video input) jacks



Note

- You can also connect video equipment to the 1 (video input) jacks at the rear of your TV.

Connecting video equipment using the (monitor output) jacks



Note

- When connecting a stereo VCR, connect the yellow plug to (the yellow jack) and the white plug to (the black jack).


Securing the TV

To prevent the TV from falling, secure the TV using one of the following methods:

- A** With the supplied screws, attach the band to the TV stand and to the rear of the TV using the provided hole.

or

- B** Put the cord or chain through the clamps to secure the TV against a wall or pillar.




Note

- Use only the supplied screws. Use of other screws may damage the TV.

Using Your New TV

Presetting channels

You can preset up to 100 TV channels in numerical sequence from program number 1 using the remote and the buttons on your TV as well.



Presetting channels automatically

- 1** Press ① to turn on the TV.



- 2** Press AUTO PROGR.






VHF LOW B/G

To preset channels automatically from a specified program number

- Press SELECT until "AUTO PROGRAM" appears.
- Press + or -. The on-screen display will start flashing.
- Press PROGR +/- or the number buttons until the desired program number appears.
- Press + or -.

Presetting channels manually


- 1 Press SELECT until "MANUAL PROGRAM" appears.  → 
- 2 Press + or -.  → 
- 3 Press PROGR +/- or the number buttons until the desired program number appears.  or 
- 4 Press + or - until the desired channel picture appears.  → 
- 5 Press SELECT. 

Using Your New TV

To change the color system setting

If the color is abnormal when receiving programs through the ㄗ (antenna) terminal or the ㉔ (video input) jack

- (1) Press SELECT until "COL SYS" appears. 

- (2) Press + or - to select the appropriate color system until the color is optimal. 

Tip

- Normally set "COL SYS" to "AUTO".

continued

Using Your New TV | 9

Presetting channels (continued)

Skipping program numbers

- 1 Press PROGR +/- or the number buttons until the unused or unwanted program number appears.
- 2 Press SELECT until "MANUAL PROGRAM" appears.
- 3 Press + or -.
- 4 Press PIC MODE.
- 5 Press SELECT.

To preset the skipped program number again

Preset the channel automatically or manually.

Tip

- You can also use SELECT and ㄗ +/- on the TV to preset channels and skip program numbers.

To use the fine tuning (FINE) function

The fine tuning (FINE) function may help to reduce the following problems: double images and lines moving across the TV screen.


You can use the fine tuning function as below:

- (1) Select the program number you want to adjust.
- (2) Press SELECT until "MANUAL PROGRAM" appears on the screen.
- (3) Press + or - on the remote control once.
- (4) Press ㊄ ㊅ to display "FINE" on the screen.
- (5) Press + or - continuously until the above problems are minimized.
The + or - icon on the screen flashes while tuning.
- (6) Press SELECT to return to normal screen.

10 | Using Your New TV

Watching the TV

This section explains functions used while watching the TV. Most operations can be done using the remote.



Using Your New TV


1 Press ① to turn on the TV.

When the TV is in the standby mode (the ① indicator on the TV is lit red), press ① on the remote or PROGR +/- on the TV.



2 Press PROGR +/- or the number buttons to select the TV program.

For double digit numbers, press -/-, then the number (e.g., for 25, press -/-, then 2 and 5).



3 Press +/- to adjust the volume.



Watching the TV (continued)

Additional tasks

To	Do this
Turn off temporarily	Press ①. The ① indicator on the TV lights up red.
Turn off completely	Press ① on the TV.
Mute the sound	Press ①.
Watch the video input (VCR, camcorder, etc.)	Press ① to select "VIDEO 1" or "VIDEO 2". To return to the TV program, press ①.
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press ①.
Adjust the volume of each TV program automatically	Press SELECT repeatedly until "INTELLIGENT VOL" appears, then press + or - to select "ON". To cancel, select "OFF".

* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

Changing the on-screen display language

1 Press SELECT until "LANGUAGE / ١٢٣٤ : ENGLISH" appears on the screen.



2 Press + or - to select "١٢٣٤".




Tip

- You can also use SELECT and +/- on the TV to select the on-screen display language.

continued

Setting the Wake Up timer

- 1 Press  until the desired period of time appears.

- 2 Select the TV program or video mode you want to display when you wake up.
- 3 Press  or set the Sleep timer if you want the TV to turn off automatically.

The  indicator on the TV lights up orange.

To cancel the Wake Up timer


Press  until "WAKE UP TIMER: OFF" appears or turn off the TV's main power.

Notes

- The Wake Up timer starts immediately after the on-screen display disappears.
- If no buttons or controls are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into the standby mode. To continue watching the TV, press any button or control on the TV or the remote.

Setting the Sleep timer

Press  until the desired period of time appears.




To cancel the Sleep timer

Press  until "SLEEP TIMER: OFF" appears or turn the TV off.

Advanced Operations

Customizing the picture and sound


You can customize the picture and sound by selecting the picture and sound modes or by adjusting its settings.



Selecting the picture and sound modes

To select the picture mode

Press PIC MODE repeatedly until you get the desired picture mode.



Select	To
DYNAMIC	receive high contrast pictures.
STANDARD	receive normal contrast pictures.
SOFT	receive mild pictures.

To select the sound mode

Press SOUND MODE repeatedly until you get the desired sound mode.




Select	To
DYNAMIC	listen to dynamic and clear sound that emphasizes the low and high sound.
DRAMA	listen to sound that emphasizes vocals and background music.
SOFT	receive soft sound.

Adjusting the picture and sound settings

- 1 Press SELECT until the desired setting appears.



Each time you press SELECT, the setting item will change as follows:



- 2 Press + or – to adjust the item.



- 3 To adjust other items, repeat steps 1 to 2.

* "HUE" can be adjusted for the NTSC system only.


Notes

- When you select a picture or sound mode, the adjusted settings will be reset according to the selected mode.
- You can also use SELECT and $\triangle$ +/- on the TV to adjust the picture and sound settings.

Advanced Operations


Enjoying bilingual programs

You can choose the sound of programs which are broadcast with the A2 bilingual system.



Viewing a bilingual program

Press A/B repeatedly until you receive the sound you want.




Note

- When viewing a non-bilingual program, select the main sound. Otherwise, you may hear some noise or abnormal sound.


Blocking the channels (CHILD LOCK)

You can prevent a child from watching certain channels by using the buttons on the remote control.



1 Select the channel you want to lock.


2 Press SELECT until "CHILD LOCK" appears on the screen.



3 Press + or - to select "ON".

The **f** symbol appears on the screen.

To unlock the channel, press + or - to select "OFF". The **f** symbol disappears from the screen.




Note

- If you preset a locked channel, that particular channel will be unlocked automatically.

Additional Information

Self-diagnosis function

Your TV is equipped with a self-diagnosis function. If there is a problem with your TV, the **⏻** indicator flashes red. The number of times the **⏻** indicator flashes indicates the possible causes.



- 1** Check that the **⏻** indicator flashes red a number of times between 3-second intervals.
- 2** Count the number of times the **⏻** indicator flashes.
- 3** Press **⏻** (main power) to turn off your TV.
- 4** Inform your nearest Sony service center about the number of times the **⏻** indicator flashes. Be sure to note the model name and serial number located on the rear of your TV.

Troubleshooting

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer.

Symptom	Solutions	Possible cause
Snowy picture 	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)	- Connection is loose or the cable is damaged. - Channel presetting is inappropriate or incomplete.
Noisy sound 	- Check the antenna type (VHF/UHF). Contact a Sony dealer for advice. - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster.	- The antenna type is inappropriate. - The antenna direction is inappropriate. - Signal transmission is low.
Distorted picture 	Turn off or disconnect the booster if it is in use.	Broadcast signals are too strong.
Noisy sound 		
No picture 	- Check the power cord, antenna and the VCR connections. - Press (power). - Press (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	- The power cord, antenna or VCR is not connected. - The TV is not turned on.
No sound 		

Additional Information

Troubleshooting (continued)

Symptom	Solutions	Possible cause
Good picture 	- Press $\triangle$ + to increase the volume level. - Press $\times$ to cancel the muting. - Press A/B () until a good sound is heard. (page 16)	- The volume level is too low. - The sound is muted. - Broadcast signal has a transmission problem.
No sound 		
Dotted lines or stripes 	- Do not use a hair dryer or other equipment near the TV. - Adjust the antenna direction for minimum interference. Contact a Sony dealer for advice.	There is local interference from cars, neon signs, hair dryers, power generators, etc.
Double images or "ghosts" 	- Use a highly directional antenna. - Use the fine tuning (FINE) function. (page 10) - Adjust the antenna direction. Contact a Sony dealer for advice. - Turn off or disconnect the booster if it is in use.	- Broadcast signals are reflected by nearby mountains or buildings. - The antenna direction is inappropriate. - Use of a booster is inappropriate.
No color 	- Press SELECT until "COLOR" appears on the screen, then press + or - to adjust the color level. (page 15) - Press SELECT until "COL SYS" appears on the screen, then check the color system setting (usually set this to "AUTO"). (page 9). - Adjust the antenna direction. Contact a Sony dealer for advice.	- The color level setting is too low. - The color system setting is inappropriate. - The antenna direction is inappropriate.
Abnormal color patches 	Keep external speakers or other electrical equipment away from the TV. Do not move the TV while the TV is turned on. Press (main power) on the TV to turn off the TV for about five minutes, then turn it on again.	The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.


continued

Symptom	Solutions	Possible cause
Lines moving across the TV screen.	Use the fine tuning (FINE) function. (page 10)	There is interference from external sources, e.g., heavy machineries, nearby broadcast station.
The  indicator on your TV flashes red a number of times between 3-second intervals.	Contact your nearest Sony service center. (page 18)	Your TV may need service.
TV cabinet creaks.	—	Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.
A "boom" sound is heard when the TV is turned on.	—	The TV's demagnetizing function is working. This does not indicate a malfunction.

Identifying parts and controls


Refer to the pages indicated in parentheses () for details.

Front panel




- ① ① (main power) button (5)
- ② PROGR +/- (program) buttons (11)
- ③ +/- (volume) buttons (11)
- ④  (TV/video) button (12)
- ⑤ AUTO PROGR (program) button (5)
- ⑥ SELECT button (9)
- ⑦  (earphone) jack

Remote Control



- 1 (power) button (11)
- 2 (TV) button (12)
- 3 Number buttons (11)
- 4 JUMP button (12)
- 5 PROGR +/- buttons (11)
- 6 SELECT button (9)
- 7 PIC MODE button (14)
- 8 + or - buttons (9)
- 9 (display) button (12)
- 10 (muting) button (12)
- 11 (video) button (12)
- 12 +/- (volume) buttons (11)
- 13 A/B button (16)
- 14 Timer setting buttons (13)
 - (wake up timer)
 - (sleep timer)
- 15 FAVORITE button (not used for this model)



- 16 SOUND MODE button (14)
- 17 Teletext operation buttons (not used for this model)
 - (text) (enlarge)
 - (reveal) (hold)
 - (index) (text clear)
 - (FASTEXT: red, green, yellow, blue)

Names/symbols of buttons on the remote are indicated in different colors to represent the available functions.








Label color	Button function
White	For general TV operations
Green	For Teletext operations

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

SECTION 1-2 GENERAL (except KV-PF21P40)

WARNING

- Dangerously high voltages are present inside the TV.
- Operate the TV only between 220 – 240 V AC.

 Do not open the cabinet and the rear cover of the TV. Refer servicing to qualified personnel.	 Install the TV in a stable position. Do not allow children to climb onto it.
 To prevent fire or shock hazard, do not expose the TV to rain or moisture.	 Do not operate the TV if any liquid or solid object falls into it. Have it checked immediately by qualified personnel only.
 Do not install the TV in a confined space, such as a bookcase or built-in cabinet. Do not block the ventilation openings of the TV.	 Clean the TV with a dry and soft cloth. Do not use benzene, thinner, or any other chemicals to clean the TV. Do not scratch the picture tube.
 Do not pull the power cord to disconnect the TV. Pull it out by the plug.	 Do not plug in too many appliances to the same power socket. Do not damage the power cord.
 Disconnect the power cord during lightning storms or if you are not going to use the TV for several days.	 Do not install the TV in hot, humid or excessively dusty places.


Using Your New TV

Getting Started

Step 1


Connect the antenna

If you wish to connect a VCR, see the "Connecting a VCR" diagram below.



Connecting a VCR

To watch the video, press  (see page 12).



Notes


- If you connect a monaural VCR, connect the yellow plug to (yellow jack) and the black plug to L (MONO) (the white jack).
- If you connect a VCR to the (antenna) terminal, preset the signal output from the VCR to the program number 0 on the TV.
- When no signal is input to the connected video equipment, the TV screen becomes blue.

CAUTION

Do not connect the power cord until you have completed making all other connections; otherwise a minimum leakage current might flow through the antenna and other terminals to ground.

Step 2

Insert the batteries into the remote




Note

- Do not use old batteries nor use different types of batteries together.

Step 3

Preset the channels automatically



Tips


- If you want to stop automatic channel presetting, press SELECT twice.
- If your TV has preset an unwanted channel or cannot preset a particular channel, then preset your TV manually (see page 9).

Note (KV-TF21P50 only)

- During automatic channel presetting, your TV screen will indicate "B/G" for the TV system.

Now You Are Ready. . .

To watch your TV, see page 11.




Connecting optional components

You can connect optional audio/video components, such as a VCR, multi disc player, camcorder, video game or stereo system.

To watch the picture of the connected equipment, press (see page 12).


Connecting a camcorder/video game equipment using the (video input) jacks



Note

- You can also connect video equipment to the (video input) jacks at the rear of your TV.

Connecting audio/video equipment using the (monitor output) jacks



Note

- When connecting a monaural VCR, connect the yellow plug to (the yellow jack) and the black plug to L (MONO) (the white jack).


Securing the TV

To prevent the TV from falling, secure the TV using one of the following methods:

- A** With the supplied screws, attach the band to the TV stand and to the rear of the TV using the provided hole.

or

- B** Put the cord or chain through the clamps to secure the TV against a wall or pillar.




Note

- Use only the supplied screws. Use of other screws may damage the TV.

Using Your New TV

Presetting channels

You can preset up to 100 TV channels in numerical sequence from program number 1 using the remote and the buttons on your TV as well.



Presetting channels automatically

- 1** Press ① to turn on the TV.



- 2** Press AUTO PROGRAM.



VHF LOW AUTO

Note

- During automatic channel presetting, your TV screen will indicate "B/G" for the TV system.



To preset channels automatically from a specified program number

- Press SELECT until "AUTO PROGRAM" appears.
- Press + or -. The on-screen display will start flashing.
- Press PROG +/– or the number buttons until the desired program number appears.
- Press + or –.

- 8** Using Your New TV

Using Your New TV | 7

Presetting channels manually

- 1 Press SELECT until "MANUAL PROGRAM" appears.
 
- 2 Press + or -.
 
- 3 Press PROGR +/- or the number buttons until the desired program number appears.
 
- 4 Press + or - until the desired channel picture appears.
 
- 5 Press SELECT.
 

Using Your New TV

To change the color system setting

If the color is abnormal when receiving programs through the ㄗ (antenna) terminal or the ㉔ (video input) jack

- (1) Press SELECT until "COL SYS" appears.



- (2) Press + or - to select the appropriate color system until the color is optimal.

Tip

- Normally set "COL SYS" to "AUTO".

Note

- The color system "SECAM" is available for KV-TF21M60 only.

continued

Presetting channels (continued)

Skipping program numbers

- 1 Press PROGR +/- or the number buttons until the unused or unwanted program number appears.
- 2 Press SELECT until "MANUAL PROGRAM" appears.
- 3 Press + or -.
- 4 Press PIC MODE.
- 5 Press SELECT.

To preset the skipped program number again

Preset the channel automatically or manually.

Tip

- You can also use SELECT and ㄗ +/- on the TV to preset channels and skip program numbers.

To use the fine tuning (FINE) function


The fine tuning (FINE) function may help to reduce the following problems: double images and lines moving across the TV screen.

You can use the fine tuning function as below:

- (1) Select the program number you want to adjust.
- (2) Press SELECT until "MANUAL PROGRAM" appears on the screen.
- (3) Press + or - on the remote control once.
- (4) Press ㄗ ㄗ to display "FINE" on the screen.
- (5) Press + or - continuously until the above problems are minimized.
The + or - icon on the screen flashes while tuning.
- (6) Press SELECT to return to normal screen.

Watching the TV

This section explains functions used while watching the TV. Most operations can be done using the remote.




1 Press ① to turn on the TV.

When the TV is in the standby mode (the ① indicator on the TV is lit red), press ① on the remote or PROGR +/- on the TV.



2 Press PROGR +/- or the number buttons to select the TV program.

For double digit numbers, press +/-, then the number (e.g., for 25, press +/-, then 2 and 5).



3 Press +/- to adjust the volume.



Watching the TV (continued)

Additional tasks

To	Do this
Turn off temporarily	Press ①. The ① indicator on the TV lights up red.
Turn off completely	Press ① on the TV.
Mute the sound	Press ①.
Watch the video input (VCR, camcorder, etc.)	Press ① to select "VIDEO 1" or "VIDEO 2". To return to the TV program, press ①.
Jump back to the previous channel	Press JUMP.
Display the on-screen information*	Press ①.
Adjust the volume of each TV program automatically	Press SELECT repeatedly until "INTELLIGENT VOL" appears, then press + or - to select "ON". To cancel, select "OFF".

* The picture, sound, and either the program number or video mode are displayed. The on-screen display for the picture and sound information disappears after about 3 seconds.

Changing the on-screen display language

1 Press SELECT until "LANGUAGE / ภาษา : ENGLISH" appears on the screen.



2 Press + or - to select "ไทย".



Tip

- You can also use SELECT and +/- on the TV to select the on-screen display language.

continued

Setting the Wake Up timer

- Press until the desired period of time appears.
- Select the TV program or video mode you want to display when you wake up.
- Press or set the Sleep timer if you want the TV to turn off automatically.

The indicator on the TV lights up orange.

To cancel the Wake Up timer


Press until "WAKE UP TIMER: OFF" appears or turn off the TV's main power.

Notes

- The Wake Up timer starts immediately after the on-screen display disappears.
- If no buttons or controls are pressed for more than two hours after the TV is turned on using the Wake Up timer, the TV automatically goes into the standby mode. To continue watching the TV, press any button or control on the TV or the remote.

Setting the Sleep timer

Press until the desired period of time appears.



To cancel the Sleep timer


Press until "SLEEP TIMER: OFF" appears or turn the TV off.

Advanced Operations

Customizing the picture and sound

You can customize the picture and sound by selecting the picture and sound modes or by adjusting its settings.


You can change the sound effect by selecting the surround mode.



Selecting the picture and sound modes

To select the picture mode

Press PIC MODE repeatedly until you get the desired picture mode.



Select	To
DYNAMIC	receive high contrast pictures.
STANDARD	receive normal contrast pictures.
SOFT	receive mild pictures.

To select the sound mode

Press SOUND MODE repeatedly until you get the desired sound mode.




Select	To
DYNAMIC	listen to dynamic and clear sound that emphasizes the low and high sound.
DRAMA	listen to sound that emphasizes vocals and background music.
SOFT	receive soft sound.


Adjusting the picture and sound settings

- 1

Press SELECT until the desired setting appears.


- 2

Press + or – to adjust the item.


- 3

To adjust other items, repeat steps 1 to 2.

* "HUE" can be adjusted for the NTSC system only.


Notes

- When you select a picture or sound mode, the adjusted settings will be reset according to the selected mode.
- You can also use SELECT and $\triangle$ +/- on the TV to adjust the picture and sound settings.

Selecting the surround mode

- 1

Press SELECT repeatedly until "SURROUND" appears.


- 2


Press + or – to select the desired surround sound.



Select	To
MOVIE	listen to sound that spreads out over a large area, giving the feeling of being at a movie theatre.
MUSIC	listen to the sound that gives the feeling of being at a live concert.
OFF	turn off the surround sound.

Blocking the channels (CHILD LOCK)

You can prevent a child from watching certain programs by using the buttons on the remote control.



- 1

Select the TV program you want to lock.
- 2


Press SELECT until "CHILD LOCK" appears on the screen.


- 3

Press + or – to select "ON".

The **i** symbol appears on the screen.

To unlock the channel, press + or – to select "OFF". The **i** symbol disappears from the screen.




Note

- If you preset a locked channel, that particular channel will be unlocked automatically.

Blocking the channels (CHILD LOCK)

You can prevent a child from watching certain channels by using the buttons on the remote control.



1 Select the channel you want to lock.


2 Press SELECT until "CHILD LOCK" appears on the screen.



3 Press + or - to select "ON".

The symbol appears on the screen.

To unlock the channel, press + or - to select "OFF". The symbol disappears from the screen.




Note

- If you preset a locked channel, that particular channel will be unlocked automatically.

continued

Enjoying stereo or bilingual programs (continued)

When receiving an A2 (German) program



If the sound is distorted or noisy when receiving a monaural program through the (antenna) terminal

Press A/B repeatedly until "MONO" appears on the screen.

To cancel the monaural sound setting, press A/B again until "AUTO" appears on the screen.




Notes

- The "MONO" or "AUTO" setting is memorized for each program position.
- You cannot receive stereo broadcast signal when the TV is in the "MONO" setting. Normally set the TV to "AUTO."

Viewing a bilingual program (KV-TF21P50 only)

Press A/B repeatedly until you receive the sound you want.



Note


- When viewing a non-bilingual program, select the main sound. Otherwise, you may hear some noise or abnormal sound.

Additional Information

Self-diagnosis function

Your TV is equipped with a self-diagnosis function. If there is a problem with your TV, the  indicator flashes red. The number of times the  indicator flashes indicates the possible causes.

Front of TV



- 1** Check that the  indicator flashes red a number of times between 3-second intervals.
- 2** Count the number of times the  indicator flashes.
- 3** Press  (main power) to turn off your TV.
- 4** Inform your nearest Sony service center about the number of times the  indicator flashes.
Be sure to note the model name and serial number located on the rear of your TV.

Additional Information

Troubleshooting

If you find any problem while viewing your TV, please check the following guide. If any problem persists, contact your Sony dealer.

Symptom	Solutions	Possible cause
Snowy picture 	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Press SELECT until "MANUAL PROGRAM" appears on the screen then preset the channel again. (page 9)	- Connection is loose or the cable is damaged. - Channel presetting is inappropriate or incomplete.
Noisy sound 	- Check the antenna type (VHF/UHF). Contact a Sony dealer for advice. - Adjust the antenna direction. Contact a Sony dealer for advice. - Try using a booster.	- The antenna type is inappropriate. - The antenna direction is inappropriate. - Signal transmission is low.
Distorted picture 	Turn off or disconnect the booster if it is in use.	Broadcast signals are too strong.
Noisy sound 		
Good picture 	- If the sound of all the channels are noisy, check the TV system (TV SYS) setting (page 10), then press AUTO PROGR to preset the channels again (page 8). - If the sound of some channels are noisy, select the channel, then select the appropriate TV system (TV SYS). (page 10) - If the sound of some channels are noisy, select the channel, then press A/B  to select the main sound. (page 12)	- The TV system setting or channel presetting is inappropriate or incomplete. - The select sound is inappropriate.
Noisy sound 		
No picture 	- Check the power cord, antenna and the VCR connections. - Press  (power). - Press  (main power) on the TV to turn off the TV for about five seconds, then turn it on again.	- The power cord, antenna or VCR is not connected. - The TV is not turned on.
No sound 		

Symptom	Solutions	Possible cause
Good picture 	- Press $\triangle$ + to increase the volume level. - Press $\times$ to cancel the muting. - Press A/B $\oplus$ until a better sound is heard.	- The volume level is too low. - The sound is muted. - Broadcast signal has a transmission problem.
No sound 		
Dotted lines or stripes 	- Do not use a hair dryer or other equipment near the TV. - Adjust the antenna direction for minimum interference. Contact a Sony dealer for advice.	There is local interference from cars, neon signs, hair dryers, power generators, etc.
Double images or "ghosts" 	- Use a highly directional antenna. - Use the fine tuning (FINE) function. (page 10) - Adjust the antenna direction. Contact a Sony dealer for advice. - Turn off or disconnect the booster if it is in use.	- Broadcast signals are reflected by nearby mountains or buildings. - The antenna direction is inappropriate. - Use of a booster is inappropriate.
No color 	- Press SELECT until "COLOR" appears on the screen, then press + or - to adjust the color level. (page 15) - Press SELECT until "COLSYS" appears on the screen, then check the color system setting (usually set this to "AUTO"). (page 9). - Adjust the antenna direction. Contact a Sony dealer for advice.	- The color level setting is too low. - The color system setting is inappropriate. - The antenna direction is inappropriate.
Abnormal color patches 	Keep external speakers or other electrical equipment away from the TV. Do not move the TV while the TV is turned on. Press $\odot$ (main power) on the TV to turn off the TV for about five minutes, then turn it on again.	The magnetic disturbance from external speakers or other equipment, or the direction of the earth's magnetic field may affect the TV.
TV cannot receive stereo broadcast signal (KV-TF21M60)	Press A/B $\oplus$ until "AUTO" appears on the screen.	The stereo reception setting is inappropriate.

continued

Additional Information | 21

Troubleshooting (continued)


Symptom	Solutions	Possible cause
Stereo broadcast sound switches on and off or is distorted. or The sound switches between monaural and stereo frequently. (KV-TF21M60)	- Check the antenna cable and connection on the TV, VCR and on the wall. (page 4) - Adjust the antenna direction. Contact a Sony dealer for advice. - Press A/B $\oplus$ until a better sound is heard. (page 17)	- Connection is loose or the cable is damaged. - The antenna direction is inappropriate. - Broadcast signal has a transmission problem.
Lines moving across the TV screen.	Use the fine tuning (FINE) function. (page 10)	There is interference from external sources, e.g., heavy machineries, nearby broadcast station.
The $\odot$ indicator on your TV flashes red a number of times between 3-second intervals.	Contact your nearest Sony service center. (page 19)	Your TV may need service.
TV cabinet creaks.	—	Changes in room temperature sometimes make the TV cabinet expand or contract, making a noise. This does not indicate a malfunction.
A "boom" sound is heard when the TV is turned on.	—	The TV's demagnetizing function is working. This does not indicate a malfunction.

22 | Additional Information

Identifying parts and controls

Refer to the pages indicated in parentheses () for details.

Front panel




- 1 ① (main power) button (5)
- 2 PROGR +/- (program) buttons (11)
- 3 ∇ +/- (volume) buttons (11)
- 4 $\square$ (TV/video) button (12)
- 5 AUTO PROGR (program) button (5)
- 6 SELECT button (9)
- 7 $\odot$ (headphone) jack

continued

Identifying parts and controls (continued)

Remote Control



- 1 $\odot$ (power) button (11)
- 2 $\square$ (TV) button (12)
- 3 Number buttons (11)
- 4 JUMP button (12)
- 5 PROGR +/- buttons (11)
- 6 SELECT button (9)
- 7 PIC MODE button (14)
- 8 + or - buttons (9)
- 9 B (display) button (12)
- 10 X (muting) button (12)
- 11 V (video) button (12)
- 12 ∇ +/- (volume) buttons (11)
- 13 A/B button (17)
- 14 Timer setting buttons (13)
 - $\odot$ (wake up timer)
 - $\odot$ (sleep timer)
- 15 FAVORITE button (not used for this model)


- 16 SOUND MODE button (14)
- 17 Teletext operation buttons (not used for this model)
 - B (text) $\oplus$ (enlarge)
 - ? (reveal) H (hold)
 - B (index) X (text clear)
 - $\blacksquare$ (FASTEXT: red, green, yellow, blue)

Names/symbols of buttons on the remote are indicated in different colors to represent the available functions.


Label color	Button function
White	For general TV operations
Green	For Teletext operations

SECTION 2 DISASSEMBLY


2-1. REAR COVER REMOVAL




2-2. CHASSIS ASSY REMOVAL



2-3. F BRACKET REMOVAL (KV-PF21P40)




(KV-TF21M60/TF21P50)



2-4. SERVICE POSITION


(Note: Remove F Bracket first.)




2-5. REPLACEMENT OF PARTS

For replacement of the Multi Button and Bar Optical ,unscrew to exchange with the new parts, and fix them with screws (+BVTP) respectively.


2-5-1. REPLACEMENT OF MULTI BUTTON




2-5-2. REPLACEMENT OF BAR OPTICAL



2-6. TERMINAL BRACKET REMOVAL




2-7. DEGAUSS COIL REMOVAL



2-8. PICTURE TUBE REMOVAL


NOTE : The picture tube for OCE model is upside down, and the position for the anode cap and tension springs are changed accordingly.




•REMOVAL OF ANODE-CAP

NOTE : After removing the anode, short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT.


•REMOVING PROCEDURES



- ① Turn up one side of the rubber cap in the direction indicated by the arrow ①.




- ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ②.



- ③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow ③.

• HOW TO HANDLE AN ANODE-CAP

- ① Do not damage the surface of anode-caps with sharp shaped objects.
- ② Do not press the rubber too hard so as not to damage the inside of anode-cap.
A metal fitting called the shatter-hook terminal is built into the rubber.
- ③ Do not turn the foot of rubber over too hard.
The shatter-hook terminal will stick out or damage the rubber.



SECTION 3

SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switches should be set as follows unless otherwise noted:

PICTURE control normal

BRIGHTNESS control normal

Perform the adjustments in the following order :

1. Beam Landing
2. Convergence
3. Focus
4. White Balance

Note : Test Equipment Required.

1. Color-bar/Pattern Generator
2. Degausser
3. Oscilloscope

Preparation :

- In order to reduce the influence of geomagnetism on the set's picture tube, face it east or west.
- Switch on the set's power and degauss with the degausser.

3-1. BEAM LANDING

1. Input a white signal with the pattern generator.

Contrast } normal
Brightness }

2. Set the pattern generator raster signal to a green raster.
3. Move the deflection yoke to the rear and adjust with the purity control so that the green is at the center and the blue and the red take up equally sized areas on each side.
(See Figures 3-1 through 3-3.)
4. Move the deflection yoke forward and adjust so that the entire screen is green. (See Figure 3-1.)
5. Switch the raster signal to blue, then to red and verify the condition.
6. When the position of the deflection yoke has been decided, fasten the deflection yoke with the screws and DY spacers.
7. If the beam does not land correctly in all the corners, use a magnet to adjust it.
(See Figure 3-4.)




Fig. 3-1




Fig. 3-2




Fig. 3-3





Fig. 3-4

3-2. CONVERGENCE


Preparation :

- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Minimize the brightness setting.
- Provide dot pattern.


(1) Horizontal and Vertical Static Convergence




(Moving vertically), adjust the V. STAT magnet so that the red, green and blue dots are on top of each other at the center of the screen.




① V. STAT



② H. STAT VR




③



④ BMC (Hexapole) Magnet.


If the red, green and blue dots are not balanced or aligned, then use the BMC magnet to adjust in the manner described below.




(2) Dynamic Convergence Adjustment

Preparation:



- Before starting this adjustment, adjust the horizontal static convergence and the vertical static convergence



on DY




(3) Screen-corner Convergence



3-3. FOCUS ADJUSTMENT


Adjust FOCUS control on the flyback transformer for the best focus.



3-4. G2 (SCREEN) AND WHITE BALANCE ADJUSTMENTS

1. G2 (SCREEN) ADJUSTMENT

- 1) Set the PICTURE to normal.
- 2) Put to VIDEO input mode without signals.
- 3) Connect R, G and B of the C3 board cathode to the oscilloscope.
- 4) Adjust BRIGHTNESS to obtain the cathode voltage to the value below.
- 5) Adjust G2 (Screen) on FBT until picture shows the point before cut-off.




2. WHITE BALANCE ADJUSTMENT

- 1) Set to Service Mode (Refer Section 4-1: ADJUSTMENTS WITH COMMANDER).
- 2) Input white raster signal.
- 3) Set the PICTURE to minimum.
- 4) Select GCT (WHB 4) and BCT (WHB 5) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 5) Set the PICTURE to maximum.
- 6) Select GDR (WHB 1) and BDR (WHB 2) with [1] and [4], and adjust the level with [3] and [6] for the best white balance.
- 7) Write into the memory by pressing [MUTING] then [0].

3. SUB BRIGHT ADJUSTMENT

- 1) Set to service mode.
- 2) Input a staircase signal of black to white from the pattern generator.
- 3) BRIGHTNESS 50%.
PICTURE MINIMUM
- 4) Select SBR (WHB7) with [1] and [4], and adjust SBR (WHB7) level with [3] and [6] so that the second stripe from the right is dimly lit.




SECTION 4

CIRCUIT ADJUSTMENTS

4-1. ADJUSTMENTS WITH COMMANDER

Service adjustments are made with the RM-952 that comes with this unit.

a. ENTERING SERVICE MODE



b. METHOD OF CANCELLATION FROM SERVICE MODE

Set the standby condition (Press **POWER** button on the commander), then press **POWER** button again, hereupon it becomes TV mode.

c. METHOD OF WRITE INTO MEMORY



- 1) Set to Service Mode.
- 2) Press **1** (UP) and **4** (DOWN), select an item of adjustment.
- 3) Press **MUTING** button and it will indicate WRITE on the screen.
- 4) Press **0** button to write into memory.

d. MEMORY WRITE CONFIRMATION METHOD

- 1) After adjustment, pull out the plug from AC outlet, and then plug into AC outlet again.
- 2) Turn the power switch ON and set to Service Mode.
- 3) Call the adjusted items again to confirm adjustments were made.

The screen display is :

Device Name	Item Name	Item No	Data	Marking of virgin NVM	Mode	
GEO		00	HPS	1C	■	SERVICE 50 ← PAL, SECAM : 50
616S		1.0C	59	7F	0	000A NTSC : 60
Suffix No (OEM Code)	Software version				Total Power-On time (hours)	





RM-952

4-2. ADJUSTMENT METHOD


Item Number 00 of device GEO

This explanation uses H-Position as an example.

1. Select "GEO 00 HPS" with the **[1]** and **[4]** buttons.
2. Raise/lower the data with the **[3]** and **[6]** buttons.
3. Select the optimum state. (The standard is 1F for PAL reception.)
4. Write with the **[MUTING]** button. (The display changes to WRITE.)
5. Execute the writing with the **[0]** button. (The WRITE display will be changed to red color while excuting, and back to SERVICE.)



Written with **[MUTING]**



Write executed with **[0]**

Use the same method for all Items. Use **[1]** and **[4]** to select the adjustment item, use **[3]** and **[6]** to adjust, write with **[MUTING]**, then execute the write with **[0]**.

- Note :**
1. In **[WRITE]**, the data for all items are written into memory together.
 2. For adjustment items that have different standard data between 50Hz or 60Hz, be sure to use the respective input signal after adjustment.

Adjustment Item Table

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No	Name							
GEO	0	HPS	7	3F	H Position	50/60HZ	12 (7-2)	CXA2130S(88H)	82 (7-2)
	1	HSZ	1F	3F	H Size	50/60HZ	11 (7-2)		81 (7-2)
	2	PAP	1F	3F	Pin Amp	50/60HZ	13 (7-2)		83 (7-2)
	3	TLT	7	0F	Trapezium	50/60HZ	15 (7-4)		85 (7-4)
	4	VPS	1F	3F	V Position	50/60HZ	0F (7-2)		7F (7-2)
	5	VSZ	1F	3F	V Size	50/60HZ	0E (7-2)		7E (7-2)
	6	SCO	7	0F	S Correction	50/60HZ	10 (7-4)		80 (7-4)
	7	VLN	7	0F	V Linearity	50/60HZ	10 (3-0)		80 (3-0)
	8	BOW	7	0F	AFC Bow	50/60HZ	16 (7-4)		86 (7-4)
	9	AGL	7	0F	AFC-Angle	50/60HZ	16 (3-0)		86 (3-0)
	10	UPN	1F	3F	Upper Pin	50/60HZ	14 (7-2)		84 (7-2)
	11	LPN	1F	3F	Lower Pin	50/60HZ	18 (7-2)		88 (7-2)
	12	HBL	0	1	H Blanking on/off		18 (1)		67 (1)
	13	LBL	7	0F	Left H Blanking	50/60HZ	17 (7-4)		87 (7-4)
	14	RBL	7	0F	Right H Blanking	50/60HZ	17 (3-0)		87 (3-0)
WHB	0	RDR	2A	3F	R Drive	DYNAMIC/others	09 (7-2)	CXA2130S(88H)	8F (7-2)
	1	GDR	2A	3F	G Drive	DYNAMIC/others	0A (7-2)		90 (7-2)
	2	BDR	2A	3F	B Drive	DYNAMIC/others	0B (7-2)		91 (7-2)
	3	RCT	7	0F	R Cutoff	SECAM/others	07 (3-0)		93 (3-0)
	4	GCT	7	0F	G Cutoff	SECAM/others	08 (7-4)		94 (7-4)
	5	BCT	7	0F	B Cutoff	SECAM/others	08 (3-0)		94 (3-0)
	6	BMN	15	1F	Brightness Minimum Data				97
	7	SBR	28	3F	Sub Brightness Control				98
SAJ	0	PMX	33	3F	Picture Maximum Data			CXA2130S(88H)	96
	1	SHU	8	0F	Sub Hue Control	TV/Video			99
	2	SSH	3	0F	Sub Sharpness Control 03/08	TV/Video			9A
	3	SCL	1F	3F	Sub Color Control	NTSC/others			9B
VP	0	EHT	4	0F	EHT Comp	50/60HZ	15 (3-0)	CXA2130S(88H)	85 (3-0)
	1	GMA	2	03	Gamma Correction	Refer NVM Map A4	0B (1-0)		1A3 (1-0)
	2	YDL	6	0F	Y Delay	PAL/SECAM/NTSC	0C (3-0)		8C (3-0)
	3	SST	1	03	SECAM ID Start Position		1B (1-0)		6A (1-0)
	4	SSP	1	03	SECAM ID Stop Position		1B (3-2)		6A (3-2)
	5	SLV	2	03	SECAM ID Level		1C (1-0)		6B (1-0)
	6	SBF	22	3F	SECAM BELL f0		1C (7-2)		6B (7-2)
	7	DYC	0	1	Dynamic Color on/off		0A (1)		59 (1)
	8	ABL	1	1	ABL Mode Switching	STANDARD Always 0	09 (1)		58 (1)
	9	VTH	1	1	ABL Detection Vth Switching		09 (0)		58 (0)
	10	SFO	1	1	FO Switching for Sharpness	NTSC/others	05 (1)		198 (1)
	11	DCX	1	1	DC Trans. Ratio Switching		06 (1)		55 (1)
	12	SHT	1	1	Pre-/Overshoot ratio Switch	NTSC/others	06 (0)		199 (0)

Adjustment Item Table

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)	
	No	Name								
VP	13	HDW	0	1	H Drive Pulse Width Switch	TV/Video/Text	00 (6)		4F (6)	
	14	AFC	1	03	AFC Gain Control		0F (1-0)		8D (1-0)	
	15	HOS	7	0F	H Oscillation		0C (7-4)		5B (7-4)	
	16	HSS	0	1	Slice Level of H Sync Sep.		0D (1)		5C (1)	
	17	VSS	0	1	Slice Level of V Sync Sep.	50/60Hz	0D (0)		5C (0)	
	18	HMS	0	1	Macro Vision C/m off/on		0E (0)		7E (0)	
	19	YUV	0	1	YUV Switch Control		01 (0)		50 (0)	
	20	CDV	1	3	CD mode for Video		0D (5-4)		1A1 (5-4)	
	21	RON	1	1	R ON	Video only not memorized	01 (3)		50 (3)	
	22	GON	1	1	G ON	not memorized	01 (2)		50 (2)	
	23	BON	1	1	B ON	not memorized	01 (1)		50 (1)	
	24	PON	1	1	P ON	not memorized	00 (7)		4F (7)	
	25	BLK	0	1	BLK Off		12 (0)		61 (0)	
	26	VMC	0	1	VM Off		13 (0)		62 (0)	
AP	0	INF	0	3F	Input Attenuation When surround off		00 (5-0)	TDA7429	19F (5-0)	
	1	INS	0	3F	Input Attenuation When surround on		02		1A0 (5-0)	
	2	PH1	0	3	Phase 1 Register Selection				76 (1-0)	
	3	PH2	0	3	Phase 2 Register Selection				76 (3-2)	
	4	PH3	0	3	Phase 3 Register Selection		#4 (3-0)		76 (5-4)	
	5	PH4	0	3	Phase 4 Register Selection				76 (7-6)	
	6	BCS	2	3	Bass Center Shift				#5 (3-0)	1A8 (1-0)
	7	TCS	2	3	Treble Center Shift		#5 (3-0)		1A9 (1-0)	
8	TRF	2	3	RF Treble Offset		#5 (3-0)	1A9 (5-4)			
MSP	0	WST	15	FF	W/G Stereo Threshold			MSP3415D (84H)	157 (7-0)	
	1	WBT	EA	FF	W/G Bilingual Threshold				158 (7-0)	
	2	WLL	5	FF	W/G Monaural Threshold				159 (7-0)	
	3	WAC	0	0F	W/G Agreement Count				15A (3-0)	
	4	WDL	30	FF	W/G Search Delay				15B (7-0)	
	5	NDL	20	FF	NICAM Search Delay				15C (7-0)	
	6	SDL	10	FF	Stereo status Read Delay				15D (7-0)	
	7	AGC	1	1	AGC Switch Auto/Constant		BB (7)		108 (7)	
	8	REL	28	3F	AGC Gain at Constant Mode		BB (6-1)		108 (6-1)	
	9	CRM	0	1	Carrier muting on/off		BB (9)		107 (1)	
	10	ACO	1	1	Audio Clock out on/off		83 (5)		10C (5)	
	11	FP	1B	7F	FM Prescale for non-M system		0E (7-0)		16C (6-0)	
	12	FPM	32	7F	FM Prescale for M system		0E (7-0)		16D (6-0)	
	13	FH	36	7F	FM Prescale for HDEV		0E (7-0)		16E (6-0)	
	14	FHM	65	7F	FM Prescale for HDEV and M		0E (7-0)		16F (6-0)	
	15	WGP	2A	7F	W/G Prescale		0E (7-0)		170 (6-0)	
	16	NIP	6D	7F	NICAM Prescale		10 (7-0)		138 (6-0)	
	17	ERR	50	FF	Auto FM switch Threshold		21 (10-3)		166 (7-0)	
18	VOL	6D	FF	Loud Speaker gain 7000h to 7f0h	0000 (15-4)	1A7 (7-0)				

Adjustment Item Table

Device Name	Functionality		Note	Data Range	Function	Note for Different Data	Register No. (bit)	Slava Address	RAM Address (bit)
	No	Name							
TXT	0	TXH	1	3	Teletext Horizontal Position			(58H)	18D (1-0)
	1	TXV	0	3	Teletext Vertical Position				18D (6-4)
OPM	0	OSH	0A	3F	OSD H Position	Option-Misc			AC (7-2)
	1	COM	0	03	Comb Selection				A5 (7-6)
	2	APC	1	1	APC Switch				A4 (5)
	3	TSY	0	03	TV Sys at Auto TV Sys				A4 (4-3)
	4	MUT	0	1	No Signal Mute				A4 (0)
	5	AFM	1	1	Auto FM switch				A4 (1)
	6	RFB	0	3	C-BPF Control				A5 (5-4)
	7	TV0	0	7	Tilt to V-Angle offset				A5 (2-0)
	8	DBL	0	1	Disable Blueback Function				A4 (2)
OPB	0	OP1	0	FF	Optional Bits 1 (see below)	Option-Bits			45
	1	OP2	0	1	Optional Bits 2 (see below)				46
	2	OP3	0	0	Optional Bits 3 (see below)				47

NOTE

- shaded items are fixed data.
- Standard data listed on the Adjustment Item Table are reference values, therefore it may be different for each model and for each mode.
- Note for Different Data Those are the standard data values written on the microprocessor. Therefore, the data values of the modes and stored respectively in the memory.
In case of a device replacement, adjustment by rewriting the data value is necessary for some items.

ITEM INFORMATION.

No. OPB0 OP1

Item	XTAL 4.43	XTAL 3.58	SECAM	2nd. Lang	B/G	I	D/K	M
KV-PF21P40	1	1	0	1	1	0	0	0
KV-TF21M60	1	1	1	1	1	1	1	1
KV-TF21P50	1	1	0	1	1	0	0	0

No. OPB1 OP2

Item	TOP	NICAM	HDEV	Thai Bil	Dis Fav.	DVD Input	AV Input	
KV-PF21P40	0	0	0	1	1	0	1	0
KV-TF21M60	0	1	1	0	1	0	1	0
KV-TF21P50	0	0	0	1	1	0	1	0


No. OPB2 OP3

Item	Pic Rot	2199 Curve	Auto PIC	Auto TV sys	US ST	AV Mono	11 KEY	Color SW
KV-PF21P40	0	1	1	0	0	1	0	1
KV-TF21M60	0	0	1	1	0	0	0	1
KV-TF21P50	0	0	1	0	0	0	0	1

4-3. PICTURE QUALITY ADJUSTMENTS


SUB COLOR ADJUSTMENT

1. Input a PAL color-bar.
2. Set to the following condition:
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
3. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
4. Set to Service Mode and select SAJ 3 'SCL' with [1] and [4] of the commander then adjust to VB2=VB3=VB4 with [3] and [6].
5. Press [MUTING] → [0] of the commander to write the data.
6. Adjust SAJ 3 'SCL' as step 2 to 5 when receiving NTSC color-bar.



SUB HUE ADJUSTMENT


1. Select Video 1.
2. Input a NTSC color-bar, video into Video 1.
3. Set the following condition:
PICTURE 100%, BRIGHTNESS 50%, COLOR 50%
4. Connect an oscilloscope to pin ① (B OUT) of CN305, A board.
5. Select SAJ 1 'SHU' with [1] and [4] of the commander by setting to Service Mode and adjust to VB1=VB2=VB3=VB4 with [3] and [6].



6. Press [MUTING] → [0] of the commander to write the data.

BELL FILTER ADJUSTMENT

1. Input SECAM color-bar signal.
2. Connect the dual-trace oscilloscope to the pin ⑨ (R-Y) of CN303 (not mounted).
3. Adjust SERVICE MODE, ITEMS 'SBF' as shown below.



4-4. A BOARD ADJUSTMENT AFTER IC003 (MEMORY) REPLACEMENT


When replacing IC003 (MEMORY), be sure to change IC001 (μ-COM) to the following new IC at the same time.
IC001 (μ-CON) : CXP86449-616S

1. Enter to Service Mode.
2. Press commander buttons [5] and [0] (Data Initialize), and [2] and [0] (Data Copy) to initialize the data.
3. Call each item number and check if the respective screen shows the normal picture.
In cases where items are not well adjusted, rectify the items with fine adjustment.
Write the data per each item number ([MUTING] + [0]).
4. Select item numbers "OPB0" (OP1), "OPB1" (OP2) and "OPB2" (OP3) and respectively set the bit per model with command buttons [3] and [6].
5. Press commander buttons [8] and [0] (Test Normal) to return to the data that was set on the shipment from the factory.
(This will also cancel Service Mode.)


4-5. PICTURE DISTORTION ADJUSTMENT

Item Number 00 – 0B


GEO 0 HSH (H POSITION)




GEO 1 HSZ (H SIZE)




GEO 2 PAP (PIN AMP)




GEO 3 TILT (TRAPEZIUM)




GEO 4 VSH (V POSITION)




GEO 5 VSZ (V SIZE)




GEO 6 SCR (VERTICAL S-Correction)




GEO 7 VLN (V LINEARITY)



GEO 8 VBOW (AFC.BOW)




GEO 9 AGL (AFC.ANGLE)




GEO 0A UCP (UPPER CORNER PIN)

GEO 0B LCP (LOWER CORNER PIN)



5-3. CIRCUIT BOARDS LOCATION



5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

Note:

- All capacitors are in μF unless otherwise noted.
- All electrolytic capacitors are rated at 50V unless otherwise noted.
- All resistors are in ohms.
 $\text{k}\Omega = 1000\Omega$, $\text{M}\Omega = 1000\text{k}\Omega$
- Indication of resistance which does not have rating electrical power is as follows.

Pitch: 5 mm

Rating electrical power 1/4W (CHIP: 1/10W)


-  : nonflammable resistor.
-  : internal component.
-  : panel designation or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B unless otherwise noted.
- **Readings are taken with a color-bar signal input.**
no mark : PAL
() : SECAM
[] : NTSC 3.58
« » : NTSC 4.43
- **Readings are taken with a 10 $\text{M}\Omega$ digital multimeter.**
- **Voltage are dc with respect to ground unless otherwise noted.**
- **Voltage variations may be noted due to normal production tolerances.**
- **All voltages are in V.**
- * : Cannot be measured.
- **Circled numbers are waveform references.**
-  : B + bus.
-  : B – bus.
-  : signal path.

Reference information


RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
COIL	: ✕	ADJUSTMENT RESISTOR
	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE

Note: The component identified by shading and mark  are critical for safety. Replace only with part number specified.


A BOARD IC001 CXP86449-616S



(1) Schematic Diagram of A(1/2) board



(2) Schematic Diagram of A(2/2) board





A BOARD * MARK LIST

	KV-TF21M60	KV-TF21P50	KV-PF21P40
C202	3900p :CHIP	3900p :CHIP	1000p
C203	3900p :CHIP	3900p :CHIP	#
C204	0.01 :PP	0.01 :PP	0.0068
C205	1500p :CHIP	1500p :CHIP	#
C206	1500p :CHIP	1500p :CHIP	3900p :CHIP
C207	0.01 :PP	0.01 :PP	#
C208	10	10	#
C213	100 16V	100 16V	#
C214	100	1000	#
C217	10	10	#
C219	0.15 :MPS	0.15 :MPS	#
C225	1 :CHIP	1 :CHIP	#
C247	1 16V :CHIP	1 16V :CHIP	#
C250	0 :CHIP	0 :CHIP	#
C264	2.2 16V :CHIP	2.2 16V :CHIP	#
C401	1 16V :CHIP	1 16V :CHIP	#
C403	470P :CHIP	470P :CHIP	#
C406	1 16V :CHIP	1 16V :CHIP	#
C415	470P :CHIP	470P :CHIP	#
C902	0.01 :PP	0.01 :PP	#
C908	470P :CHIP	470P :CHIP	#
C909	1 16V :CHIP	1 16V :CHIP	#
CN901	4P	4P	3P
D100	MA111-TX	#	#
D401	UDZS-TE17-9.1B	UDZS-TE17-9.1B	#
D404	UDZS-TE17-9.1B	UDZS-TE17-9.1B	#
D903	UDZS-TE17-9.1B	UDZS-TE17-9.1B	#
IC100	S-80743AL-A7-77	#	#
J401	6P	6P	4P
J902	3P	3P	2P
JR107	0 :CHIP	#	#
JR401	0 :CHIP	0 :CHIP	#
JR403	0 :CHIP	0 :CHIP	#
JW159	3.9 :RS	JW (15.0 mm)	JW (15.0 mm)
JW203	JW (5.0 mm)	JW (5.0 mm)	#
L902	10UH	10UH	#
Q202	UN2216	UN2216	#
Q402	UN2216	UN2216	#
Q403	2SA1037AK	2SA1037AK	#
R101	100 :CHIP	100 :CHIP	#
R102	100 :CHIP	100 :CHIP	#
R202	15K :CHIP	15K :CHIP	8.2K :CHIP
R203	10K :CHIP	10K :CHIP	15K :CHIP
R204	15K :CHIP	15K :CHIP	8.2K :CHIP
R205	15K :CHIP	15K :CHIP	#
R206	10K :CHIP	10K :CHIP	#
R207	15K :CHIP	15K :CHIP	#
R208	15K :CHIP	15K :CHIP	1.0K :CHIP
R209	15K :CHIP	15K :CHIP	#
R211	220 :CHIP	220 :CHIP	15K :CHIP
R222	0 :CHIP	0 :CHIP	#
R228	4.7	4.7	#
R301	8.2K :CHIP	8.2K :CHIP	8.2K :CHIP
R401	1.0K :CHIP	1.0K :CHIP	#
R402	10K :CHIP	1.0K :CHIP	#
R403	10K :CHIP	1.0K :CHIP	#
R407	1.0K :CHIP	1.0K :CHIP	#
R409	470K :CHIP	470K :CHIP	#
R410	470K :CHIP	470K :CHIP	#
R415	470K :CHIP	470K :CHIP	#
R416	15K :CHIP	15K :CHIP	#
R622	5.6 :RS	33 :RS	33 :RS
R902	330	330	#
R907	470K :CHIP	470K :CHIP	#
R908	15K :CHIP	15K :CHIP	#
TU101	FSS BTF-WG441	FSS BTF-LG413	FSS BTF-LG413

Note) The parts indicated as “#” in this circuit diagram are not listed here, as they are not used in this models.

A BOARD WAVEFORMS





NOTE:
The circuit indicated at left contains high voltage of over 600 Vp-p. Please pay attention when inspecting or repairing it to prevent an electric shock.


A BOARD

IC		D002	B-7	D617	E-7
IC001	B-9	D003	C-7	D618	E-8
IC002	C-8	D004	D-7	D620	D-7
IC003	A-8	D005	B-7	D621	E-7
IC100	B-4	D006	A-3	D622	E-6
IC201	B-10	D203	C-10	D623	E-10
IC203	B-3	D300	A-7	D624	E-10
IC204	B-2	D301	A-7	D625	C-10
IC301	B-6	D302	B-5	D627	E-7
IC502	E-6	D303	A-4	D628	F-5
IC503	H-4	D304	A-4	D629	E-8
IC601	H-7	D305	A-4	D630	D-8
IC602	G-6	D306	B-4	D631	F-10
IC603	D-7	D307	B-4	D632	E-10
IC604	D-8	D308	B-4	D633	D-10
IC901	H-12	D309	B-5	D634	E-10
PH600	G-6	D310	A-5	D635	E-10
TRANSISTOR		D311	C-5	D636	D-10
Q001	B-7	D312	C-6	D637	E-10
Q002	B-7	D313	A-7	D638	D-10
Q003	B-8	D314	A-7	D901	B-11
Q004	B-8	D315	B-6	D902	C-11
Q101	A-3	D316	B-6	D903	B-11
Q201	A-10	D317	A-7	D904	C-11
Q202	A-9	D401	C-2	D905	E-12
Q203	B-9	D402	C-2	D906	G-11
Q204	B-10	D403	B-1		
Q205	A-10	D404	C-1		
Q206	A-9	D405	C-2		
Q207	A-10	D406	B-1		
Q301	A-7	D407	C-1		
Q302	A-5	D408	B-1		
Q303	A-6	D409	A-1		
Q304	A-5	D504	C-5		
Q305	A-5	D505	G-5		
Q306	B-5	D506	E-5		
Q307	C-6	D507	E-5		
Q308	C-6	D508	G-5		
Q309	C-6	D509	E-5		
Q310	C-6	D510	E-4		
Q311	D-7	D511	F-4		
Q312	B-6	D512	F-4		
Q313	B-7	D513	H-4		
Q315	B-5	D517	E-2		
Q401	C-1	D518	E-2		
Q402	C-1	D519	E-2		
Q403	C-2	D520	E-4		
Q404	C-3	D521	H-3		
Q501	D-5	D522	I-4		
Q502	D-6	D525	E-5		
Q503	E-6	D526	F-5		
Q505	D-5	D527	E-3		
Q506	D-2	D528	E-3		
Q507	G-5	D529	E-4		
Q509	E-5	D530	E-1		
Q511	E-1	D531	E-5		
Q512	E-4	D532	D-5		
Q600	C-10	D600	F-11		
Q601	E-9	D601	H-7		
Q602	H-6	D602	F-11		
Q603	H-6	D603	E-9		
Q604	G-5	D604	H-6		
Q605	E-10	D605	F-9		
Q606	E-10	D606	E-9		
Q607	G-11	D607	E-9		
Q608	D-11	D608	E-9		
Q901	G-11	D609	G-7		
Q902	G-12	D610	H-7		
DIODE		D611	G-6		
D001	B-7	D612	E-7		
		D613	G-6		
		D614	G-6		
		D615	E-6		
		D616	D-8		


A [MAIN TUNER, VIF, SIF, AV SW Y/C DECODE JUNGLE,]
[POWER SUPPLY, DEFLECTION]

PRINTED WIRING BOARD


- A Board -



(3) Schematic Diagram of C3 board




C3 BOARD WAVEFORMS




C3 [RGB OUT]

PRINTED WIRING BOARD

- C3 Board -




(4) Schematic Diagram of F board



PRINTED WIRING BOARD

F [CISPR]


– F Board –




5-5. SEMICONDUCTORS

DIODE


AU-01Z-V1
EL1Z
GP08D




D4SB60L




ERC04-06SE
RN4Z
31DQ06-FC5




ERA22-08
ERD29-08J




1SS355TE-17




ON3171-R




D1NS4
RD30ESB2
RD6.8ES-B1
RD9.1ES-L2
1SS119-25
11EQS04
11ES2-NTA2B




DTZ-TT11-15B
DTZ10B
MA111-(K8). S0
UDZS-TE17-5.1B
UDZS-TE17-6.8B
UDZS-TE17-9.1B



DA204K




FMU-G26S




LED

SPB-26MVWF




TRANSISTOR


UN2111
UN2211
UN2213
UN2216
2SCA1037AK-T146-R
2SC1623-L5L6




2SC2785-HFE




2SA1091-0




2SD2144S-UVW



2SC2611
2SC2688-LK




IRF614



2SK2845-LB102




2SD2578-CA




IC

CXA2139S (48PIN)
CXP86449-616S (64PIN)
M24C08-BN6 (8PIN)
RS3FS (30PIN)
TDA7429S (42PIN)




Dual In-line Package
Pin 6~98

MM1319AFBE (7PIN)
NJM2903M (8PIN)




Single In-line Package
Pin 6~98


NJM78M09FA
TA7805S




SBX1981-51P



SE-135N




TDA8172



STR-F6654


MARKING SIDE VIEW




Zig-zag In-line Package
Pin 6~99

RU-1P

MARKING SIDE VIEW



TA8248K



SECTION 3
EXPLODED VIEWS

NOTE:


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark Δ are critical for safety.
Replace only with part number specified.

6-1. CHASSIS

●: BVTP 3 x 12 7-685-648-79

■: BVTP 4 x 16 7-685-663-71



REF. NO.	PART NO.	DESCRIPTION	REMARK
1	X-4037-082-1	BEZNET ASSY (KV-TF21P50)	
	X-4037-084-1	BEZNET ASSY (KV-PF21P40)	
	X-4037-263-1	BEZNET ASSY (KV-TF21M60)	
2	4-070-291-0	BUTTON, POWER	
3	4-070-290-0	BUTTON, MULTI	
4	1-505-740-1	SPEAKER (5X9CM)	
5	4-054-981-0	SCREW, STEPPING	
6	4-365-808-4	SCREW (5), TAPPING	
7	4-064-818-0	SPACER, DY	
8	* 3-704-372-1	HOLDER, HV CABLE	
9	Δ 8-738-812-0	PICTURE TUBE (A51LP170X)	
10	8-451-505-1	DEFLECTION YOKE (Y21RSA-S)	
11	* A-1331-900-A	C3 BOARD MOUNTED	
12	4-369-318-4	SPRING, TENSION	
13	Δ 1-416-946-1	COIL, DEMAGNETIC	
14	4-067-189-0	PWB(L), GUIDE	
15	4-067-187-0	PWB(R), GUIDE	
	8-598-448-1	TUNER, FSS FIT-LG413 (except KV-TF21M60)	
	8-598-451-2	TUNER, FSS FIT-WG441 (KV-TF21M60)	
17	Δ 1-453-293-1	TRANSFORMER ASSY, FLYBACK (NX-1748/M3A4)	
18	* A-1299-071-A	A BOARD COMPLETE (KV-TF21M60)	
	* A-1299-078-A	A BOARD COMPLETE (KV-TF21P50)	
	* A-1299-079-A	A BOARD COMPLETE (KV-PF21P40)	
19	4-057-714-0	PIECE ASSY, TLH CORRECTION	
20	4-022-115-2	HOLDER, AC CORD	
21	Δ 1-575-023-1	CORD, POWER (WITH CONNECTOR) 6A/250V	
22	1-452-032-0	MAGNET, DISC	
23	4-051-736-4	PIECE A(90), CONV. CORRECT	
24	4-067-877-1	BRACKET, TERMINAL (KV-TF21M60/TF21P50)	
	4-067-877-2	BRACKET, TERMINAL (KV-PF21P40)	
25	4-074-017-1	BLOTTING SHEET	
26	* A-1241-360-A	F BOARD MOUNTED	
27	X-4037-264-1	DOOR ASSY, CONTROL (KV-TF21M60)	
	X-4037-121-1	DOOR ASSY, CONTROL (KV-TF21P50)	
	X-4037-122-1	DOOR ASSY, CONTROL (KV-PF21P40)	
28	4-070-300-0	COVER, REAR	
29	Δ 4-064-883-1	HOLDER, DOOR	
30	* 4-379-189-1	CUSHION, SPEAKER	
31	4-069-652-1	CUSHION (H: BAND)	
32	* 4-070-292-0	BAR, OPTICAL	
33	4-067-182-0	HOLDER, FB	

ELECTRICAL PARTS LIST

A

NOTE:

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All resistors are in ohms
- F : nonflammable
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

CAPACITORS

- MF : μ F, PF : μ F

COILS

- MMH : mH, UH : μ H

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	A-1294-841-A	A BOARD COMPLETE *****		C108	1-104-664-11	ELECT 47MF 20%	16V
				C109	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
* A-1299-071-A	COMPLETE PWB, A			C110	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
* 4-055-304-11	HOLDER, LED			C111	1-163-005-11	CERAMIC CHIP 470PF 10%	50V
4-382-854-11	SCREW (M3X10), P, SW (+)			C112	1-104-664-11	ELECT 47MF 20%	16V
4-382-854-21	SCREW (M3X14), P, SW (+)			C113	1-104-664-11	ELECT 47MF 20%	25V
				C114	1-126-967-11	ELECT 47MF 20%	50V
		<CAPACITOR>		C202	1-163-016-00	CERAMIC CHIP 0.0039MF 10%	50V
C003	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C202	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V
C004	1-163-001-11	CERAMIC CHIP 220PF 10%	50V			(KV-PF21P40)	
C005	1-163-001-11	CERAMIC CHIP 220PF 10%	50V	C203	1-163-016-00	CERAMIC CHIP 0.0039MF 10%	50V
C006	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V			(except KV-PF21P40)	
C007	1-104-664-11	ELECT 47MF 20%	16V	C204	1-136-153-00	MYLAR 0.01MF 5%	50V
						(except KV-PF21P40)	
C008	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C204	1-130-481-00	MYLAR 0.0068MF 5%	50V
C010	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(KV-PF21P40)	
C012	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C205	1-163-011-11	CERAMIC CHIP 0.0015MF 10%	50V
C013	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V			(except KV-PF21P40)	
C014	1-104-664-11	ELECT 47MF 20%	25V	C206	1-163-011-11	CERAMIC CHIP 0.0015MF 10%	50V
						(except KV-PF21P40)	
C015	1-163-009-11	CERAMIC CHIP 0.001MF 10%	50V	C206	1-164-182-11	CERAMIC CHIP 0.0033MF 10%	50V
C016	1-163-113-00	CERAMIC CHIP 68PF 5%	50V			(KV-PF21P40)	
C017	1-163-113-00	CERAMIC CHIP 68PF 5%	50V	C207	1-136-153-00	MYLAR 0.01MF 5%	50V
C019	1-104-664-11	ELECT 47MF 20%	25V			(except KV-PF21P40)	
C022	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C208	1-126-964-11	ELECT 10MF 20%	50V
						(except KV-PF21P40)	
C023	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C209	1-126-964-11	ELECT 10MF 20%	50V
C024	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V	C210	1-126-933-11	ELECT 100MF 20%	16V
C026	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C211	1-126-941-11	ELECT 470MF 20%	25V
C027	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C212	1-126-933-11	ELECT 100MF 20%	16V
C028	1-163-037-11	CERAMIC CHIP 0.022MF 10%	50V	C213	1-126-933-11	ELECT 100MF 20%	16V
						(except KV-PF21P40)	
C030	1-126-965-11	ELECT 22MF 20%	50V	C214	1-126-942-61	ELECT 1000MF 20%	25V
C031	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V			(except KV-PF21P40)	
C032	1-107-823-11	CERAMIC CHIP 0.47MF 10%	16V	C215	1-126-942-61	ELECT 1000MF 20%	25V
C034	1-163-031-11	CERAMIC CHIP 0.01MF 5%	50V	C216	1-163-021-91	CERAMIC CHIP 0.01MF 10%	50V
C041	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C217	1-126-964-11	ELECT 10MF 20%	50V
						(except KV-PF21P40)	
C042	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C218	1-136-167-00	MYLAR 0.15MF 5%	50V
C043	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(except KV-PF21P40)	
C044	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C219	1-136-167-00	MYLAR 0.15MF 5%	50V
C047	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(except KV-PF21P40)	
C048	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C220	1-126-942-61	ELECT 1000MF 20%	25V
				C221	1-126-964-11	ELECT 10MF 20%	50V
C050	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C223	1-126-965-11	ELECT 22MF 20%	50V
C051	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C224	1-163-133-00	CERAMIC CHIP 470PF 5%	50V
C053	1-163-251-11	CERAMIC CHIP 100PF 5%	50V				
C054	1-163-251-11	CERAMIC CHIP 100PF 5%	50V	C225	1-109-982-11	CERAMIC CHIP 1MF 10%	10V
C055	1-163-251-11	CERAMIC CHIP 100PF 5%	50V			(except KV-PF21P40)	
				C226	1-109-982-11	CERAMIC CHIP 1MF 10%	10V
C103	1-164-004-11	CERAMIC CHIP 0.1MF 10%	25V	C227	1-163-037-11	CERAMIC CHIP 0.022MF 10%	50V
C104	1-104-665-11	ELECT 100MF 20%	10V				
C107	1-163-005-11	CERAMIC CHIP 470PF 10%	50V				

A

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
C228	1-163-024-00	CERAMIC CHIP	0.018MF 10% 50V	C330	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C229	1-163-018-00	CERAMIC CHIP	0.0056MF 10% 50V	C332	1-126-963-11	ELECT	4.7MF 20% 50V
C230	1-163-024-00	CERAMIC CHIP	0.018MF 10% 50V	C335	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C231	1-163-018-00	CERAMIC CHIP	0.0056MF 10% 50V	C336	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C232	1-163-037-11	CERAMIC CHIP	0.022MF 10% 50V	C337	1-126-961-11	ELECT	2.2MF 20% 50V
C233	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C338	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V
C234	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C341	1-115-340-11	CERAMIC CHIP	0.22MF 10% 25V
C235	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C342	1-163-259-91	CERAMIC CHIP	220PF 5% 50V
C236	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C401	1-164-346-11	CERAMIC CHIP 1MF (except KV-PF21P40)	16V
C238	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C402	1-164-346-11	CERAMIC CHIP 1MF	16V
C240	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C403	1-163-005-11	CERAMIC CHIP 470PF (except KV-PF21P40)	10% 50V
C241	1-164-346-11	CERAMIC CHIP	1MF 16V	C404	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C242	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C405	1-126-935-11	ELECT	470MF 20% 16V
C243	1-216-295-91	SHORT	0	C406	1-164-346-11	CERAMIC CHIP 1MF (except KV-PF21P40)	16V
C244	1-164-700-11	CERAMIC CHIP	0.68MF 16V	C407	1-164-346-11	CERAMIC CHIP 1MF	16V
C245	1-164-346-11	CERAMIC CHIP	1MF 16V	C408	1-163-133-00	CERAMIC CHIP 470PF	5% 50V
C246	1-163-018-00	CERAMIC CHIP	0.0056MF 10% 50V	C409	1-126-963-11	ELECT	4.7MF 20% 50V
C247	1-164-346-11	CERAMIC CHIP 1MF (except KV-PF21P40)	16V	C415	1-163-133-00	CERAMIC CHIP 470PF (except KV-PF21P40)	5% 50V
C248	1-163-010-11	CERAMIC CHIP	0.0012MF 10% 50V	C502	1-163-145-00	CERAMIC CHIP	0.0015MF 5% 50V
C249	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C506	1-107-638-11	ELECT	33MF 20% 160V
C250	1-216-295-91	SHORT	0	C507	1-161-830-00	CERAMIC	0.0047MF 500V
C251	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V (except KV-PF21P40)	C510	1-102-112-00	CERAMIC	330PF 10% 50V
C252	1-164-346-11	CERAMIC CHIP	1MF 16V	C512	1-163-989-11	CERAMIC CHIP	0.033MF 10% 25V
C253	1-163-037-11	CERAMIC CHIP	0.022MF 10% 50V	C513	1-163-263-11	CERAMIC CHIP	330PF 5% 50V
C254	1-126-965-11	ELECT	22MF 20% 50V	C514	1-106-383-00	MYLAR	0.047MF 10% 200V
C255	1-163-037-11	CERAMIC CHIP	0.022MF 10% 50V	C517	1-164-182-11	CERAMIC CHIP	0.0033MF 10% 50V
C256	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C518	1-104-665-11	ELECT	100MF 20% 10V
C259	1-126-933-11	ELECT	100MF 20% 16V	C519	1-102-212-00	CERAMIC	820PF 10% 500V
C264	1-164-505-11	CERAMIC CHIP 2.2MF (except KV-PF21P40)	16V	C521	1-126-934-11	ELECT	220MF 20% 16V
C265	1-164-505-11	CERAMIC CHIP	2.2MF 16V	C522	1-126-933-11	ELECT	100MF 20% 16V
C301	1-126-935-11	ELECT	470MF 20% 16V	C523	1-102-002-00	CERAMIC	680PF 10% 500V
C302	1-163-005-11	CERAMIC CHIP	470PF 10% 50V	C524	1-126-967-11	ELECT	47MF 20% 50V
C303	1-126-964-11	ELECT	10MF 20% 50V	C526	1-130-495-00	MYLAR	0.1MF 5% 50V
C304	1-126-967-11	ELECT	47MF 20% 50V	C527	1-102-820-00	CERAMIC	330PF 5% 50V
C305	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C528	1-162-134-11	CERAMIC	470PF 10% 2KV
C306	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	C530	1-137-372-11	MYLAR	0.022MF 5% 50V
C307	1-163-233-11	CERAMIC CHIP	18PF 5% 50V	C531	1-126-961-11	ELECT	2.2MF 20% 50V
C308	1-163-259-91	CERAMIC CHIP	220PF 5% 50V	C532	1-126-941-11	ELECT	470MF 20% 25V
C309	1-126-957-11	ELECT	0.22MF 20% 50V	C533	1-126-941-11	ELECT	470MF 20% 25V
C310	1-126-963-11	ELECT	4.7MF 20% 50V	C536	1-136-165-00	MYLAR	0.1MF 5% 50V
C311	1-126-964-11	ELECT	10MF 20% 50V	C537	1-126-969-11	ELECT	220MF 20% 50V
C312	1-164-346-11	CERAMIC CHIP	1MF 16V	C538	1-136-076-00	FILM	0.0085MF 3% 2KV
C313	1-164-346-11	CERAMIC CHIP	1MF 16V	C539	1-129-746-91	FILM	0.039MF 5% 400V
C315	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C540	1-136-171-00	MYLAR	0.33MF 5% 50V
C316	1-104-664-11	ELECT	47MF 20% 25V	C546	1-165-319-11	CERAMIC CHIP	0.1MF 50V
C317	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V	C549	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V
C318	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C550	1-106-220-00	MYLAR	0.1MF 10% 100V
C319	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C551	1-126-960-11	ELECT	1MF 20% 50V
C320	1-163-031-11	CERAMIC CHIP	0.01MF 50V	C552	1-162-116-00	CERAMIC	680PF 10% 2KV
C322	1-163-005-11	CERAMIC CHIP	470PF 10% 50V	C553	1-162-116-00	CERAMIC	680PF 10% 2KV
C324	1-163-017-00	CERAMIC CHIP	0.0047MF 10% 50V	C554	1-137-417-11	MYLAR	0.0047MF 10% 200V
C325	1-126-960-11	ELECT	1MF 20% 50V	C556	1-126-941-11	ELECT	470MF 20% 25V
C327	1-126-965-11	ELECT	22MF 20% 50V	C557	1-126-941-11	ELECT	470MF 20% 25V
C328	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V				

A

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK
C558	1-123-024-21	ELECT	33MF 160V
C560	1-102-228-00	CERAMIC	470PF 10% 500V
C561	1-129-708-91	FILM	0.0033MF 5% 630V
C562	1-102-228-00	CERAMIC	470PF 10% 500V
C564	1-163-038-91	CERAMIC CHIP	0.1MF 25V
C565	1-107-655-11	ELECT	47MF 20% 250V
C566	1-102-244-00	CERAMIC	220PF 10% 500V
C567	1-115-521-11	FILM	0.82MF 5% 250V
C568	1-102-228-00	CERAMIC	470PF 10% 500V
C570	1-115-520-11	FILM	0.68MF 5% 250V
C573	1-106-379-12	MYLAR	0.033MF 10% 200V
C574	1-107-636-11	ELECT	10MF 20% 160V
C576	1-130-495-00	MYLAR	0.1MF 5% 50V
C577	1-106-395-00	MYLAR	0.15MF 10% 200V
C582	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C586	1-216-295-91	SHORT	0
C600 Δ	1-104-705-11	MYLAR	0.1MF 20% 250V
C602 Δ	1-104-705-11	MYLAR	0.1MF 20% 250V
C604	1-163-009-11	CERAMIC CHIP	0.001MF 10% 50V
C605 Δ	1-127-942-51	CERAMIC	330PF 10% 250V
C606 Δ	1-127-942-51	CERAMIC	330PF 10% 250V
C607	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C608	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C611	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C612	1-161-830-00	CERAMIC	0.0047MF 99% 500V
C613	1-117-802-11	ELECT	180MF 20% 450V
C616	1-130-202-00	FILM	0.022MF 10% 400V
C617	1-107-792-11	CERAMIC	100PF 5% 1KV
C618	1-125-893-11	FILM	680PF 3% 1.5KV
C619 Δ	1-119-886-51	CERAMIC	470PF 10% 250V
C620	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C621	1-102-114-00	CERAMIC	470PF 10% 50V
C622	1-102-119-00	CERAMIC	0.0015MF 10% 50V
C623	1-104-665-11	ELECT	100MF 20% 25V
C624	1-125-772-91	CERAMIC	1500PF 10% 2KV
C627	1-102-002-00	CERAMIC	680PF 10% 500V
C628	1-126-942-61	ELECT	1000MF 20% 25V
C629	1-126-964-11	ELECT	10MF 20% 50V
C630	1-123-024-21	ELECT	33MF 160V
C633	1-104-999-11	MYLAR	0.1MF 10% 200V
C634	1-126-933-11	ELECT	100MF 20% 16V
C635	1-104-665-11	ELECT	100MF 20% 10V
C636	1-104-760-11	CERAMIC CHIP	0.047MF 10% 50V
C639	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C640	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C641	1-102-002-00	CERAMIC	680PF 10% 500V
C642	1-126-943-11	ELECT	2200MF 20% 25V
C643	1-104-665-11	ELECT	100MF 20% 10V
C644	1-104-331-11	CERAMIC	0.0022MF 10% 1KV
C645	1-137-605-11	MYLAR	0.01MF 10% 250V
C646	1-107-679-41	ELECT	10MF 20% 450V
C647	1-163-275-11	CERAMIC CHIP	0.001MF 5% 50V
C649	1-126-940-11	ELECT	330MF 20% 25V
C650	1-163-275-11	CERAMIC CHIP	0.001MF 5% 50V
C651	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C652	1-126-965-11	ELECT	22MF 20% 50V
C653	1-104-664-11	ELECT	47MF 20% 25V
C657	1-101-821-00	CERAMIC	0.0022MF 500V

REF. NO.	PART NO.	DESCRIPTION	REMARK
C658	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C901	1-136-153-00	MYLAR	0.01MF 5% 50V
C902	1-136-153-00	MYLAR	0.01MF 5% 50V (except KV-PF21P40)
C905	1-126-963-11	ELECT	47MF 20% 50V
C906	1-164-346-11	CERAMIC CHIP	1MF 16V
C907	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
C908	1-163-133-00	CERAMIC CHIP	470PF 5% 50V (except KV-PF21P40)
C909	1-164-346-11	CERAMIC CHIP	1MF 16V (except KV-PF21P40)
C910	1-126-967-11	ELECT	47MF 20% 50V
C911	1-126-967-11	ELECT	47MF 20% 50V
C912	1-164-004-11	CERAMIC CHIP	0.1MF 10% 25V
C913	1-104-665-11	ELECT	100MF 20% 10V
C914	1-163-133-00	CERAMIC CHIP	470PF 5% 50V
<CONNECTOR>			
CN104	1-695-915-11	TAB (CONTACT)	
CN202 *	1-785-608-11	PIN, CONNECTOR 4P	
CN203 *	1-564-506-11	PLUG, CONNECTOR 3P	
CN204 *	1-564-506-11	PLUG, CONNECTOR 3P	
CN305 *	1-564-509-11	PLUG, CONNECTOR 6P	
CN505	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P	
CN506	4-352-844-01	PIN, LEAD, COATING	
CN601 *	1-580-843-11	PIN, CONNECTOR (POWER)	
CN604 *	1-573-963-11	PIN, CONNECTOR (PC BOARD) 3P	
CN901 *	1-564-507-11	PLUG, CONNECTOR 4P (except KV-PF21P40)	
CN901 *	1-564-506-11	PLUG, CONNECTOR 3P (KV-PF21P40)	
<DIODE>			
D001	8-719-988-61	DIODE 1SS355TE-17 (KV-TF21M60)	
D005	8-719-988-61	DIODE 1SS355TE-17	
D006	8-719-988-61	DIODE 1SS355TE-17	
D100	8-719-073-01	DIODE MA111-(K8),S0	
D203	8-719-914-42	DIODE DA204K	
D300	1-216-295-91	SHORT	0
D301	8-719-988-61	DIODE 1SS355TE-17	
D306	8-719-988-61	DIODE 1SS355TE-17	
D307	8-719-988-61	DIODE 1SS355TE-17	
D308	8-719-988-61	DIODE 1SS355TE-17	
D309	8-719-069-54	DIODE UDZS-TE17-5.1B	
D311	8-719-988-61	DIODE 1SS355TE-17	
D312	8-719-988-61	DIODE 1SS355TE-17	
D313	8-719-988-61	DIODE 1SS355TE-17	
D314	8-719-988-61	DIODE 1SS355TE-17	
D315	8-719-988-61	DIODE 1SS355TE-17	
D316	8-719-069-57	DIODE UDZS-TE17-6.8B	
D320	8-719-069-60	DIODE UDZS-TE17-9.1B	
D321	8-719-069-60	DIODE UDZS-TE17-9.1B	
D401	8-719-069-60	DIODE UDZS-TE17-9.1B (except KV-PF21P40)	
D402	8-719-069-60	DIODE UDZS-TE17-9.1B	
D403	8-719-069-60	DIODE UDZS-TE17-9.1B	
D404	8-719-069-60	DIODE UDZS-TE17-9.1B (except KV-PF21P40)	
D405	8-719-069-60	DIODE UDZS-TE17-9.1B	
D406	8-719-069-60	DIODE UDZS-TE17-9.1B	

A

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
D504	8-719-302-43	DIODE EL1Z		FB600	1-410-397-21	FERRITE	1.1UH
D505	8-719-988-61	DIODE 1SS355TE-17		FB601	1-410-397-21	FERRITE	1.1UH
D506	8-719-911-19	DIODE 1SS119-25		FB602	1-410-397-21	FERRITE	1.1UH
D507	8-719-988-61	DIODE 1SS355TE-17					
D508	8-719-988-61	DIODE 1SS355TE-17		FB603	1-410-397-21	FERRITE	1.1UH
				FB604	1-412-911-31	FERRITE	0UH
D509	1-216-073-00	RES,CHIP 10K	5% 1/10W	FB607	1-410-397-21	FERRITE	1.1UH
D510	8-719-988-61	DIODE 1SS355TE-17		FB608	1-412-911-31	FERRITE	0UH
D511	8-719-988-61	DIODE 1SS355TE-17		FB611	1-410-397-21	FERRITE	1.1UH
D512	8-719-988-61	DIODE 1SS355TE-17					
D513	8-719-908-03	DIODE GP08D		FB613	1-410-397-21	FERRITE	1.1UH
				FB615	1-410-397-21	FERRITE	1.1UH
D517	8-719-312-71	DIODE RS3FS					
D518	8-719-900-26	DIODE ERD29-08J					
D521	8-719-302-43	DIODE EL1Z				<IC>	
D522	8-719-302-43	DIODE EL1Z					
D523	8-719-302-43	DIODE EL1Z		IC001	8-752-905-22	IC CXP86449-616S	
				IC002	8-759-371-21	IC MM1319AFBE	
D527	8-719-908-03	DIODE GP08D		IC003	8-759-527-71	IC M24C08-BN6	
D528	8-719-908-03	DIODE GP08D		IC100	8-759-042-02	IC S-80743AL-A7-S (KV-TF21M60)	
D531	8-719-988-61	DIODE 1SS355TE-17		IC201	8-759-339-60	IC TA8248K	
D532	8-719-988-61	DIODE 1SS355TE-17					
D534	1-216-295-91	SHORT 0		IC203	8-759-553-40	IC TDA7429S	
				IC301	8-752-090-41	IC CXA2139S	
D602	8-719-911-19	DIODE 1SS119-25		IC502	8-759-700-07	IC NJM2903M	
D605	8-719-510-53	DIODE D4SB60L		IC503	8-759-980-58	IC TDA8172	
D609	8-719-311-31	DIODE RU-1P		IC601	8-749-013-75	IC STR-F6654	
D610	8-719-210-21	DIODE 11EQS04					
D611	8-719-046-74	DIODE AU-01Z-V1		IC602	8-749-920-61	IC SE-135N	
				IC603	8-759-701-59	IC NJM78M09FA	
D613	8-719-046-74	DIODE AU-01Z-V1		IC604	8-759-231-53	IC TA7805S	
D614	8-719-046-74	DIODE AU-01Z-V1		IC901	8-742-014-11	HYB IC SBX1981-51	
D618	8-719-067-18	DIODE RN4Z					
D620	8-719-110-72	DIODE RD30ESB2				<JACK>	
D622	8-719-071-39	DIODE FMU-G26S					
				J401	1-779-849-11	JACK BLOCK, PIN 4P (KV-PF21P40)	
D623	8-719-978-65	DIODE DTZ-TT11-15B		J401	1-779-850-11	JACK BLOCK, PIN 6P (except KV-PF21P40)	
D624	8-719-073-01	DIODE MA111-(K8).S0		J901	1-770-786-11	JACK	
D625	8-719-977-28	DIODE DTZ10B		J902	1-779-205-11	JACK, PIN 2P (KV-PF21P40)	
D627	8-719-073-84	DIODE 31DQ06-FC5		J902	1-770-329-11	JACK, PIN 3P (except KV-PF21P40)	
D628	8-719-911-19	DIODE 1SS119-25					
D631	8-719-068-00	DIODE ERC04-06SE				<CHIP CONDUCTOR>	
D632	8-719-068-00	DIODE ERC04-06SE		JR001	1-216-295-91	SHORT	0
D633	8-719-948-45	DIODE ERA22-08		JR002	1-216-295-91	SHORT	0
D634	8-719-073-01	DIODE MA111-(K8).S0		JR003	1-216-295-91	SHORT	0
D635	8-719-073-01	DIODE MA111-(K8).S0		JR004	1-216-295-91	SHORT	0
				JR005	1-216-295-91	SHORT	0
D636	8-719-510-02	DIODE D1NS4					
D637	8-719-109-96	DIODE RD6.8ESB1		JR006	1-216-295-91	SHORT	0
D638	8-719-024-99	DIODE 11ES2-NTA2B		JR007	1-216-295-91	SHORT	0
D901	8-719-069-60	DIODE UDZS-TE17-9.1B		JR008	1-216-295-91	SHORT	0
D902	8-719-069-60	DIODE UDZS-TE17-9.1B		JR009	1-216-295-91	SHORT	0
				JR010	1-216-295-91	SHORT	0
D903	8-719-069-60	DIODE UDZS-TE17-9.1B (except KV-PF21P40)					
D904	8-719-069-60	DIODE UDZS-TE17-9.1B		JR011	1-216-295-91	SHORT	0
D905	8-719-069-60	DIODE UDZS-TE17-9.1B		JR012	1-216-295-91	SHORT	0
D906	8-719-045-19	DIODE SPB-26MVWF		JR013	1-216-295-91	SHORT	0
				JR014	1-216-295-91	SHORT	0
				JR015	1-216-295-91	SHORT	0
		<CONNECTOR>					
DY1	* 1-580-798-11	CONNECTOR PIN (DY) 6P		JR016	1-216-295-91	SHORT	0
				JR018	1-216-295-91	SHORT	0
		<FERRITE BEAD>		JR019	1-216-295-91	SHORT	0
				JR102	1-216-295-91	SHORT	0
FB501	1-410-397-21	FERRITE	1.1UH	JR107	1-216-295-91	SHORT	0 (KV-TF21M60)
FB502	1-410-397-21	FERRITE	1.1UH				

A

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
JR202	1-216-295-91	SHORT	0	Q101	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
JR301	1-216-295-91	SHORT	0	Q201	8-729-424-67	TRANSISTOR UN2216	
JR303	1-216-295-91	SHORT	0	Q202	8-729-424-67	TRANSISTOR UN2216 (except KV-PF21P40)	
JR401	1-216-295-91	SHORT	0 (except KV-PF21P40)	Q203	8-729-421-19	TRANSISTOR UN2213	
JR403	1-216-295-91	SHORT	0	Q204	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
JR404	1-216-295-91	SHORT	0	Q205	8-729-421-19	TRANSISTOR UN2213	
JR405	1-216-295-91	SHORT	0	Q206	8-729-421-19	TRANSISTOR UN2213	
JR500	1-216-295-91	SHORT	0	Q207	8-729-421-19	TRANSISTOR UN2213	
JR501	1-216-295-91	SHORT	0	Q301	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
JR503	1-216-295-91	SHORT	0	Q302	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
JR600	1-216-295-91	SHORT	0	Q303	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
		<COIL>		Q305	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L002	1-414-856-11	INDUCTOR	10UH	Q306	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L003	1-414-180-11	INDUCTOR	3.3UH	Q307	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L005	1-414-233-22	INDUCTOR CHIP	0UH	Q308	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L101	1-414-856-11	INDUCTOR	10UH	Q312	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L102	1-414-856-11	INDUCTOR	10UH	Q313	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L103	1-414-856-11	INDUCTOR	10UH	Q315	8-729-421-19	TRANSISTOR UN2213	
L104	1-414-856-11	INDUCTOR	10UH	Q401	8-729-424-67	TRANSISTOR UN2216	
L105	1-414-856-11	INDUCTOR	10UH	Q402	8-729-424-67	TRANSISTOR UN2216 (except KV-PF21P40)	
L204	1-414-856-11	INDUCTOR	10UH	Q403	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R (except KV-PF21P40)	
L301	1-414-189-31	INDUCTOR	100UH	Q404	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L302	1-414-185-41	INDUCTOR	22UH	Q503	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L501	1-412-525-31	INDUCTOR	10UH	Q505	8-729-931-45	TRANSISTOR IRF614	
L502	1-422-613-11	COIL, AIR CORE		Q506	8-729-119-80	TRANSISTOR 2SC2688-LK	
L503	1-412-525-31	INDUCTOR	10UH	Q507	8-729-026-49	TRANSISTOR 2SA1037AK-T146-R	
L504	1-412-525-31	INDUCTOR	10UH	Q509	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L505	1-412-525-31	INDUCTOR	10UH	Q511	8-729-048-07	TRANSISTOR 2SD2578-CA	
L506	1-412-525-31	INDUCTOR	10UH	Q604	8-729-200-17	TRANSISTOR 2SA1091-O	
L507	1-459-111-00	INDUCTOR	10MMH	Q605	8-729-044-30	TRANSISTOR 2SK2845-LB102	
L508	1-412-525-31	INDUCTOR	10UH	Q606	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L509	1-459-390-00	INDUCTOR	390UH	Q607	8-729-922-37	TRANSISTOR 2SD2144S-UVW	
L510	1-416-972-11	COIL, HORIZONTAL LINEARITY		Q608	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
L512	1-412-549-11	INDUCTOR	1MMH	Q901	8-729-421-19	TRANSISTOR UN2213	
L513	1-412-549-11	INDUCTOR	1MMH	Q902	8-729-421-19	TRANSISTOR UN2213	
L515	1-459-104-00	COIL, WITH CORE				<RESISTOR>	
L518	1-414-187-11	INDUCTOR	47UH	R001	1-414-233-22	INDUCTOR CHIP	0UH
L601	1-412-527-11	INDUCTOR	15UH	R002	1-216-025-91	RES,CHIP	100 5% 1/10W
L901	1-408-603-31	INDUCTOR	10UH	R003	1-216-295-91	SHORT	0
L902	1-408-603-31	INDUCTOR	10UH (except KV-PF21P40)	R004	1-216-025-91	RES,CHIP	100 5% 1/10W
L905	1-414-856-11	INDUCTOR	10UH	R005	1-216-025-91	RES,CHIP	100 5% 1/10W
		<PHOTO COUPLER>		R007	1-216-295-91	SHORT	0
PH600 △	8-749-924-35	PHOTO COUPLER ON3171-R		R008	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
		<IC LINK>		R010	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
PS200	1-532-675-21	LINK, IC 1.5A/150V		R011	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
		<TRANSISTOR>		R012	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
Q002	8-729-120-28	TRANSISTOR 2SC1623-L5L6		R013	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
Q003	8-729-424-08	TRANSISTOR UN2111		R014	1-216-025-91	RES,CHIP	100 5% 1/10W
Q004	8-729-421-22	TRANSISTOR UN2211		R015	1-216-025-91	RES,CHIP	100 5% 1/10W
				R017	1-216-049-91	RES,CHIP	1K 5% 1/10W
				R018	1-216-033-00	RES,CHIP	220 5% 1/10W
				R019	1-216-073-00	RES,CHIP	10K 5% 1/10W
				R021	1-216-073-00	RES,CHIP	10K 5% 1/10W
				R022	1-216-033-00	RES,CHIP	220 5% 1/10W

A

REF. NO.	PART NO.	DESCRIPTION			REMARK	REF. NO.	PART NO.	DESCRIPTION			REMARK		
R024	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R208	1-216-073-00	RES,CHIP	10K	5%	1/10W		
R025	1-216-057-00	RES,CHIP	2.2K	5%	1/10W				(KV-PF21P40)				
R026	1-216-057-00	RES,CHIP	2.2K	5%	1/10W			R209	1-216-077-91	RES,CHIP	15K	5%	1/10W
R027	1-216-073-00	RES,CHIP	10K	5%	1/10W				(except KV-PF21P40)				
R028	1-216-073-00	RES,CHIP	10K	5%	1/10W	R211	1-216-033-00	RES,CHIP	220	5%	1/10W		
R029	1-216-049-91	RES,CHIP	1K	5%	1/10W			(except KV-PF21P40)					
R031	1-216-049-91	RES,CHIP	1K	5%	1/10W	R211	1-216-043-91	RES,CHIP	560	5%	1/10W		
								(KV-PF21P40)					
R035	1-216-025-91	RES,CHIP	100	5%	1/10W	R212	1-216-033-00	RES,CHIP	220	5%	1/10W		
R036	1-216-025-91	RES,CHIP	100	5%	1/10W	R213	1-216-073-00	RES,CHIP	10K	5%	1/10W		
R037	1-216-025-91	RES,CHIP	100	5%	1/10W	R214	1-216-073-00	RES,CHIP	10K	5%	1/10W		
R040	1-216-025-91	RES,CHIP	100	5%	1/10W	R215	1-216-059-00	RES,CHIP	2.7K	5%	1/10W		
R041	1-216-025-91	RES,CHIP	100	5%	1/10W	R216	1-216-059-00	RES,CHIP	2.7K	5%	1/10W		
						R217	1-216-067-00	RES,CHIP	5.6K	5%	1/10W		
R042	1-216-295-91	SHORT	0			R218	1-216-067-00	RES,CHIP	5.6K	5%	1/10W		
R043	1-216-049-91	RES,CHIP	1K	5%	1/10W	R219	1-216-025-91	RES,CHIP	100	5%	1/10W		
R044	1-216-025-91	RES,CHIP	100	5%	1/10W	R220	1-216-025-91	RES,CHIP	100	5%	1/10W		
R045	1-414-233-22	INDUCTOR CHIP	0UH			R221	1-216-295-91	SHORT	0				
R046	1-216-049-91	RES,CHIP	1K	5%	1/10W	R222	1-216-295-91	SHORT	0 (except KV-PF21P40)				
R047	1-414-233-22	INDUCTOR CHIP	0UH			R225	1-216-033-00	RES,CHIP	220	5%	1/10W		
R048	1-216-073-00	RES,CHIP	10K	5%	1/10W	R226	1-216-033-00	RES,CHIP	220	5%	1/10W		
R050	1-216-073-00	RES,CHIP	10K	5%	1/10W	R227	1-216-033-00	RES,CHIP	220	5%	1/10W		
R053	1-216-049-91	RES,CHIP	1K	5%	1/10W	R228	1-249-389-11	CARBON	4.7	5%	1/4W		
R055	1-216-073-00	RES,CHIP	10K	5%	1/10W			(except KV-PF21P40)					
						R229	1-216-073-00	RES,CHIP	10K	5%	1/10W		
R056	1-216-073-00	RES,CHIP	10K	5%	1/10W	R230	1-216-065-91	RES,CHIP	4.7K	5%	1/10W		
R061	1-216-033-00	RES,CHIP	220	5%	1/10W	R231	1-216-295-91	SHORT	0				
R062	1-216-041-00	RES,CHIP	470	5%	1/10W	R234	1-249-389-11	CARBON	4.7	5%	1/4W		
R063	1-216-037-00	RES,CHIP	330	5%	1/10W	R235	1-216-069-00	RES,CHIP	6.8K	5%	1/10W		
R064	1-216-037-00	RES,CHIP	330	5%	1/10W	R236	1-216-069-00	RES,CHIP	6.8K	5%	1/10W		
R065	1-216-037-00	RES,CHIP	330	5%	1/10W	R237	1-216-308-00	RES,CHIP	4.7	5%	1/10W		
R066	1-216-049-91	RES,CHIP	1K	5%	1/10W	R301	1-216-071-00	RES,CHIP	8.2K	5%	1/10W		
R067	1-216-049-91	RES,CHIP	1K	5%	1/10W			(except KV-PF21P40)					
R101	1-216-025-91	RES,CHIP	100	5%	1/10W	R301	1-216-065-91	RES,CHIP	4.7K	5%	1/10W		
		(except KV-PF21P40)						(KV-PF21P40)					
R102	1-216-025-91	RES,CHIP	100	5%	1/10W								
		(except KV-PF21P40)				R302	1-216-295-91	SHORT	0				
R105	1-216-295-91	SHORT	0			R303	1-216-049-91	RES,CHIP	1K	5%	1/10W		
R109	1-216-041-00	RES,CHIP	470	5%	1/10W								
R111	1-216-025-91	RES,CHIP	100	5%	1/10W	R304	1-216-073-00	RES,CHIP	10K	5%	1/10W		
R112	1-216-025-91	RES,CHIP	100	5%	1/10W	R305	1-216-051-00	RES,CHIP	1.2K	5%	1/10W		
R113	1-216-047-91	RES,CHIP	820	5%	1/10W	R306	1-216-073-00	RES,CHIP	10K	5%	1/10W		
						R308	1-216-025-91	RES,CHIP	100	5%	1/10W		
R202	1-216-077-91	RES,CHIP	15K	5%	1/10W	R309	1-216-025-91	RES,CHIP	100	5%	1/10W		
		(except KV-PF21P40)											
R202	1-216-071-00	RES,CHIP	8.2K	5%	1/10W								
		(KV-PF21P40)				R310	1-216-025-91	RES,CHIP	100	5%	1/10W		
R203	1-216-073-00	RES,CHIP	10K	5%	1/10W	R311	1-216-017-91	RES,CHIP	47	5%	1/10W		
		(except KV-PF21P40)				R312	1-216-041-00	RES,CHIP	470	5%	1/10W		
R203	1-216-077-91	RES,CHIP	15K	5%	1/10W	R313	1-216-053-00	RES,CHIP	1.5K	5%	1/10W		
		(KV-PF21P40)				R314	1-216-045-00	RES,CHIP	680	5%	1/10W		
R204	1-216-077-91	RES,CHIP	15K	5%	1/10W								
		(except KV-PF21P40)				R316	1-216-053-00	RES,CHIP	1.5K	5%	1/10W		
						R317	1-216-077-91	RES,CHIP	15K	5%	1/10W		
R204	1-216-071-00	RES,CHIP	8.2K	5%	1/10W	R318	1-216-051-00	RES,CHIP	1.2K	5%	1/10W		
		(KV-PF21P40)				R319	1-216-025-91	RES,CHIP	100	5%	1/10W		
R205	1-216-077-91	RES,CHIP	15K	5%	1/10W	R320	1-216-065-91	RES,CHIP	4.7K	5%	1/10W		
		(except KV-PF21P40)											
R206	1-216-073-00	RES,CHIP	10K	5%	1/10W	R321	1-216-073-00	RES,CHIP	10K	5%	1/10W		
		(except KV-PF21P40)				R322	1-216-033-00	RES,CHIP	220	5%	1/10W		
R207	1-216-077-91	RES,CHIP	15K	5%	1/10W	R331	1-216-295-91	SHORT	0				
		(except KV-PF21P40)				R332	1-216-033-00	RES,CHIP	220	5%	1/10W		
R208	1-216-077-91	RES,CHIP	15K	5%	1/10W	R333	1-216-073-00	RES,CHIP	10K	5%	1/10W		
		(except KV-PF21P40)											
						R334	1-216-129-00	RES,CHIP	2.2M	5%	1/10W		
						R335	1-216-045-00	RES,CHIP	680	5%	1/10W		

KV-PF21P40/TF21M60/TF21P50
RM-952

A

REF. NO.	PART NO.	DESCRIPTION	REMARK	REF. NO.	PART NO.	DESCRIPTION	REMARK
R338	1-216-033-00	RES,CHIP	220 5% 1/10W	R510	1-215-885-00	METAL OXIDE	68 5% 2W F
R340	1-216-025-91	RES,CHIP	100 5% 1/10W	R511	1-215-911-11	METAL OXIDE	100 5% 3W F
R345	1-216-081-00	RES,CHIP	22K 5% 1/10W	R516	1-216-081-00	RES,CHIP	22K 5% 1/10W
R348	1-208-806-11	METAL CHIP	10K 0.50% 1/10W	R518	1-247-807-31	CARBON	100 5% 1/4W
R349	1-216-073-00	RES,CHIP	10K 5% 1/10W	R520	1-215-445-00	METAL	10K 1% 1/4W
R350	1-216-061-00	RES,CHIP	3.3K 5% 1/10W	R522	1-208-806-11	METAL CHIP	10K 0.50% 1/10W
R351	1-216-053-00	RES,CHIP	1.5K 5% 1/10W	R523	1-249-411-11	CARBON	330 5% 1/4W
R354	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R525	1-208-830-11	METAL CHIP	100K 0.50% 1/10W
R355	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R526	1-208-798-11	METAL CHIP	4.7K 0.50% 1/10W
R356	1-216-057-00	RES,CHIP	2.2K 5% 1/10W	R527	1-216-001-00	RES,CHIP	10 5% 1/10W
R357	1-216-079-00	RES,CHIP	18K 5% 1/10W	R528	1-208-814-91	METAL CHIP	22K 0.50% 1/10W
R358	1-216-049-91	RES,CHIP	1K 5% 1/10W	R529	1-208-766-11	METAL CHIP	220 0.50% 1/10W
R359	1-216-033-00	RES,CHIP	220 5% 1/10W	R531	1-247-843-11	CARBON	3.3K 5% 1/4W
R360	1-216-033-00	RES,CHIP	220 5% 1/10W	R533	1-249-417-11	CARBON	1K 5% 1/4W
R361	1-216-073-00	RES,CHIP	10K 5% 1/10W	R534	1-216-361-21	METAL OXIDE	0.22 5% 2W F
R362	1-216-075-00	RES,CHIP	12K 5% 1/10W	R535	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R363	1-216-079-00	RES,CHIP	18K 5% 1/10W	R536	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R364	1-216-295-91	SHORT	0	R537	1-208-814-91	METAL CHIP	22K 0.50% 1/10W
R365	1-216-033-00	RES,CHIP	220 5% 1/10W	R540	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R366	1-216-073-00	RES,CHIP	10K 5% 1/10W	R541	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R367	1-216-073-00	RES,CHIP	10K 5% 1/10W	R542	1-216-295-91	SHORT	0
R370	1-216-033-00	RES,CHIP	220 5% 1/10W	R543	1-249-426-11	CARBON	5.6K 5% 1/4W F
R376	1-216-081-00	RES,CHIP	22K 5% 1/10W	R544	1-216-457-21	METAL OXIDE	1.2K 5% 2W F
R377	1-216-121-91	RES,CHIP	1M 5% 1/10W	R545	1-216-077-91	RES,CHIP	15K 5% 1/10W
R378	1-216-031-00	RES,CHIP	180 5% 1/10W	R546	1-216-077-91	RES,CHIP	15K 5% 1/10W
R401	1-216-049-91	RES,CHIP	1K 5% 1/10W	R547	1-216-085-00	RES,CHIP	33K 5% 1/10W
R402	1-216-073-00	(except KV-PF21P40) RES,CHIP	10K 5% 1/10W	R549	1-215-451-00	METAL	18K 1% 1/4W
R403	1-216-073-00	(except KV-PF21P40) RES,CHIP	10K 5% 1/10W	R550	1-216-097-91	RES,CHIP	100K 5% 1/10W
R404	1-216-073-00	RES,CHIP	10K 5% 1/10W	R551	1-249-421-11	CARBON	2.2K 5% 1/4W
R405	1-216-049-91	RES,CHIP	1K 5% 1/10W	R552	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R406	1-216-073-00	RES,CHIP	10K 5% 1/10W	R553	1-215-457-00	METAL	33K 1% 1/4W
R407	1-216-049-91	RES,CHIP	1K 5% 1/10W	R554	1-215-457-00	METAL	33K 1% 1/4W
R408	1-216-049-91	(except KV-PF21P40) RES,CHIP	1K 5% 1/10W	R556	1-215-437-00	METAL	4.7K 1% 1/4W
R409	1-216-041-00	RES,CHIP	470 5% 1/10W	R558	1-249-421-11	CARBON	2.2K 5% 1/4W
R410	1-216-113-00	(except KV-PF21P40) RES,CHIP	470K 5% 1/10W	R559	1-249-429-11	CARBON	10K 5% 1/4W
R411	1-216-113-00	RES,CHIP	470K 5% 1/10W	R560	1-216-073-00	RES,CHIP	10K 5% 1/10W
R412	1-216-041-00	RES,CHIP	470 5% 1/10W	R562	1-249-401-11	CARBON	47 5% 1/4W
R413	1-216-021-00	RES,CHIP	68 5% 1/10W	R565	1-216-073-00	RES,CHIP	10K 5% 1/10W
R414	1-216-113-00	RES,CHIP	470K 5% 1/10W	R567	1-216-105-91	RES,CHIP	220K 5% 1/10W
R415	1-216-113-00	RES,CHIP	470K 5% 1/10W	R568	1-249-383-11	CARBON	1.5 5% 1/4W F
R416	1-216-077-91	(except KV-PF21P40) RES,CHIP	15K 5% 1/10W	R570	1-216-069-00	RES,CHIP	6.8K 5% 1/10W
R417	1-216-077-91	(except KV-PF21P40) RES,CHIP	15K 5% 1/10W	R571	1-215-437-00	METAL	4.7K 1% 1/4W
R418	1-216-113-00	RES,CHIP	470K 5% 1/10W	R573	1-216-089-91	RES,CHIP	47K 5% 1/10W
R419	1-216-022-00	RES,CHIP	75 5% 1/10W	R577	1-215-913-11	METAL OXIDE	220 5% 3W F
R426	1-216-033-00	RES,CHIP	220 5% 1/10W	R578	1-216-369-00	METAL OXIDE	1 5% 2W F
R505	1-216-099-00	RES,CHIP	120K 5% 1/10W	R579	1-216-097-91	RES,CHIP	100K 5% 1/10W
R506	1-216-085-00	RES,CHIP	33K 5% 1/10W	R580	1-208-830-11	METAL CHIP	100K 0.50% 1/10W
R507	1-249-389-11	CARBON	4.7 5% 1/4W F	R581	1-208-798-11	METAL CHIP	4.7K 0.50% 1/10W
R508	1-215-910-00	METAL OXIDE	68 5% 3W F	R585	1-249-391-11	CARBON	6.8 5% 1/4W F
R509	1-215-911-11	METAL OXIDE	100 5% 3W F	R588	1-215-888-00	METAL OXIDE	220 5% 2W F
				R589	1-215-888-00	METAL OXIDE	220 5% 2W F
				R590	1-215-465-00	METAL	68K 1% 1/4W
				R591	1-260-288-11	CARBON	0.47 5% 1/2W F
				R593	1-260-288-11	CARBON	0.47 5% 1/2W F
				R594	1-260-288-11	CARBON	0.47 5% 1/2W F
				R596	1-216-485-11	METAL OXIDE	5.6K 5% 3W F
				R597	1-247-750-11	CARBON	680 5% 1/2W F
				R598	1-249-438-11	CARBON	56K 5% 1/4W

The components identified by shading
and mark $\triangle$ are critical for safety.
Replace only with part number specified.

A **C₃**

REF. NO.	PART NO.	DESCRIPTION	REMARK
R599	1-249-389-11	CARBON	4.7 5% 1/4W
R600	1-249-438-11	CARBON	56K 5% 1/4W
R601	1-249-418-11	CARBON	1.2K 5% 1/4W F
R602	1-249-389-11	CARBON	4.7 5% 1/4W F
R603	1-215-485-00	METAL	470K 1% 1/4W
R607	1-249-425-11	CARBON	4.7K 5% 1/4W
R608	1-240-205-91	CARBON	22M 5% 1/2W
R609	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R610	1-216-073-00	RES,CHIP	10K 5% 1/10W
R611	1-216-089-91	RES,CHIP	47K 5% 1/10W
R612	1-216-045-00	RES,CHIP	680 5% 1/10W
R614	1-216-041-00	RES,CHIP	470 5% 1/10W
R615	1-216-350-11	METAL OXIDE	1.2 5% 1W F
R616	1-260-302-51	CARBON	6.8 5% 1/2W F
R617	1-247-791-91	CARBON	22 5% 1/4W
R619	1-260-128-11	CARBON	270K 5% 1/2W
R620	1-215-915-11	METAL OXIDE	470 5% 3W F
R622	1-216-398-11	METAL OXIDE (KV-TF21M60)	5.6 5% 3W F
R625	1-202-961-11	CEMENTED	1.8 5% 10W
R628	1-202-961-11	CEMENTED	1.8 5% 10W
R632	1-202-933-61	FUSIBLE	0.1 10% 1/2W F
R634 $\triangle$	1-218-265-11	METAL	8.2M 5% 1W
R635	1-216-492-21	METAL OXIDE	82K 5% 3W F
R636	1-215-924-00	METAL OXIDE	15K 5% 3W F
R637	1-216-492-21	METAL OXIDE	82K 5% 3W F
R639	1-216-363-00	METAL OXIDE	0.33 5% 2W F
R640	1-249-415-11	CARBON	680 5% 1/4W
R641	1-216-362-11	METAL OXIDE	0.27 5% 2W F
R642	1-249-419-11	CARBON	1.5K 5% 1/4W
R643	1-247-843-11	CARBON	3.3K 5% 1/4W
R644	1-249-419-11	CARBON	1.5K 5% 1/4W
R646	1-215-924-00	METAL OXIDE	15K 5% 3W F
R647	1-249-401-11	CARBON	47 5% 1/4W
R648	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
R649	1-249-417-11	CARBON	1K 5% 1/4W
R650	1-215-882-00	METAL OXIDE	22 5% 2W F
R652	1-215-900-11	METAL OXIDE	22K 5% 2W F
R653	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R657	1-260-127-11	CARBON	220K 5% 1/2W
R659	1-216-049-91	RES,CHIP	1K 5% 1/10W
R660	1-216-073-00	RES,CHIP	10K 5% 1/10W
R661	1-215-873-00	METAL OXIDE	4.7K 5% 1W F
R901	1-249-411-11	CARBON	330 5% 1/4W
R902	1-249-411-11	CARBON (except KV-PF21P40)	330 5% 1/4W
R903	1-216-022-00	RES,CHIP	75 5% 1/10W
R904	1-216-033-00	RES,CHIP	220 5% 1/10W
R905	1-216-113-00	RES,CHIP	470K 5% 1/10W
R906	1-216-077-91	RES,CHIP	15K 5% 1/10W
R907	1-216-113-00	RES,CHIP (except KV-PF21P40)	470K 5% 1/10W
R908	1-216-077-91	RES,CHIP (except KV-PF21P40)	15K 5% 1/10W
R909	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R910	1-216-065-91	RES,CHIP	4.7K 5% 1/10W
R911	1-216-067-00	RES,CHIP	5.6K 5% 1/10W
R912	1-216-041-00	RES,CHIP	470 5% 1/10W

REF. NO.	PART NO.	DESCRIPTION	REMARK
R913	1-216-049-91	RES,CHIP	1K 5% 1/10W
R914	1-216-055-00	RES,CHIP	1.8K 5% 1/10W
R915	1-216-061-00	RES,CHIP	3.3K 5% 1/10W
R916	1-216-017-91	RES,CHIP	47 5% 1/10W
R917	1-216-041-00	RES,CHIP	470 5% 1/10W
R918	1-216-041-00	RES,CHIP	470 5% 1/10W
<RELAY>			
RY601 $\triangle$	1-755-299-11	RELAY	
<SWITCH>			
S502	1-572-707-11	SWITCH, LEVER	
S600 $\triangle$	1-571-433-21	SWITCH, PUSH (AC POWER)	
S901	1-692-431-21	SWITCH, TACTILE	
S902	1-692-431-21	SWITCH, TACTILE	
S903	1-692-431-21	SWITCH, TACTILE	
S904	1-692-431-21	SWITCH, TACTILE	
S905	1-692-431-21	SWITCH, TACTILE	
S906	1-692-431-21	SWITCH, TACTILE	
S907	1-692-431-21	SWITCH, TACTILE	
<TRANSFORMER>			
T501	1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE	
T503 $\triangle$	1-453-293-11	FBT ASSY, NX-1748/M3A4	
T601	1-424-682-11	TRANSFORMER, LINE FILTER	
T603 $\triangle$	1-433-512-11	TRANSFORMER, CONVERTER (SRT)	
T604 $\triangle$	1-431-852-11	TRANSFORMER, CONVERTER (SRT)	
<THERMISTOR>			
THP600	1-810-961-11	THERMISTOR, POSITIVE	
<TUNER>			
TU101	8-598-448-10	TUNER, FSS BTF-LG413 (except KV-TF21M60)	
TU101	8-598-451-20	TUNER, FSS BTF-WG441 (KV-TF21M60)	
<CRYSTAL>			
X001	1-579-125-11	VIBRATOR, CERAMIC	
X301	1-781-134-21	VIBRATOR, CRYSTAL	
X302	1-781-132-21	VIBRATOR, CRYSTAL	

* A-1331-900-A		C3 BOARD MOUNTED	*****
7-682-948-01		SCREW +PSW 3X8	
<CAPACITOR>			
C701	1-162-114-00	CERAMIC	0.0047MF 2KV
C702	1-102-074-00	CERAMIC	0.001MF 10% 50V

The components identified by shading
and mark Δ are critical for safety.
Replace only with part number specified.

C3

F

REF. NO.	PART NO.	DESCRIPTION	REMARK			
C703	1-107-651-11	ELECT	4.7MF	20%	250V	
C704	1-130-202-00	FILM	0.022MF	5%	400V	
C706	1-104-664-11	ELECT	47MF	20%	16V	
C708	1-102-114-00	CERAMIC	470PF	10%	50V	
C709	1-102-114-00	CERAMIC	470PF	10%	50V	
C710	1-102-114-00	CERAMIC	470PF	10%	50V	
C712	1-102-116-00	CERAMIC	680PF	10%	50V	
C713	1-102-116-00	CERAMIC	680PF	10%	50V	
C714	1-102-116-00	CERAMIC	680PF	10%	50V	
C716	1-126-933-11	ELECT	100MF	20%	16V	
C717	1-101-880-00	CERAMIC	47PF	5%	50V	
C736	1-102-114-00	CERAMIC	470PF	10%	50V	
C737	1-102-114-00	CERAMIC	470PF	10%	50V	
C746	1-102-114-00	CERAMIC	470PF	10%	50V	
<CONNECTOR>						
CN701	1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P				
CN702	1-695-915-11	TAB (CONTACT)				
CN703	* 1-564-509-11	PLUG, CONNECTOR 6P				
CN704	1-695-915-11	TAB (CONTACT)				
<DIODE>						
D701	8-719-911-19	DIODE 1SS119-25				
D702	8-719-911-19	DIODE 1SS119-25				
D703	8-719-911-19	DIODE 1SS119-25				
D707	8-719-911-19	DIODE 1SS119-25				
D708	8-719-911-19	DIODE 1SS119-25				
D709	8-719-911-19	DIODE 1SS119-25				
D710	8-719-911-19	DIODE 1SS119-25				
D711	8-719-911-19	DIODE 1SS119-25				
D712	8-719-911-19	DIODE 1SS119-25				
D713	8-719-911-19	DIODE 1SS119-25				
D714	8-719-911-19	DIODE 1SS119-25				
D715	8-719-911-19	DIODE 1SS119-25				
D716	8-719-911-19	DIODE 1SS119-25				
D717	8-719-121-26	DIODE RD9.1ESL2				
<JACK>						
J701	Δ 1-540-071-22	SOCKET, CRT				
<COIL>						
L701	1-410-667-31	INDUCTOR	22UH			
L710	1-408-613-31	INDUCTOR	68UH			
L711	1-408-613-31	INDUCTOR	68UH			
L712	1-408-613-31	INDUCTOR	68UH			
<TRANSISTOR>						
Q704	8-729-326-11	TRANSISTOR 2SC2611				
Q705	8-729-326-11	TRANSISTOR 2SC2611				
Q706	8-729-326-11	TRANSISTOR 2SC2611				
Q707	8-729-200-17	TRANSISTOR 2SA1091-O				
Q708	8-729-200-17	TRANSISTOR 2SA1091-O				

REF. NO.	PART NO.	DESCRIPTION				REMARK	
Q709	8-729-200-17	TRANSISTOR 2SA1091-O					
Q710	8-729-119-78	TRANSISTOR 2SC2785-HFE					
Q711	8-729-119-78	TRANSISTOR 2SC2785-HFE					
Q712	8-729-119-78	TRANSISTOR 2SC2785-HFE					
<RESISTOR>							
R703	1-249-496-11	CARBON	100K	5%	1/2W		
R705	1-216-380-11	METAL OXIDE	8.2	5%	2W	F	
R706	1-215-417-00	METAL	680	1%	1/4W		
R707	1-215-413-00	METAL	470	1%	1/4W		
R708	1-216-379-21	METAL OXIDE	6.8	5%	2W	F	
R710	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F	
R711	1-247-752-11	CARBON	1K	5%	1/2W		
R712	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F	
R713	1-247-752-11	CARBON	1K	5%	1/2W		
R714	1-215-922-11	METAL OXIDE	6.8K	5%	3W	F	
R715	1-247-752-11	CARBON	1K	5%	1/2W		
R719	1-215-480-00	METAL	300K	1%	1/4W		
R720	1-249-923-11	CARBON	1K	5%	1/4W	F	
R721	1-215-489-00	METAL	680K	1%	1/4W		
R722	1-249-923-11	CARBON	1K	5%	1/4W	F	
R723	1-215-479-00	METAL	270K	1%	1/4W		
R724	1-249-923-11	CARBON	1K	5%	1/4W	F	
R725	1-249-421-11	CARBON	2.2K	5%	1/4W		
R726	1-249-421-11	CARBON	2.2K	5%	1/4W		
R727	1-249-421-11	CARBON	2.2K	5%	1/4W		
R728	1-249-407-11	CARBON	150	5%	1/4W		
R729	1-249-407-11	CARBON	150	5%	1/4W		
R730	1-249-407-11	CARBON	150	5%	1/4W		
R731	1-249-407-11	CARBON	150	5%	1/4W		
R732	1-249-407-11	CARBON	150	5%	1/4W		
R733	1-249-406-11	CARBON	120	5%	1/4W		
R734	1-247-739-11	CARBON	100	5%	1/2W		
R738	1-247-807-31	CARBON	100	5%	1/4W		
R739	1-247-807-31	CARBON	100	5%	1/4W		
R740	1-247-807-31	CARBON	100	5%	1/4W		
R755	1-249-418-11	CARBON	1.2K	5%	1/4W		
R756	1-249-418-11	CARBON	1.2K	5%	1/4W		
R757	1-249-418-11	CARBON	1.2K	5%	1/4W		
<VARIABLE RESISTOR>							
RV702	1-241-656-11	RES, ADJ, METAL FILM 110M					

* A-1241-360-A		F BOARD MOUNTED					

1-533-223-11		CLIP, FUSE					
4-044-778-11		COVER, CAP TYPE CONDENSER					
<CAPACITOR>							
C654	△ 1-117-703-11	CERAMIC	0.0047MF	99%	250V		
C4602	△ 1-104-708-11	MYLAR	0.47MF	20%	250V		

The components identified by shading
and mark $\triangle$ are critical for safety.
Replace only with part number specified.



REF. NO.	PART NO.	DESCRIPTION	REMARK
		<CONNECTOR>	
CN4601 *	1-580-843-11	PIN, CONNECTOR (POWER)	
CN4602 *	1-580-843-11	PIN, CONNECTOR (POWER)	
CN4603	1-695-915-11	TAB (CONTACT)	
		<FUSE>	
F4601 $\triangle$	1-532-237-00	FUSE, TIME-LAG (BET) 3.15A/250V	
		<RESISTOR>	
R4601 $\triangle$	1-202-719-00	SOLID 1M 10% 1/2W	
		<TRANSFORMER>	
T4601	1-424-682-11	TRANSFORMER, LINE FILTER	
		<VARISTOR>	
VDR461	1-803-830-31	VARISTOR (ERZV14D621)	

		MISCELLANEOUS	

$\triangle$	1-416-946-11	COIL, DEMAGNETIC	
	1-417-151-21	MATCHING TRANSFORMER, ANTENNA (KV-TF21P40 ONLY)	
	1-452-032-00	MAGNET, DISC	
	1-501-372-81	ANTENNA, TELESCOPIC (KV-PF21P40 ONLY)	
	1-505-740-11	SPEAKER (5X9CM)	
	1-540-005-31	CAP ASSY, HIGH VOLTAGE	
$\triangle$	1-575-023-11	CORD, POWER (WITH CONNECTOR) 6A/250V	
	8-451-505-11	DEFLECTION YOKE (Y21RSA-S)	
$\triangle$	8-738-812-05	PICTURE TUBE (A51LPT70X)	

		ACCESSORIES AND PACKING MATERIAL	

	3-701-910-00	SCREW, SPECIAL (DIA. 3.8X20)	
	4-059-705-01	CLIP	
	3-867-728-11	MANUAL, INSTRUCTION (except KV-PF21P40)	
	3-867-760-11	MANUAL, INSTRUCTION (KV-TF21P40)	
	4-392-003-21	BAND, HOLDING	
*	4-037-759-01	BAG, PROTECTION	
*	4-072-172-01	CUSHION(UPPER)(ASSY)	
*	4-072-175-01	CUSHION(LOWER)(ASSY)	
*	4-072-178-01	INDIVIDUAL CARTON	

REF. NO.	PART NO.	DESCRIPTION	REMARK
		REMOTE COMMANDER	

1-418-163-11		REMOTE COMMANDER (RM-952)	
9-939-697-01		BATTERY COVER, REMOTE COMMANDER	

