

# GDM-F400/F400T9


## SERVICE MANUAL

*GDM-F400  
US Model  
Canadian Model*

*Chassis No. SCC-L03D-A*

*GDM-F400T9  
AEP Model*

*Chassis No. SCC-L03D-A*



**N3P CHASSIS**

### SPECIFICATIONS

CRT	0.22 mm aperture grille pitch 19 inches measured diagonally 90-degree deflection FD Trinitron	Deflection frequency* AC input voltage/current Power consumption	Horizontal: 30 to 107 kHz Vertical: 48 to 160 Hz 100 to 240 V, 50 – 60 Hz, 1.8 – 1.0 A Max. 140 W (with no USB devices connected)
Viewable image size	Approx. 364.8 × 273.6 mm (w/h) (14 3/8 × 10 7/8 inches) 18.0" viewing image	Dimensions	Approx. 444 × 476 × 455 mm (w/h/d) (17 1/2 × 18 3/4 × 18 inches)
Resolution	Horizontal: Max. 1600 dots Vertical: Max. 1200 lines	Mass	Approx. 28 kg (61 lb 12 oz)
Standard image area	Approx. 352 × 264 mm (w/h) (13 7/8 × 10 1/2 inches) or Approx. 330 × 264 mm (w/h) (13 × 10 1/2 inches)	Plug and Play	DDC1/DDC2B/DDC2Bi/DDC2B+

\* Recommended horizontal and vertical timing condition

- Horizontal sync width duty should be more than 4.8% of total horizontal time or 0.8 µs, whichever is larger.
- Horizontal blanking width should be more than 2.5 µsec.
- Vertical blanking width should be more than 450 µsec.

Design and specifications are subject to change without notice.

**TRINITRON® COLOR GRAPHIC DISPLAY**

**SONY®**



## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Check that all control knobs, shields, covers, ground straps, and mounting hardware have been replaced. Be absolutely certain that you have replaced all the insulators.
4. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
5. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
6. Check the line cords for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
7. Check the B+ and HV to see if they are specified values. Make sure your instruments are accurate; be suspicious of your HV meter if sets always have low HV.
8. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC Leakage. Check leakage as described below.





Fig. A. Using an AC voltmeter to check AC leakage.

#### CAUTION ON DAS (ECS) CONNECTOR

- The connector for DAS (ECS) adjustment is provided inside the cover shown below. Be careful with an electrical shock when connecting the connector with the power supplied. Also, return the removed cover to the home position.



#### LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes).

Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOMs that are suitable. Nearly all battery operated digital multimeters that have a 2 V AC range are suitable. (See Fig. A)

#### WARNING!!

**NEVER TURN ON THE POWER IN A CONDITION IN WHICH THE DEGAUSS COIL HAS BEEN REMOVED.**

#### SAFETY-RELATED COMPONENT WARNING!!

**COMPONENTS IDENTIFIED BY SHADING AND MARK**

**⚠ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL FOR SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.**

#### AVERTISSEMENT!!

**NE JAMAIS METTRE SOUS TENSION QUAND LA BOBINE DE DEMAGNETISATION EST ENLEVÉE.**

#### ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

**LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET UNE MARQUE ⚠ SONT CRITIQUES POUR LA SÉCURITÉ. NE LES REMPLACER QUE PAR UNE PIÈCE PORTANT LE NUMÉRO SPÉCIFIÉ. LES RÉGLAGES DE CIRCUIT DONT L'IMPORTANCE EST CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT SONT IDENTIFIÉS DANS LE PRÉSENT MANUEL. SUIVRE CES PROCÉDURES LORS DE CHAQUE REMPLACEMENT DE COMPOSANTS CRITIQUES, OU LORSQU'UN MAUVAIS FONCTIONNEMENT EST SUSPECTÉ.**

## POWER SAVING FUNCTION

This monitor meets the power-saving guidelines set by VESA, ENERGY STAR, and NUTEK. If the monitor is connected to a computer or video graphics board that is DPMS (Display Power Management Signaling) compliant, the monitor will automatically reduce power consumption in three stages as shown below.

Power mode	Power consumption*	⊕ (power) indicator
normal operation	≤ 140 W (GDM-F400)	green
1 standby	≤ 80 W (GDM-F400)	green and orange alternate
2 suspend	≤ 10 W (GDM-F400)	green and orange alternate
3 active off**	≤ 3 W (GDM-F400)	orange
power off	0 W	off

\* Figures reflect power consumption when no USB compatible peripherals are connected to the monitor.


\*\*When your computer enters the “active off” mode, the input signal is cut and NO INPUT SIGNAL appears on the screen. After the time set in “Changing the power saving delay time.” (page 1-6) has elapsed, the monitor enters the power saving mode.

### To change the power saving delay time

See page 1-6.


## DIAGNOSIS

This monitor is equipped with a self-diagnosis function. If there is a problem with your monitor or computer(s), the screen will go blank and the ⊕ (power) indicator will either light up green or flash orange. If the ⊕ (power) indicator is lit in orange, the computer is in power saving mode. Try pressing any key on the keyboard.



### If the ⊕ (power) indicator is green

- 1 Remove any plugs from the video input 1 and 2 connectors, or turn off the connected computer(s).
- 2 Press the ⊕ (power) button to turn the monitor off and on.
- 3 Move the joystick to the right for 2 seconds before the monitor enters power saving mode.



If all four color bars appear (white, red, green, blue), the monitor is working properly. Reconnect the video input cables and check the condition of your computer(s).

If the color bars do not appear, there is a potential monitor failure. Inform your authorized Sony dealer of the monitor's condition.

### If the ⊕ (power) indicator is flashing orange

Press the ⊕ (power) button to turn the monitor off and on.

If the ⊕ (power) indicator lights up green, the monitor is working properly.

If the ⊕ (power) indicator is still flashing, there is a potential monitor failure. Count the number of seconds between orange flashes of the ⊕ (power) indicator and inform your authorized Sony dealer of the monitor's condition. Be sure to note the model name and serial number of your monitor. Also note the make and model of your computer and video board.

# GDM-F400/F400T9

## TIMING SPECIFICATION

MODE	TEST MODE	MODE 1	MODE 2	MODE 3	MODE 4
MODE AT PRODUCTION					
RESOLUTION	738 X 414	1600 X 1200	1600 X 1200	1280 X 1024	
CLOCK	28.322 MHz	229.5 MHz	202.5 MHz	157.5 MHz	
HORIZONTAL					
H-FREQ	31.469 kHz usec	106.25 kHz usec	93.75 kHz usec	91.146 kHz usec	
H. TOTAL	31.777	9.412	10.667	10.971	
H. BLK	5.72	2.44	2.765	2.844	
H. FP	0.318	0.279	0.316	0.406	
H. SYNC	3.813	0.837	0.948	1.016	
H. BP	1.589	1.325	1.501	1.422	
H. ACTIV	26.057	6.972	7.901	8.127	
- VERTICAL -					
V. FREQ(HZ)	70.087 Hz lines	85 Hz lines	75 Hz lines	85.024 Hz lines	
V. TOTAL	449	1250	1250	1072	
V. BLK	35	50	50	48	
V. FP	5	1	1	1	
V. SYNC	2	3	3	3	
V. BP	28	46	46	44	
V. ACTIV	414	1200	1200	1024	
- SYNC -					
INT(G)	NO	NO	NO	NO	
EXT(H/V)/POLARITY	YES N/P	YES P/P	YES P/P	YES P/P	
EXT(CS) /POLARITY	NO	NO	NO	NO	
INT/NON INT	NON INT	NON INT	NON INT	NON INT	
SIZE	352 X 264 mm	352 X 264 mm	352 X 264 mm	330 X 264 mm	

## TABLE OF CONTENTS

<i>Section</i>	<i>Title</i>	<i>Page</i>
<b>1. GENERAL .....</b>		1-1
<b>2. DISASSEMBLY</b>		
2-1. Cabinet Removal .....		2-1
2-2. A Board Removal .....		2-1
2-3. AC Inlet and Rear Shield Removal .....		2-2
2-4. D Board Removal .....		2-2
2-5. Service Position .....		2-3
2-6. US Board Removal .....		2-3
2-7. Bezel and H Board Removal .....		2-4
2-8. Picture Tube Removal .....		2-5
2-9. Harness Location .....		2-6
<b>3. SAFETY RELATED ADJUSTMENT .....</b>		3-1
<b>4. ADJUSTMENTS .....</b>		4-1
<b>5. DIAGRAMS</b>		
5-1. Block Diagrams .....		5-1
5-2. Frame Shchematic Diagram .....		5-5
5-3. Circuit Boards Location .....		5-7
5-4. Schematic Diagrams and Printed Wiring Boards .....		5-8
(1) Schematic Diagrams of US Board .....		5-9
(2) Schematic Diagrams of A Board .....		5-11
(3) Schematic Diagram of H Board .....		5-14
(4) Schematic Diagram of D Board .....		5-15
5-5. Semiconductors .....		5-29
<b>6. EXPLODED VIEWS</b>		
6-1. Chassis .....		6-1
6-2. Picture Tube .....		6-2
6-3. Packing Materials .....		6-3
<b>7. ELECTRICAL PARTS LIST .....</b>		7-1

The operating instructions mentioned here are partial abstracts from the Operating Instruction Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

## Precautions


### Warning on power connections

- Use the supplied power cord. If you use a different power cord, be sure that it is compatible with your local power supply.

#### For the customers in the U.S.A.

If you do not use the appropriate cord, this monitor will not conform to mandatory FCC standards.

Example of plug types



for 100 to 120 V AC



for 200 to 240 V AC

- Before disconnecting the power cord, wait at least 30 seconds after turning off the power to allow the static electricity on the screen's surface to discharge.
- After the power is turned on, the screen is demagnetized (degaussed) for about 3 seconds. This generates a strong magnetic field around the screen which may affect data stored on magnetic tapes and disks placed near the monitor. Be sure to keep magnetic recording equipment, tapes, and disks away from the monitor.

The equipment should be installed near an easily accessible outlet.

## Installation

Do not install the monitor in the following places:

- on surfaces (rugs, blankets, etc.) or near materials (curtains, draperies, etc.) that may block the ventilation holes
- near heat sources such as radiators or air ducts, or in a place subject to direct sunlight
- in a place subject to severe temperature changes
- in a place subject to mechanical vibration or shock
- on an unstable surface
- near equipment which generates magnetism, such as a transformer or high voltage power lines
- near or on an electrically charged metal surface

## Maintenance

- Clean the screen with a soft cloth. If you use a glass cleaning liquid, do not use any type of cleaner containing an anti-static solution or similar additive as this may scratch the screen's coating.
- Do not rub, touch, or tap the surface of the screen with sharp or abrasive items such as a ballpoint pen or screwdriver. This type of contact may result in a scratched picture tube.
- Clean the cabinet, panel and controls with a soft cloth lightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent, such as alcohol or benzene.


## Transportation

When you transport this monitor for repair or shipment, use the original carton and packing materials.


### Use of the tilt-swivel

This monitor can be adjusted within the angles shown below. To turn the monitor vertically or horizontally, hold it at the bottom with both hands.

GDM-F400



GDM-F500




# SECTION 1

## GENERAL

### Identifying parts and controls

See the pages in parentheses for further details. GDM-F500 is used for illustration purposes throughout this manual.

Front



**[1] RESET button (page 14)**

This button resets the adjustments to the factory settings.

**[2] ASC (auto sizing and centering) button (page 9)**

This button automatically adjusts the size and centering of the picture.

**[3] INPUT button and HD 15/BNC indicators (page 9)**

This button selects the HD15 or BNC video input signal. The input signal and corresponding input indicator change each time you press this button.

**[4] Joystick (page 11)**

The joystick is used to display the menu and make adjustments to the monitor, including brightness and contrast adjustments.

**[5] (power) switch and indicator (pages 7, 15, 18)**

This button turns the monitor on and off. The power indicator lights up in green when the monitor is turned on, and either flashes in green and orange, or lights up in orange when the monitor is in power saving mode.

**[6] AC IN connector (page 7)**

This connector provides AC power to the monitor.


**[7] USB (universal serial bus) upstream connector (page 8)**

Use this connector to link the monitor to a USB compliant computer.

**[8] USB (universal serial bus) downstream connectors (page 8)**

Use these connectors to link USB peripheral devices to the monitor.

Rear



**[9] Video input 1 connector (HD15) (page 6)**

This connector inputs RGB video signals (0.700 Vp-p, positive) and sync signals.



**Pin No.      Signal**

1	Red
2	Green (Composite Sync on Green)
3	Blue
4	ID (Ground)
5	DDC Ground*
6	Red Ground
7	Green Ground
8	Blue Ground
9	DDC + 5V*
10	Ground
11	ID (Ground)
12	Bi-Directional Data (SDA)*
13	H. Sync
14	V. Sync
15	Data Clock (SCL)*

\* DDC (Display Data Channel) is a standard of VESA.

**[10] Video input 2 connector (BNC) (page 6)**

This connector inputs RGB video signals (0.700 Vp-p, positive) and sync signals.

EN

## Setup


Before using your monitor, check that the following accessories are included in your carton:

- Power cord (1)
- HD15 video signal cable (1)
- USB cable (1)
- Macintosh adapter (1)
- Windows Monitor Information Disk (1)
- Warranty card (1)
- Notes on cleaning the screen's surface (1)
- This instruction manual (1)

### Step 1: Connect your monitor to your computer

Turn off the monitor and computer before connecting.

#### ■ Connecting to an IBM PC/AT or compatible computer




#### If your PC system is not compatible with Plug & Play (DDC2AB or DDC2B+)

This monitor uses the No.9 pin in the video signal connector for Plug & Play (DDC2AB or DDC2B+) compatibility. See page 5 for the location of the No.9 pin.

- If your computer accepts the No.9 pin, use the supplied HD15 video signal cable.
- If your computer does not accept the No.9 pin, please consult your dealer for advice on obtaining an HD15 adapter.


#### ■ Connecting to a Macintosh or compatible computer

Use the supplied Macintosh adapter.



- \* Connect the supplied Macintosh adapter to the computer before connecting the cable. This adapter is compatible with Macintosh LC, Performa, Quadra, Power Macintosh and Power Macintosh G3 series computers. Macintosh II series and some older versions of PowerBook models may need an adapter with micro switches (not supplied).

#### ■ Connecting to the five BNC connectors




- \* Connect the cables from left to right in the following order: Red-Green-Blue-HD-VD.

#### Notes

- Do not touch the pins of the video cable connector as this might bend the pins.
- Plug & Play (DDC) does not apply to the five BNC connectors. If you want to use Plug & Play, connect your computer to the HD15 connector using the supplied video signal cable.

### Step 2: Connect the power cord

With the monitor and computer switched off, first connect the power cord to the monitor, then connect it to a power outlet.



### Step 3: Turn on the monitor and computer

First turn on the monitor, then turn on the computer.



The installation of your monitor is complete.  
If necessary, use the monitor's controls to adjust the picture.

#### If no picture appears on your screen

- Check that the monitor is correctly connected to the computer.
- If NO INPUT SIGNAL appears on the screen, try changing the input signal (page 9), and confirm that your computer's graphic board is completely seated in the correct bus slot.
- If you are replacing an old monitor with this model and OUT OF SCAN RANGE appears on the screen, reconnect the old monitor. Then adjust the computer's graphic board so that the horizontal frequency is between 30 – 107 kHz (GDM-F400) or 30 – 121 kHz (GDM-F500), and the vertical frequency is between 48 – 160 Hz.

For more information about the on-screen messages, see "Trouble symptoms and remedies" on page 16.

EN

#### For customers using Windows 95/98

To maximize the potential of your monitor, install the new model information file from the supplied Windows Monitor Information Disk onto your PC.

This monitor complies with the "VESA DDC" Plug & Play standard. If your PC/graphics board complies with DDC, select "Plug & Play Monitor (VESA DDC)" or this monitor's model name as the monitor type in the "Control Panel" of Windows 95/98. If your PC/graphics board has difficulty communicating with this monitor, load the Windows Monitor Information Disk and select this monitor's model name as the monitor type.

#### For customers using Windows NT4.0

Monitor setup in Windows NT4.0 is different from Windows 95/98 and does not involve the selection of monitor type. Refer to the Windows NT4.0 instruction manual for further details on adjusting the resolution, refresh rate, and number of colors.


#### Adjusting the monitor's resolution and color number

Adjust the monitor's resolution and color number by referring to your computer's instruction manual. The color number may vary according to your computer or video board. The color palette setting and the actual number of colors are as follows:

- High Color (16 bit) → 65,536 colors
- True Color (24 bit) → about 16.77 million colors  
In true color mode (24 bit), speed may be slower.

## Connecting Universal Serial Bus (USB) compliant peripherals

Your monitor has one upstream and four downstream USB connectors. They provide a fast and easy way to connect USB compliant peripheral devices (such as keyboards, mice, printers and scanners) to your computer using a standardized USB cable. To use your monitor as a hub for your peripheral devices, connect the USBs as illustrated below.



1 Turn on the monitor and computer.

2 Connect your computer to the square upstream connector using the supplied USB cable.

### For customers using Windows

If a message appears on your screen, follow the on-screen instructions and select Generic USB Hub as the default setting.

3 Connect your USB compliant peripheral devices to the rectangular downstream USB connectors.

### Notes


- Not all computers and /or operating systems support USB configurations. Check your computer's instruction manual to see if you can connect USB devices.
- In most cases, USB driver software needs to be installed on the host computer. Refer to the peripheral device's instruction manual for further details.
- The monitor functions as a USB hub as long as the monitor is either "on" or in power saving mode.
- If you connect a keyboard or mouse to the USB connectors and then boot your computer for the first time, the peripheral devices may not function. First connect the keyboard and mouse directly to the computer and set up the USB compliant devices. Then connect them to this monitor.
- Do not lean on the monitor when plugging in the USB cables. The monitor may suddenly shift and cause injury.

## Selecting the on-screen menu language (LANG)


English, French, German, Spanish, Italian, and Japanese versions of the on-screen menus are available. The default setting is English.

1 Press the joystick

See page 11 for more information on using the joystick.



2 Move the joystick to highlight LANG and press the joystick again.



3 Move the joystick up or down to select a language and press the joystick again.

- ENGLISH
- FRANÇAIS: French
- DEUTSCH: German
- ESPAÑOL: Spanish
- ITALIANO: Italian
- 日本語: Japanese

### To close the menu

Press the joystick once to return to the main menu, and twice to return to normal viewing. If no buttons are pressed, the menu closes automatically after about 30 seconds.

### To reset to English

Press the RESET button while the LANGUAGE menu is displayed on the screen.

## Selecting the input signal

You can connect two computers to this monitor using the HD15 and BNC connectors. To switch between the two computers, use the INPUT button.

Press the INPUT button.

The input signal and corresponding input indicator change each time you press this button.



### Notes

- If no signal is input to the selected connector, the monitor automatically switches to the other connector.
- If you restart the computer you want to view, or that computer is in power saving mode, the monitor may automatically switch to the other connector's signal. If this happens, manually select the desired signal using the INPUT button.

## Automatically sizing and centering the picture

You can easily adjust the picture to fill the screen by pressing the ASC (auto sizing and centering) button.

Press the ASC button.

The picture automatically fills the screen.



### Notes

- This function is intended for use with a computer running Windows or similar graphic user interface software that provides a full-screen picture. It may not work properly if the background color is dark or if the input picture does not fill the screen to the edges (such as an MS-DOS prompt).
- Pictures with an aspect ratio of 5:4 (resolution: 1280 × 1024, 1800 × 1440<sup>\*</sup>) are displayed at their actual resolution and do not fill the screen to the edges.
- The screen may go blank for a few seconds when the ASC button is pressed. This is not a malfunction.

\* GDM-F500 only


EN

## Customizing Your Monitor

You can make numerous adjustments to your monitor using the on-screen menu.


### Navigating the menu

Press the joystick to display the main MENU on your screen. See page 11 for more information on using the joystick.




Use the joystick to select one of the following menus.


- ① **CENTER** (page 11)  
Select the CENTER menu to adjust the picture's centering.




- ② **SIZE** (page 11)  
Select the SIZE menu to adjust the picture's horizontal and vertical size.




- ③ **GEOM** (page 12)  
Select the GEOM menu to adjust the picture's rotation and shape.



- ④ **ZOOM** (page 12)  
Select the ZOOM menu to enlarge or reduce the picture.




- ⑤ **COLOR** (page 12)  
Select the COLOR menu to adjust the picture's color temperature. You can use this to match the monitor's colors to a printed picture's colors.



### ⑥ SCREEN (page 13)

Select the SCREEN menu to adjust the picture's quality. You can adjust the vertical and horizontal convergence, landing, and moire cancellation effect.



### ⑦ LANG (page 8)


Select LANG to choose the on-screen menu's language.



### ⑧ OPTION (page 14)


Select OPTION to adjust the monitor's options. The options include:

- degaussing the screen
- changing the on-screen menu position
- changing the power saving delay time
- locking the controls



### ⑨ EXIT


Select EXIT to close the menu.



### Using the joystick

#### 1 Select the menu you want to adjust.

Move the joystick up, down, left, or right to highlight the desired menu. Press the joystick to select the menu item.



#### 2 Adjust the menu.

Move the joystick up, down, left, or right to make the adjustment.



#### 3 Close the menu.

Press the joystick once to return to the main menu, and twice to return to normal viewing. If no buttons are pressed, the menu closes automatically after about 30 seconds.



### Resetting the adjustments

Press the RESET button. See page 14 for more information on resetting the adjustments.




## Adjusting the brightness and contrast

Brightness and contrast adjustments are made using a separate BRIGHTNESS/CONTRAST menu.

These settings are stored in memory for all input signals.

#### 1 Move the joystick in any direction.

The BRIGHTNESS/CONTRAST menu appears on the screen.



the horizontal and vertical frequencies of the current input signal

#### 2 Move the joystick up or down to adjust the brightness (◎), and left or right to adjust the contrast (◎).

The menu automatically disappears after about 3 seconds.

EN

## Adjusting the centering of the picture (CENTER)

This setting is stored in memory for the current input signal.

#### 1 Press the joystick.

The main MENU appears on the screen.

#### 2 Move the joystick to highlight ◎ CENTER and press the joystick again.

The CENTER menu appears on the screen.

#### 3 Move the joystick up or down to adjust the vertical centering, and left or right to adjust the horizontal centering.

## Adjusting the size of the picture (SIZE)

This setting is stored in memory for the current input signal.

#### 1 Press the joystick.

The main MENU appears on the screen.

#### 2 Move the joystick to highlight ◎ SIZE and press the joystick again.

The SIZE menu appears on the screen.

#### 3 Move the joystick up or down to adjust the vertical size, and left or right to adjust the horizontal size.

## Adjusting the shape of the picture (GEOM)

The GEOM settings allow you to adjust the rotation and shape of the picture. The rotation setting is stored in memory for all input signals. All other settings are stored in memory for the current input signal.

- 1 Press the joystick.**  
The main MENU appears on the screen.
- 2 Move the joystick to highlight  GEOM and press the joystick again.**  
The GEOMETRY menu appears on the screen.
- 3 First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.**

Select	To
<input type="checkbox"/> ROTATION	rotate the picture
<input checked="" type="checkbox"/> PINCUSHION	expand or contract the picture sides
<input type="checkbox"/> PIN BALANCE	shift the picture sides to the left or right
<input type="checkbox"/> KEYSTONE	adjust the picture width at the top of the screen
<input type="checkbox"/> KEY BALANCE	shift the picture to the left or right at the top of the screen

## Enlarging or reducing the picture (ZOOM)

This setting is stored in memory for the current input signal.

- 1 Press the joystick.**  
The main MENU appears on the screen.
- 2 Move the joystick to highlight  ZOOM and press the joystick again.**  
The ZOOM menu appears on the screen.
- 3 Move the joystick left or right to enlarge or reduce the picture.**

### Note

Adjustment stops when either the horizontal or vertical size reaches its maximum or minimum value.

## Adjusting the color of the picture (COLOR)


The COLOR settings allow you to adjust the picture's color temperature by changing the color level of the white color field. Colors appear reddish if the temperature is low, and bluish if the temperature is high. This adjustment is useful for matching the monitor's colors to a printed picture's colors.

This setting is stored in memory for all input signals.

- 1 Press the joystick.**  
The main MENU appears on the screen.
- 2 Move the joystick to highlight  COLOR and press the joystick again.**  
The COLOR menu appears on the screen.
- 3 Move the joystick left or right to select a color temperature.**

The preset color temperatures are 5000K, 6500K, and 9300K. Since the default setting is 9300K, the whites will change from a bluish hue to a reddish hue as the temperature is lowered to 6500K and 5000K.

- 4 If necessary, fine tune the color temperature.**  
First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.



- [1] Adjusting the BIAS (black level)**  
This changes the brightness of both the dark and light areas of an image.
- [2] Adjusting the GAIN (white level)**  
This changes the contrast of just the light areas of an image.

You can adjust the R(Red), G(Green), and B(Blue) component of the input signal when making changes to items [1] and [2].

If you fine tune the color temperature, the new color settings are stored in memory for each of the three color temperatures and item [3] of the on-screen menu changes as follows:

- [5000K] → [1]
- [6500K] → [2]
- [9300K] → [3]

## Adjusting the quality of the picture (SCREEN)

The SCREEN settings allow you to adjust the quality of the picture by controlling the convergence, moire, and landing.

- If you see red or blue shadows around letters or lines, adjust the convergence.
- If elliptical or wavy patterns appear on the screen, cancel the moire.
- If the color is irregular at the corners of the screen, adjust the landing.

The CANCEL MOIRE and MOIRE ADJUST settings are stored in memory for the current input signal. All other settings are stored in memory for all input signals.

- 1 Press the joystick.**  
The main MENU appears on the screen.
- 2 Move the joystick to highlight  SCREEN and press the joystick again.**  
The SCREEN menu appears on the screen.
- 3 First move the joystick up or down to select the desired adjustment item. Then move the joystick left or right to make the adjustment.**

Select	To
<input checked="" type="checkbox"/> H CONVERGENCE	horizontally shift red or blue shadows
<input type="checkbox"/> V CONVERGENCE	vertically shift red or blue shadows
<input checked="" type="checkbox"/> TOP V CONVER TOP	vertically shift red or blue shadows at the top of the screen
<input checked="" type="checkbox"/> BOT V CONVER BOT	vertically shift red or blue shadows at the bottom of the screen
<input type="checkbox"/> LANDING	select one of the four corners of the screen <input type="checkbox"/> :top left <input type="checkbox"/> :top right <input type="checkbox"/> :bottom left <input type="checkbox"/> :bottom right
<input type="checkbox"/> ADJ LANDING ADJUST	reduce any irregularities in the color of the corner selected in LANDING to a minimum

Select	To
<input type="checkbox"/> CANCEL MOIRE*	turn the moire cancellation function ON or OFF <input checked="" type="checkbox"/> ADJ (MOIRE ADJUST) appears in the menu when you select ON
<input checked="" type="checkbox"/> ADJ MOIRE ADJUST	adjust the degree of moire cancellation until the moire is at a minimum

\* Moire is a type of natural interference which produces soft, wavy lines on your screen. It may appear due to interference between the pattern of the picture on the screen and the phosphor pitch pattern of the monitor.

Example of moire



### Note

The picture may become fuzzy when CANCEL MOIRE is set to ON.

EN

## Additional settings (OPTION)

You can manually degauss (demagnetize) the monitor, change the menu position, set the power saving delay time, and lock the controls.

### 1 Press the joystick.

The main MENU appears on the screen.

### 2 Move the joystick to highlight OPTION and press the joystick again.

The OPTION menu appears on the screen.

### 3 Move the joystick to highlight the desired adjustment item.

Adjust the selected item according to the following instructions.

#### Degaussing the screen

The monitor is automatically demagnetized when the power is turned on.

#### To manually degauss the monitor, first move the joystick up or down to select (MANUAL DEGAUSS). Then move the joystick to the right.

The screen is degaussed for about 3 seconds. If a second degauss cycle is needed, allow a minimum interval of 20 minutes for the best result.

#### Changing the menu's position.

Change the menu's position if it is blocking an image on the screen.

#### To change the menu's on-screen position, first move the joystick up or down to select (OSD H POSITION) for horizontal adjustment, or (OSD V POSITION) for vertical adjustment. Then move the joystick to the left or right to shift the on-screen menu.

#### Changing the power saving delay time.

#### To adjust the time it takes to enter the power saving mode, first move the joystick up or down to select (PWR SAVE DELAY). Then move the joystick to the left or right to select the desired time.

If you select OFF, the monitor does not enter power saving mode. See page 15 for more information about the monitor's power saving capabilities.

#### Locking the controls.

#### To protect adjustment data by locking the controls, first move the joystick up or down to select (CONTROL LOCK). Then move the joystick to the right to select LOCK.

Only the (power) switch, EXIT, and (CONTROL LOCK) of the OPTION menu will operate. If any other items are selected, the mark appears on the screen.

#### To cancel the control lock

Repeat the procedure above and set (CONTROL LOCK) to UNLOCK.

## Resetting the adjustments

This monitor has the following three reset methods. Use the RESET button to reset the adjustments.



### Resetting a single adjustment item

Use the joystick to select the adjustment item you want to reset, and press the RESET button.

### Resetting all of the adjustment data for the current input signal

Press the RESET button when no menu is displayed on the screen. Note that the following items are not reset by this method:

- on-screen menu language (page 8)
- on-screen menu position (page 14)
- power saving delay time (page 14)
- control lock (page 14)

### Resetting all of the adjustment data for all input signals

Press and hold the reset button for more than two seconds.

#### Note

The RESET button does not function when (CONTROL LOCK) is set to LOCK.

## Technical Features

### Preset and user modes

When the monitor receives an input signal, it automatically matches the signal to one of the factory preset modes stored in the monitor's memory to provide a high quality picture at the center of the screen. (See page i for a list of the factory preset modes.) For input signals that do not match one of the factory preset modes, the digital Multiscan technology of this monitor ensures that a clear picture appears on the screen for any timing in the monitor's frequency range (horizontal: 30 – 107 kHz (GDM-F400) or 30 – 121 kHz (GDM-F500), vertical: 48 – 160 Hz). If the picture is adjusted, the adjustment data is stored as a user mode and automatically recalled whenever the same input signal is received.

#### Note for Windows users

For Windows users, check your video board manual or the utility program which comes with your graphic board and select the highest available refresh rate to maximize monitor performance.

### Power saving function

This monitor meets the power-saving guidelines set by VESA, ENERGY STAR, and NUTEK. If the monitor is connected to a computer or video graphics board that is DPMS (Display Power Management Signaling) compliant, the monitor will automatically reduce power consumption in three stages as shown below.

Power mode	Power consumption*	(power) indicator
normal operation	≤ 160 W (GDM-F500) ≤ 140 W (GDM-F400)	green
1 standby	≤ 100 W (GDM-F500) ≤ 80 W (GDM-F400)	green and orange alternate
2 suspend	≤ 15 W (GDM-F500) ≤ 10 W (GDM-F400)	green and orange alternate
3 active off**	≤ 1 W (GDM-F500) ≤ 3 W (GDM-F400)	orange
power off	0 W	off

\* Figures reflect power consumption when no USB compatible peripherals are connected to the monitor.

\*\* When your computer enters the "active off" mode, the input signal is cut and NO INPUT SIGNAL appears on the screen. After the time set in "Changing the power saving delay time." (page 14) has elapsed, the monitor enters the power saving mode.

#### To change the power saving delay time


See page 14.

## Troubleshooting

Before contacting technical support, refer to this section.

### If thin lines appear on your screen (damper wires)


The lines you are experiencing on your screen are normal for the Trinitron monitor and are not a malfunction. These are shadows from the damper wires used to stabilize the aperture grille and are most noticeable when the screen's background is light (usually white). The aperture grille is the essential element that makes a Trinitron picture tube unique by allowing more light to reach the screen, resulting in a brighter, more detailed picture.



### On-screen messages

EN

If there is something wrong with the input signal, one of the following messages appears on the screen. To solve the problem, see "Trouble symptoms and remedies" on page 16.



#### 1 The input signal condition

**OUT OF SCAN RANGE** indicates that the input signal is not supported by the monitor's specifications.

#### NO INPUT SIGNAL

indicates that no signal is input, or that no signal is input from the selected connector (HD15 or BNC).

#### 2 The connector indicator

This message indicates which connector is receiving the wrong signal. If there is something wrong with the signal from both connectors, HD15 and BNC are displayed alternately.

## Trouble symptoms and remedies

If the problem is caused by the connected computer or other equipment, please refer to the connected equipment's instruction manual. Use the self-diagnosis function (page 18) if the following recommendations do not resolve the problem.


Symptom	Check these items
<b>No picture</b>	<ul style="list-style-type: none"> <li>If the <math>\odot</math> (power) indicator is not lit           <ul style="list-style-type: none"> <li>Check that the power cord is properly connected.</li> <li>Check that the <math>\odot</math> (power) switch is in the "on" position.</li> </ul> </li> <li>If the NO INPUT SIGNAL message appears on the screen, or if the <math>\odot</math> (power) indicator is either orange or alternating between green and orange           <ul style="list-style-type: none"> <li>Check that the video signal cable is properly connected and all plugs are firmly seated in their sockets. If you are using the five BNC connectors, connect them in the correct order (from left to right: Red-Green-Blue-HD-VD) (page 6).</li> <li>Check that the input select setting is correct (page 9).</li> <li>Check that the HD15 video input connector's pins are not bent or pushed in.</li> </ul> </li> </ul> <p><b>■Problems caused by the connected computer or other equipment</b></p> <ul style="list-style-type: none"> <li>The computer is in power saving mode. Try pressing any key on the computer keyboard.</li> <li>Check that the computer's power is "on."</li> <li>Check that the graphic board is completely seated in the proper bus slot.</li> </ul>
If the OUT OF SCAN RANGE message appears on the screen	<p><b>■Problems caused by the connected computer or other equipment</b></p> <ul style="list-style-type: none"> <li>Check that the video frequency range is within that specified for the monitor. If you replaced an old monitor with this monitor, reconnect the old monitor and adjust the frequency range to the following.</li> </ul> <p>Horizontal: 30 – 107 kHz (GDM-F400), 30 – 121 kHz (GDM-F500) Vertical: 48 – 160 Hz</p>
If no message is displayed and the $\odot$ (power) indicator is green or flashing orange	<ul style="list-style-type: none"> <li>Use the Self-diagnosis function (page 18).</li> </ul>
If using Windows 95/98	<ul style="list-style-type: none"> <li>If you replaced an old monitor with this monitor, reconnect the old monitor and do the following. Install the Windows Monitor Information Disk (page 7) and select this monitor ("GDM-F400" or "GDM-F500") from among the Sony monitors in the Windows 95/98 monitor selection screen. If you choose to select "Plug and Play," connect the monitor to the computer with the HD15 video signal cable. You cannot use the five BNC connectors.</li> </ul>
If using a Macintosh system	<ul style="list-style-type: none"> <li>Check that the Macintosh adapter and the video signal cable are properly connected (page 6).</li> </ul>
<b>Picture flickers, bounces, oscillates, or is scrambled</b>	<ul style="list-style-type: none"> <li>Isolate and eliminate any potential sources of electric or magnetic fields such as other monitors, laser printers, electric fans, fluorescent lighting, or televisions.</li> <li>Move the monitor away from power lines or place a magnetic shield near the monitor.</li> <li>Try plugging the monitor into a different AC outlet, preferably on a different circuit.</li> <li>Try turning the monitor 90° to the left or right.</li> </ul> <p><b>■Problems caused by the connected computer or other equipment</b></p> <ul style="list-style-type: none"> <li>Check your graphics board manual for the proper monitor setting.</li> <li>Confirm that the graphics mode (VESA, Macintosh 21" Color, etc.) and the frequency of the input signal are supported by this monitor (page i). Even if the frequency is within the proper range, some video boards may have a sync pulse that is too narrow for the monitor to sync correctly.</li> <li>Adjust the computer's refresh rate (vertical frequency) to obtain the best possible picture.</li> </ul>
<b>Picture is fuzzy</b>	<ul style="list-style-type: none"> <li>Adjust the brightness and contrast (page 11).</li> <li>Degauss the monitor* (page 14).</li> <li>If CANCEL MOIRE is ON, the picture may become fuzzy. Decrease the moire cancellation effect or set CANCEL MOIRE to OFF (page 13).</li> </ul>

Symptom	Check these items
<b>Picture is ghosting</b>	<ul style="list-style-type: none"> <li>Eliminate the use of video cable extensions and/or video switch boxes.</li> <li>Check that all plugs are firmly seated in their sockets.</li> </ul>
<b>Picture is not centered or sized properly</b>	<ul style="list-style-type: none"> <li>Press the ASC button (page 9).</li> <li>Adjust the size (page 11) or centering (page 11). Note that some video modes do not fill the screen to the edges.</li> </ul>
<b>Edges of the image are curved</b>	<ul style="list-style-type: none"> <li>Adjust the geometry (page 12).</li> </ul>
<b>Wavy or elliptical pattern (moire) is visible</b>	<p><b>■Problems caused by the connected computer or other equipment</b></p> <ul style="list-style-type: none"> <li>Change your desktop pattern.</li> </ul>
<b>Color is not uniform</b>	<ul style="list-style-type: none"> <li>Degauss the monitor* (page 14). If you place equipment that generates a magnetic field, such as a speaker, near the monitor, or if you change the direction the monitor faces, color may lose uniformity.</li> <li>Adjust the landing (page 13).</li> </ul>
<b>White does not look white</b>	<ul style="list-style-type: none"> <li>Adjust the color temperature (page 12).</li> <li>Check that the five BNC connectors are connected in the correct order (from left to right: Red-Green-Blue-HD-VD) (page 6).</li> </ul>
<b>Letters and lines show red or blue shadows at the edges</b>	<ul style="list-style-type: none"> <li>Adjust the convergence (page 13).</li> </ul>
<b>Monitor buttons do not operate</b>	<ul style="list-style-type: none"> <li>If the control lock is set to LOCK, set it to UNLOCK (page 14).</li> </ul>
<b>USB peripherals do not function</b>	<ul style="list-style-type: none"> <li>Check that the appropriate USB connectors are securely connected (page 8).</li> <li>Check that the <math>\odot</math> (power) switch is in the "on" position.</li> </ul> <p><b>■Problems caused by the connected computer or other equipment</b></p> <ul style="list-style-type: none"> <li>Check that the power of any self-powered USB compliant peripheral devices is "on."</li> <li>Install the latest version of the device driver on your computer. Contact your device's manufacturer for information about the appropriate device driver.</li> <li>If your USB compliant keyboard or mouse does not function, connect them directly to your computer, reboot your computer, and make any necessary adjustments to the USB settings. Then reconnect the keyboard or mouse to the monitor.</li> <li>For customers using Windows 95           <ol style="list-style-type: none"> <li>Right-click on My Computer and select Properties.</li> <li>Click on the Device Manager tab. Scroll down and select Universal Serial Bus Controller.</li> <li>If Universal Serial Bus Controller does not appear, you need to load a USB supplement disk. Contact your computer's manufacturer for more information about obtaining a USB supplement disk.</li> <li>Select Generic USB Device from the USB controller list and click on Properties.</li> <li>If there is a check in the box next to "Disable in this hardware profile," remove the check.</li> <li>Click on Refresh.</li> </ol> </li> </ul>
<b>A hum is heard right after the power is turned on</b>	<ul style="list-style-type: none"> <li>This is the sound of the auto-degauss cycle. When the power is turned on, the monitor is automatically degaussed for three seconds.</li> </ul>

\* If a second degauss cycle is needed, allow a minimum interval of 20 minutes for the best result. A humming noise may be heard, but this is not a malfunction.



**Displaying this monitor's name, serial number, and date of manufacture.**


While the monitor is receiving a video signal, press and hold the joystick for more than three seconds to display this monitor's information box.




EN

## Self-diagnosis function

This monitor is equipped with a self-diagnosis function. If there is a problem with your monitor or computer(s), the screen will go blank and the  (power) indicator will either light up green or flash orange. If the  (power) indicator is lit in orange, the computer is in power saving mode. Try pressing any key on the keyboard.



### If the (power) indicator is green


- 1 Remove any plugs from the video input 1 and 2 connectors, or turn off the connected computer(s).
- 2 Press the  (power) button to turn the monitor off and on.
- 3 Move the joystick to the right for 2 seconds before the monitor enters power saving mode.






If all four color bars appear (white, red, green, blue), the monitor is working properly. Reconnect the video input cables and check the condition of your computer(s).

If the color bars do not appear, there is a potential monitor failure. Inform your authorized Sony dealer of the monitor's condition.

### If the (power) indicator is flashing orange

Press the  (power) button to turn the monitor off and on.

If the  (power) indicator lights up green, the monitor is working properly.

If the  (power) indicator is still flashing, there is a potential monitor failure. Count the number of seconds between orange flashes of the  (power) indicator and inform your authorized Sony dealer of the monitor's condition. Be sure to note the model name and serial number of your monitor. Also note the make and model of your computer and video board.

## Specifications

### GDM-F400

CRT	0.22 mm aperture grille pitch 19 inches measured diagonally 90-degree deflection FD Trinitron
Viewable image size	Approx. 364.8 × 273.6 mm (w/h) (14 3/8 × 10 7/8 inches) 18.0" viewing image
Resolution	Horizontal: Max. 1600 dots Vertical: Max. 1200 lines
Standard image area	Approx. 352 × 264 mm (w/h) (13 7/8 × 10 1/2 inches) or Approx. 330 × 264 mm (w/h) (13 × 10 1/2 inches)
Deflection frequency*	Horizontal: 30 to 107 kHz Vertical: 48 to 160 Hz
AC input voltage/current	100 to 240 V, 50 – 60 Hz, 1.8 – 1.0 A
Power consumption	Max. 140 W (with no USB devices connected)
Dimensions	Approx. 444 × 476 × 455 mm (w/h/d) (17 1/2 × 18 7/8 × 18 inches)
Mass	Approx. 28 kg (61 lb 12 oz)
Plug and Play	DDC1/DDC2B/DDC2Bi/DDC2B+
Supplied accessories	See page 6

### GDM-F500

CRT	0.22 mm aperture grille pitch 21 inches measured diagonally 90-degree deflection FD Trinitron
Viewable image size	Approx. 403.8 × 302.2 mm (w/h) (16 × 12 inches) 19.8" viewing image
Resolution	Horizontal: Max. 1800 dots Vertical: Max. 1440 lines
Standard image area	Approx. 388 × 291 mm (w/h) (15 3/8 × 11 1/2 inches) or Approx. 364 × 291 mm (w/h) (14 3/8 × 11 1/2 inches)
Deflection frequency*	Horizontal: 30 to 121 kHz Vertical: 48 to 160 Hz
AC input voltage/current	100 to 240 V, 50 – 60 Hz, 2.0 – 1.0 A
Power consumption	Max. 160 W (with no USB devices connected)
Dimensions	Approx. 502 × 511 × 486.3 mm (w/h/d) (19 7/8 × 20 1/8 × 19 1/4 inches)
Mass	Approx. 34 kg (74 lb 15 oz)
Plug and Play	DDC1/DDC2B/DDC2AB/DDC2B+
Supplied accessories	See page 6


- \* Recommended horizontal and vertical timing condition
- Horizontal sync width duty should be more than 4.8% of total horizontal time or 0.8  $\mu$ s, whichever is larger.
  - Horizontal blanking width should be more than 2.5  $\mu$ sec.
  - Vertical blanking width should be more than 450  $\mu$ sec.

Design and specifications are subject to change without notice.


## SECTION 2

### DISASSEMBLY


#### 2-1. CABINET REMOVAL




#### 2-2. A BOARD REMOVAL




## 2-3. AC INLET AND REAR SHIELD REMOVAL




## 2-4. D BOARD REMOVAL




## 2-5. SERVICE POSITION



## 2-6. US BOARD REMOVAL




## 2-7. BEZEL AND H BOARD REMOVAL



## 2-8. PICTURE TUBE REMOVAL


- Remove the bezel. (Refer to 2-7.)




### • REMOVAL OF ANODE-CAP

NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon painted on the CRT, after removing the anode.


### • REMOVING PROCEDURES



- ① Turn up one side of the rubber cap in the direction indicated by the arrow ④.




- ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow ⑤.




- ③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ⑥.

### • HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- ③ Don't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.



## 2-9. HARNESS LOCATION



## SECTION 3

### SAFETY RELATED ADJUSTMENT

When replacing or repairing the shown below table, the following operational checks must be performed as a safety precaution against X-rays emissions from the unit.

	Part Replaced (☒)
HV ADJ	RV901

	Part Replaced (☒)
HV Regulator Circuit Check	D Board T901(FBT), IC901, R903, R922, RV901 • Mounted D board
HV Protector Circuit Check	D Board T901(FBT), R927, R920, C923, D913, D916, R935, R936 • Mounted D board
Beam Current Protector Circuit Check	D Board R933, R932, R934, R923, R928, R939, R918, R053, IC901, D918, D901, D902, T901(FBT) • Mounted D board

\* Confirm one minute later turning on the power.

#### a) HV Protector Circuit Check

- 1) Confirm that the voltage between cathode of D913 on G board and GND is more than 25.5 V DC.
- 2) Confirm that the HV protector circuit works and TV Raster disappears when apply the voltage less than 34.2 V DC between cathode of D913 and GND using an external DC power supply.

#### b) Beam Current Protector Circuit Check-1

##### (Hardware)

Apply 4.7 V DC to the connection point of R932 and R933. Connect constant current source to the FBT ⑪ pin (-) on the D board and to the GND, then confirm that when 2.0 mA is flown, the beam protector circuit operates and high voltage value drops over 1.0 kV.

#### c) Beam Current Protector Circuit Check-2

##### (Software)

Connect constant current source to the FBT ⑪ pin (-) on the D board and to the GND, then confirm that when 1.7 mA is flown, the beam protector circuit operates and IIV value (CRT anode voltage) is below 1.0 kVDC.

Or, confirm that the raster disappears.

## SECTION 4

### ADJUSTMENTS

#### • Landing Rough Adjustment

1. Enter the full white signal. (or the full black dots signal).
2. Adjust the contrast to the maximum.
3. Make the screen monogreen.

Note: Off the outputs from R ch and B ch of SG.

4. Reverse the DY, and adjust coarsely the purity magnet so that a green raster positions in the center of screen.
5. Adjust the tilt of DY, and fix lightly with a clamp.

Note: "TILT" shall be set at 128.

#### <Specifications>

Adjust so that the green is within the specification given right.  
Adjust target : within  $\pm 1$

$0 \pm 3$	$0 \pm 7.5$	$0 \pm 3$
$0 \pm 5$	$0 \pm 5$	$0 \pm 5$
$0 \pm 3$	$0 \pm 7.5$	$0 \pm 3$

The red and blue must be within the specification given right with respect to the green.

$\pm 6$	$\pm 6$	$\pm 6$
$\pm 6$	$\pm 4$	$\pm 6$
$\pm 6$	$\pm 6$	$\pm 6$


A difference between red and blue must be within the specification given right.

10	10	10
10	7	10
10	10	10

\* Adjustment and measurement should be made at the points one inch inside the fluorescent screen.


7. Insert wedges to make the DY neck stand upright without moving it.  
At this time, without shaking the DY, firmly insert the wedges.
8. Adjust vertical swing with the vertical pin, and adjust horizontal swing so that horizontal keystone and V TILT become optimum, then fix with four wedges.  
In Such a case, insert wedges tightly to eliminate a play of DY.

#### <How to fix with wedges>



"a" and "b" must be equal, and "c" and "d" must be almost equal.

#### <How to drive in wedges>



Apply an adhesive to the top wedge only. Apply it to both sides of wedge and inside of DY.

- Note:
- (1) Hand degauss must be used on stand-by or power-off condition.  
This model has an automatic earth magnetism correction function by using an earth magnetism sensor and a LCC coil. When using a hand degauss while monitor (LCC coil) is being operated, it sometimes gets magnetized, and the system may not work properly as a result.
  - (2) Adjust in a non-magnetic field. BV=24uT.
  - (3) If adjusting in a magnetic fields, add the shift from the non-magnetic field in your estimation.
  4. Attach the wobbling coil to the designated part of the CRT neck.
  5. Attach the sensor of the landing adjustment unit on the CRT surface.
  6. Adjust the DY position and purity, and the DY tilt, and landing of the center and 4 corners with the landing checker.
    - Moving the "LCC\_NS", adjust the landing at the Y end.
    - Adjust the landing by moving "LCC NS", "LCC LT", "LCC LB", "LCC RT" and "LCC RB". However, the register adjustment must be limited within the following range.


"LCC NS"	$128 \pm 20$
"LCC LT", "LCC LB", "LCC RT", "LCC RB"	$128 \pm 30$

After adjustment, save the service data.

9. Check the landing of each corner, and if it does not satisfy the specification, paste a Disk-Mg onto the funnel and adjust.
  - (1) Do not paste more than two magnets on one corner.
  - (2) Magnets will be placed in a range 80 ~ 100 mm from the DY along diagonal lines.
  - (3) After placing magnets, absolutely hand degauss and check the results. (Hand degauss must be used on stand-by or power-off condition.)
10. Remove the sensor and wobbling coil.
11. Switch the signal to R.G.B., and check that each color is pure.
12. Check that the DY is not tilting, and fix the purity Mg with a white pen. Fix wedges with RTV.

# GDM-F400/F400T9


Connect the communication cable of the computer to the connector located on the D board or US board on the monitor. Run the service software and then follow the instruction.




\*The parts above (① ~ ③) are necessary for DAS adjustment.

## • Convergence Rough Adjustment


- (1) Receive an image of the white crosshatch signals (white lines on black).
- (2) Place the protrusions of the 6-fold poles magnet attached to the CRT neck upon each other. (Fig. 1)
- (3) Make rough adjustment of the H and V direction convergence by using 4-fold poles magnet.



\* Set so that the protruding parts of the 2 magnet rings agree with each other.




## • Convergence Specification



## • White Balance Adjustment Specification


1. COLOR INDEX=3  
 $x=0.283 \pm 0.005$   
 $y=0.298 \pm 0.005$   
(All White)
2. COLOR INDEX=2  
 $x=0.313 \pm 0.005$   
 $y=0.329 \pm 0.005$   
(All White)
3. COLOR INDEX=1  
 $x=0.346 \pm 0.005$   
 $y=0.359 \pm 0.005$   
(All White)

## • Vertical and Horizontal Position and Size Specification




## • Focus adjustment


Adjust the focus volume 1 and 2 for the optimum focus.




## SECTION 5 DIAGRAMS

### 5-1. BLOCK DIAGRAMS






## 5-2. FLAME SCHEMATIC DIAGRAM



### 5-3. CIRCUIT BOARDS LOCATION



### 5-4. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

**Note:**

- All capacitors are in  $\mu\text{F}$  unless otherwise noted. (pF:  $\mu\mu\text{F}$ )  
Capacitors without voltage indication are all 50 V.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm  
Rating electrical power 1/4 W (CHIP : 1/10 W)

- All resistors are in ohms.
- : nonflammable resistor.
- : fusible resistor.
- : internal component.
- : panel designation, and adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- : earth-ground.
- : earth-chassis.
- The components identified by in this basic schematic diagram have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation.  
Should replacement be required, replace only with the value originally used.
- When replacing components identified by , make the necessary adjustments indicated. (See page 3-1)
- When replacing the part in below table, be sure to perform the related adjustment.


**Note: The components identified by shading and mark are critical for safety. Replace only with part number specified.**

**Note: Les composants identifiés par un tramé et une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.**

- All voltages are in V.
- Readings are taken with a 10 M digital multimeter.
- Readings are taken with a color-bar signal input.
- Voltage variations may be noted due to normal production tolerances.
- \* : Can not be measured.
- Circled numbers are waveform references.
- : B + bus.
- : B - bus.

• Divided circuit diagram

One sheet of D board circuit diagram is divided into four sheets, each having the code D-a to D-d. For example, the destination on the code D-a sheet is connected to on the D-b sheet.



	Part Replaced
HV ADJ	RV901

	Part Replaced
HV Regulator Circuit Check	D Board T901 (FBT), IC901, R903, R922, RV901 • Mounted D board
HV Protector Circuit Check	D Board T901 (FBT), R927, R920, C923, D913, D916, R935, R936 • Mounted D board
Beam Current Protector Circuit Check	D Board R933, R932, R934, R923, R928, R939, R918, R053, IC901, D918, D901, D902, T901 (FBT) • Mounted D board


### Terminal name of semiconductors in silk screen printed circuit (\*)

	Device	Printed symbol	Terminal name	Circuit
①	Transistor		Collector Base Emitter	
②	Transistor		Collector Base Emitter	
③	Diode		Cathode Anode	
④	Diode		Cathode Anode (NC)	
⑤	Diode		Cathode Anode (NC)	
⑥	Diode		Common Anode Cathode	
⑦	Diode		Common Anode Cathode	
⑧	Diode		Common Anode Anode	
⑨	Diode		Common Anode Anode	
⑩	Diode		Common Cathode Cathode	
⑪	Diode		Common Cathode Cathode	
⑫	Diode		Anode Anode Cathode Cathode	
⑬	Transistor (FET)		Drain Source Gate	
⑭	Transistor (FET)		Drain Source Gate	
⑮	Transistor (FET)		Source Drain Gate	
⑯	Transistor		Emitter Collector Base	
-	Discrete semiconductor			


(Chip semiconductors that are not actually used are included.)

Ver.1.5

(1) Schematic Diagram of US Board



(2) Schematic Diagram of A Board




Schematic diagram


← US board

Schematic diagrams

→ A boards →



(4) Schematic Diagram of D (ⓐ, ⓑ, ⓒ, ⓔ) Board



Schematic diagrams


← A|H boards

Schematic diagram



D-ⓐ board →

## • Divided circuit diagram

One sheet of D board circuit diagram is divided into four sheets, each having the code D-④ to D-⑦. For example, the destination (ab1) on the code D-④ sheet is connected to (ab1) on the D-⑤ sheet.




## • D BOARD WAVEFORMS

**A**

1 | 2 | 3 | 4 | 5 | 6 | 7

A



- Divided circuit diagram


One sheet of D board circuit diagram is divided into four sheets, each having the code D-① to D-④. For example, the destination (ab1) on the code D-① sheet is connected to ab1 on the D-④ sheet.

a b 1  
Ref. No.  
Circuit diagram division code

Schematic diagram

← D-① board


• D-④ BOARD IC701, IC702 LA6510



I

Schematic diagram

D-④ board →



- Divided circuit diagram


One sheet of D board circuit diagram is divided into four sheets, each having the code D-ⓐ to D-ⓓ. For example, the destination ⓐ1 on the code D-ⓐ sheet is connected to ⓐ1 on the D-ⓑ sheet.

a b 1  
→ Ref. No.  
→ Circuit diagram division code


D

$\mu$ -COM, DEFLECTION,  
LCC, POWER SUPPLY

— D BOARD (Conductor Side) —



— D BOARD (Component Side) —





A


[VIDEO]

— A BOARD (Conductor Side) —


• A BOARD  
SEMICONDUCTOR  
LOCATION

IC	
(Conductor Side)	(Component Side)
IC401	D-1
IC402	D-2
IC403	C-1
IC404	C-2
IC405	A-3
IC406	A-2
IC407	B-1
IC408	D-3
IC409	A-1
IC410	D-1
TRANSISTOR	
(Conductor Side)	(Component Side)
Q101	A-1
Q102	A-1
Q103	C-1
Q201	A-1
Q202	A-1
Q203	C-1
Q301	A-1
Q302	A-1
Q303	C-1
Q401	C-2
Q402	C-2
Q403	D-3
Q404	D-2
Q405	D-2
Q406	D-2
Q408	A-1
Q409	A-2
Q410	A-3
Q411	A-2
Q415	D-3
Q416	D-1
Q418	C-1
DIODE	
(Conductor Side)	(Component Side)
D101	D-1
D103	B-1
D104	B-2
D105	B-1
D106	C-3
D107	A-1
D111	D-3
D201	D-1
D203	B-1
D204	B-2
D205	A-3
D206	C-3
D207	A-1
D211	D-2
D301	D-1
D303	B-1
D304	B-1
D305	B-1
D306	C-3
D307	B-1
D311	D-2
D401	D-3
D406	C-2
D407	A-1
D408	D-3
D409	C-1
D413	A-3

\*: Refer to Terminal name of  
semiconductors in silk screen  
printed circuit (see page 5-8)




— A BOARD (Component Side) —



 NOTE:  
The circuit indicated as left contains high voltage of over  
600 Vp-p. Care must be paid to prevent an electric shock in  
inspection or repairing.


## 5-5. SEMICONDUCTORS

BA9756FS-E2  
MB88346BPFV




20 pin SOP


LA6500-FA



LA6510




CA0005AM-TP  
NJM4558M  
 $\mu$ PC4558G2  
24LC21AT/SN




8 pin SOP

CXA2043Q




TOP VIEW

CXA2044M-T6  
LSC4380DW2R2




28 pin SOP

DM-60




5 pin

LM324M  
SN74HC02ANS  
SN74HC04ANS  
SN74HCT04ANS




14 pin SOP

FA4111




14 pin SIP

MB90F553APF-G-N11



MCR5102


MARKING SIDE VIEW




19 pin ZIP

DTA114GKA-T146  
DTA114TUA-T106  
DTA124EUA-T106  
DTA143ESA-TP  
DTA144EKA-T146  
DTC114GKA  
DTC124EK  
DTC124EUA-T106  
2SA1036K-Q  
2SA1162-G  
2SA1462-Y33  
2SC1623-L5L6

2SA1358-Y  
2SC3421-Y



2SC3209LK




MC33262P  
MM1170BFB  
M24C16-MN6T




8 pin DIP

LA7841L




LM1283N  
TUSB2040N




28 pin DIP


NJM78M09FA  
TA78M12S




DTC114ESA  
2SA1175-HFE  
2SC2784-E  
2SC2785-HFE




2SC4015TV2




PST600J-T




2SC5022-02  
2SJ449



2SD1802-S




2SA1049-GR




2SK2195F04




2SA1091-O  
2SC2362K-G  
2SC3941A-Q (TA)



2SK3155-01  
2SK3157-01



# GDM-F400/F400T9



## SECTION 6

### EXPLODED VIEWS


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque  $\triangle$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

#### 6-1. CHASSIS

$\blacktriangle$	7-685-647-79	+BVTP 3X10
$\blacksquare$	7-685-663-71	+BVTP 4X16
$\triangle$	7-685-872-09	+BVTT 3X8
$\square$	7-685-881-09	+BVTT 4X8




REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
1	* 4-068-937-01	SHIELD, EMI		9	4-052-345-01	SCREW, (3X8) (+K), TAPPING	
2	3-704-372-01	HOLDER, HV CABLE		10	1-694-509-11	TERMINAL BOARD ASSY, I/O	
3	3-703-319-01	PURSE LOCK (DIA. 15)		11	* A-1298-762-B	A BOARD, COMPLETE	
4	* 8-933-353-00	D BOARD, COMPLETE	5	12	4-068-929-01	CABINET	
5	$\triangle$ X-4035-425-1	TRANSFORMER ASSY,FLYBACK (NX-4500//J1E4)		13	4-068-919-01	COVER (L), SCREW	
6	* 4-394-972-21	CAP, POWER		14	4-068-918-01	COVER (R), SCREW	
7	4-389-025-01	SCREW (M4) (EXT TOOTH WASHER)		15	4-069-895-11	LABEL, INFORMATION [F400]	
8	$\triangle$ 1-251-382-22	INLET, AC 3P (WITH NOISE FILTER)		15	4-069-895-01	LABEL, INFORMATION [F400T9]	
				16	1-543-653-11	CORE ASSY, BEAD (DIVISION TYPE)	

## 6-2. PICTURE TUBE

- |                |            |
|----------------|------------|
| ▲ 7-685-647-79 | +BVTP 3X10 |
| ■ 7-685-663-71 | +BVTP 4X16 |
| □ 7-685-881-09 | +BVTT 4X8  |


The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque ▲ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
51	X-4036-401-4	BEZEL ASSY		52		66	4-365-808-01 SCREW (5), TAPPING
52	4-065-308-01	BUTTON, POWER		67	* 4-382-848-01	HOLDER, PRINTED CIRCUIT BOARD	
53	4-068-917-01	BAR, EXTENSION		68	* 3-703-141-00	HOLDER, PRINTED CIRCUIT BOARD	
54	3-653-339-01	SPRING, COMPRESSION		69	4-065-302-01	COVER, ECS	
55	4-046-797-01	SCREW (3X12), (+) BV TAP		70	X-4036-400-1	STAND ASSY	71-73
56	4-065-309-01	KNOB (MENU)		71	4-061-396-01	STOPPER (A)	
57	* 8-933-354-00	H BOARD, COMPLETE		72	4-063-397-01	RING, TILT SWIVEL	
58	▲ 8-736-406-71	ITC ASSY (19TRF-R1)	59-61	73	4-047-474-01	FOOT, RUBBER	
59	▲ 1-451-495-12	DEFLECTION YOKE (Y19TRK)		74	4-062-381-01	STOPPER (B)	
60	▲ 1-452-912-61	NECK ASSEMBLY (NA-2914)		75	* 8-933-355-00	US BOARD, COMPLETE	
61	4-050-492-01	SPACER, DEFLECTION YOKE		76	4-068-922-01	COVER, STAND	
62	* 4-047-316-01	SPRING, EXTENSION		77	4-308-870-00	CLIP, LEAD WIRE	
63	▲ 1-416-984-11	COIL, LANDING CORRECTION (LCC)		78	1-452-032-00	MAGNET, DISK; 10mmφ	
64	▲ 1-416-983-11	COIL, LANDING CORRECTION (NS)		79	1-452-094-00	MAGNET, ROTATABLE DISK; 15mmφ	
65	▲ 1-416-982-11	COIL, DEGAUSSING		80	4-051-736-21	PIECE A (90), CONV. CORRECT	

## 6-3. PACKING MATERIALS



The components identified by shading and mark  $\triangle$  are critical for safety. Replace only with part number specified.

Les composants identifiés par un trame et une marque  $\triangle$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
101	* 4-068-248-01	CUSHION (UPPER) ASSY		107	$\triangle$ * 1-782-783-11	CORD SET, POWER [F400]	
102	* 4-041-927-31	BAG, POLYETHYLENE		107	$\triangle$ 1-782-784-11	CORD SET, POWER [F400T9]	
103	* 4-068-254-01	PAD FOR TILT FIXING		108	1-785-429-11	ADAPTOR, CONVERSION (for Macintosh)	
104	* 4-068-249-01	CUSHION (LOWER) ASSY		109	1-790-081-21	CABLE, USB	
105	* 4-070-120-01	INDIVIDUAL CARTON [F400]		110	3-864-156-22	MANUAL, INSTRUCTION [F400]	
105	* 4-070-121-01	INDIVIDUAL CARTON [F400T9]		110	3-864-156-31	MANUAL, INSTRUCTION [F400T9]	
106	1-790-650-11	CABLE ASSY (15P DSUBX2 CONNECTOR)		111	1-759-641-14	DISK, INFORMATION (for Windows)	



## SECTION 7

## ELECTRICAL PARTS LIST

A

## NOTE:

The components identified by shading and mark  $\Delta$  are critical for safety. Replace only with part number specified.

Les composants identifiés par un tramé et une marque  $\Delta$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

The components identified by  $\blacksquare$  in this manual have been carefully factory-selected for each set in order to satisfy regulations regarding X-ray radiation. Should replacement be required, replace only with the value originally used.

• Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

## • CAPACITORS

MF :  $\mu$ F

## • COILS

UH :  $\mu$ H

## RESISTORS

- All resistors are in ohms
- F : nonflammable

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
	* A-1298-762-B	A BOARD,COMPLETE		C403	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
		*****		C404	1-104-664-11	ELECT 47MF	20% 25V
				C405	1-128-560-11	ELECT 22MF	20% 100V
	4-382-854-11	SCREW (M3X10), P, SW (+)	(IC406,IC407, IC409)	C406	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
				C407	1-107-823-11	CERAMIC CHIP 0.47MF	10% 16V
				C408	1-164-489-11	CERAMIC CHIP 0.22MF	10% 16V
				C409	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C410	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C411	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C413	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C414	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C415	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C418	1-163-243-11	CERAMIC CHIP 47PF	5% 50V
				C420	1-163-222-11	CERAMIC CHIP 5PF	0.25PF 50V
				C421	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C422	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C424	1-104-664-11	ELECT 47MF	20% 25V
				C425	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
				C426	1-126-933-11	ELECT 100MF	20% 16V
				C427	1-115-340-11	CERAMIC CHIP 0.22MF	10% 25V
				C429	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C430	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C432	1-107-652-11	ELECT 10MF	20% 250V
				C433	1-104-664-11	ELECT 47MF	20% 25V
				C434	1-162-318-11	CERAMIC 0.001MF	10% 500V
				C435	1-104-664-11	ELECT 47MF	20% 25V
				C436	1-104-664-11	ELECT 47MF	20% 25V
				C437	1-104-665-11	ELECT 100MF	20% 25V
				C438	1-162-114-00	CERAMIC 0.0047MF	2KV
				C439	1-162-318-11	CERAMIC 0.001MF	10% 500V
				C440	1-162-318-11	CERAMIC 0.001MF	10% 500V
				C442	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C443	1-128-528-11	ELECT 470MF	20% 16V
				C444	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C445	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C446	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
				C447	1-104-664-11	ELECT 47MF	20% 25V
				C448	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
				C449	1-163-235-11	CERAMIC CHIP 22PF	5% 50V
				C452	1-104-664-11	ELECT 47MF	20% 25V
				C453	1-128-562-11	ELECT 47MF	20% 100V
				C454	1-163-227-11	CERAMIC CHIP 10PF 0.5PF	50V
				C455	1-115-340-11	CERAMIC CHIP 0.22MF	10% 25V

# GDM-F400/F400T9

A

Les composants identifiés par un trame et une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark △ are critical for safety.  
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
C458	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V					
C459	1-163-021-91 CERAMIC CHIP 0.01MF	10% 50V		D311	8-719-062-51 DIODE 1PS226-115		
C460	1-104-664-11 ELECT 47MF	20% 25V		D401	8-719-109-85 ZENER DIODE RD5.1ESB2		
C462	1-163-021-91 CERAMIC CHIP 0.01MF	10% 50V		D406	8-719-911-19 DIODE 1SS119-25		
C466	1-162-318-11 CERAMIC 0.001MF	10% 500V		D407	8-719-052-12 DIODE 1SS376TE-17		
C467	1-162-318-11 CERAMIC 0.001MF	10% 500V		D408	8-719-976-96 ZENER DIODE DTZ4.7C		
C468	1-162-134-11 CERAMIC 470PF	10% 2KV		D409	8-719-062-51 DIODE 1PS226-115		
C469	1-126-963-11 ELECT 4.7MF	20% 50V		D413	8-719-911-19 DIODE 1SS119-25		
C470	1-104-664-11 ELECT 47MF	20% 25V		D414	8-719-109-66 ZENER DIODE RD3.3ESB2		
C471	1-104-664-11 ELECT 47MF	20% 25V		D415	8-719-051-85 DIODE HSS83TD		
C472	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V		D416	8-719-404-50 DIODE MA111-TX		
C477	1-164-489-11 CERAMIC CHIP 0.22MF	10% 16V		D417	8-719-404-50 DIODE MA111-TX		
C478	1-164-346-11 CERAMIC CHIP 1MF	16V		D418	8-719-052-12 DIODE 1SS376TE-17		
C479	1-164-346-11 CERAMIC CHIP 1MF	16V					
C480	1-164-489-11 CERAMIC CHIP 0.22MF	10% 16V					
C481	1-136-169-00 FILM 0.22MF	5% 50V					
C482	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V					
C483	1-163-021-91 CERAMIC CHIP 0.01MF	10% 50V					
C484	1-163-021-91 CERAMIC CHIP 0.01MF	10% 50V					
C485	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V					
C486	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V					
C487	1-164-004-11 CERAMIC CHIP 0.1MF	10% 25V					
C488	1-117-450-11 FILM 0.47MF	10% 250V					
<b>&lt;CONNECTOR&gt;</b>							
CN401	* 1-564-523-11 PLUG, CONNECTOR 8P			FB402	1-412-911-31 FERRITE	1.1UH	
CN402	* 1-564-526-11 PLUG, CONNECTOR 11P			FB403	1-216-295-91 SHORT	0	
CN403	* 1-564-522-11 PLUG, CONNECTOR 7P			FB405	1-412-911-31 FERRITE	1.1UH	
CN404	* 1-564-521-11 PLUG, CONNECTOR 6P			FB406	1-412-911-31 FERRITE	1.1UH	
CN405	* 1-766-179-11 PIN, CONNECTOR (PC BOARD) 2P			FB408	1-412-911-31 FERRITE	1.1UH	
CN406	* 1-564-522-11 PLUG, CONNECTOR 7P			FB409	1-216-295-91 SHORT	0	
CN412	1-695-915-11 TAB (CONTACT)			FB410	1-216-295-91 SHORT	0	
<b>&lt;DIODE&gt;</b>							
D101	8-719-062-51 DIODE 1PS226-115			FB411	1-216-295-91 SHORT	0	
D103	8-719-052-12 DIODE 1SS376TE-17			FB413	1-412-911-31 FERRITE	1.1UH	
D104	8-719-052-12 DIODE 1SS376TE-17			FB414	1-216-295-91 SHORT	0	
D105	8-719-052-12 DIODE 1SS376TE-17						
D106	8-719-404-50 DIODE MA111-TX						
D107	8-719-052-12 DIODE 1SS376TE-17						
D111	8-719-062-51 DIODE 1PS226-115						
D201	8-719-062-51 DIODE 1PS226-115						
D203	8-719-052-12 DIODE 1SS376TE-17						
D204	8-719-052-12 DIODE 1SS376TE-17						
D205	8-719-052-12 DIODE 1SS376TE-17						
D206	8-719-404-50 DIODE MA111-TX						
D207	8-719-052-12 DIODE 1SS376TE-17						
D211	8-719-062-51 DIODE 1PS226-115						
D301	8-719-062-51 DIODE 1PS226-115						
D303	8-719-052-12 DIODE 1SS376TE-17						
D304	8-719-052-12 DIODE 1SS376TE-17						
D305	8-719-052-12 DIODE 1SS376TE-17						
D306	8-719-404-50 DIODE MA111-TX						
D307	8-719-052-12 DIODE 1SS376TE-17						
<b>&lt;IC&gt;</b>							
IC401	8-759-064-36 IC MB88346BPFV						
IC402	8-759-925-72 IC SN74HC02ANS						
IC403	8-759-445-85 IC LM1283N						
IC404	8-759-525-20 IC LSC4380DW2R2						
IC405	8-759-502-82 IC LM324M						
IC406	8-759-263-43 IC TA78M12S						
IC407	8-749-013-74 IC FA4111						
IC408	8-759-522-86 IC M52755FP-TP						
IC409	8-749-011-42 IC SI-3050F						
IC410	8-759-502-82 IC LM324M						
<b>&lt;JACK&gt;</b>							
J401	△ 1-251-598-11 SOCKET, CRT						























# GDM-F400/F400T9

D H US

Les composants identifiés par un trame et une marque  $\triangle$  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

The components identified by shading and mark  $\triangle$  are critical for safety.  
Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
TH601 $\triangle$	1-809-260-11	THERMISTOR, POWER		R812	1-247-815-91	CARBON	220 5% 1/4W
TH1501	1-807-970-11	THERMISTOR		R813	1-247-815-91	CARBON	220 5% 1/4W
			<THERMISTOR>	R814	1-249-429-11	CARBON	10K 5% 1/4W
				R815	1-249-429-11	CARBON	10K 5% 1/4W
				R816	1-247-863-91	CARBON	22K 5% 1/4W
THP601 $\triangle$	1-809-827-11	THERMISTOR, POSITIVE		R817	1-247-863-91	CARBON	22K 5% 1/4W
			<VARISTOR>	R818	1-215-445-00	METAL	10K 1% 1/4W
				R819	1-249-441-11	CARBON	100K 5% 1/4W
				R824	1-247-863-91	CARBON	22K 5% 1/4W
				R825	1-247-863-91	CARBON	22K 5% 1/4W
VDR601 $\triangle$	1-810-622-21	VARISTOR		R826	1-249-412-11	CARBON	390 5% 1/4W
VDR602 $\triangle$	1-801-268-51	VARISTOR TNR14V471K660		R827	1-249-406-11	CARBON	120 5% 1/4W
				R828	1-215-421-00	METAL	1K 1% 1/4W
			<CRYSTAL>				
X001	1-567-781-61	VIBRATOR, CRYSTAL (4MHz)					<SWITCH>
				S801	1-771-464-11	SWITCH, STICK (CONT +/-, BRT +/-)	
*****				S807	1-762-196-21	SWITCH, TACT (INPUT)	
				S808	1-762-196-21	SWITCH, TACT (ASC)	
				S809	1-762-196-21	SWITCH, TACT (RESET)	
* 8-933-354-00	H BOARD,COMPLETE						<THERMISTOR>
	*****			TH801	1-807-796-11	THERMISTOR	
*****							
			<CAPACITOR>				
C805	1-124-589-11 ELECT	47MF	20%				
C811	1-124-589-11 ELECT	47MF	20%				
			<CONNECTOR>				
CN801	* 1-564-525-11 PLUG, CONNECTOR 10P						* 8-933-355-00 US BOARD,COMPLETE
							*****
			<DIODE>				<CAPACITOR>
D810	8-719-064-11 DIODE SPR-325MVW			C2601	1-163-021-91	CERAMIC CHIP 0.01MF	10% 50V
D812	8-719-060-26 DIODE SLR-325YCT31			C2602	1-104-664-11 ELECT	47MF	20% 25V
D813	8-719-060-26 DIODE SLR-325YCT31			C2603	1-104-664-11 ELECT	47MF	20% 25V
				C2605	1-104-664-11 ELECT	47MF	20% 25V
				C2606	1-104-664-11 ELECT	47MF	20% 25V
			<TRANSISTOR>				
Q801	8-729-119-78 TRANSISTOR 2SC2785-HFE			C2607	1-126-934-11 ELECT	220MF	20% 10V
Q802	8-729-119-78 TRANSISTOR 2SC2785-HFE			C2608	1-126-934-11 ELECT	220MF	20% 10V
Q803	8-729-119-78 TRANSISTOR 2SC2785-HFE			C2609	1-126-934-11 ELECT	220MF	20% 10V
Q804	8-729-119-78 TRANSISTOR 2SC2785-HFE			C2610	1-126-934-11 ELECT	220MF	20% 10V
				C2612	1-104-664-11 ELECT	47MF	20% 25V
			<RESISTOR>				
R801	1-215-429-00 METAL	2.2K	1%				
R802	1-215-437-00 METAL	4.7K	1%				
R803	1-215-433-00 METAL	3.3K	1%				
R804	1-215-421-00 METAL	1K	1%				
R805	1-215-417-00 METAL	680	1%				
				C2909	1-163-243-11 CERAMIC CHIP 47PF		5% 50V
				C2910	1-163-275-11 CERAMIC CHIP 0.001MF		5% 50V
				C2911	1-104-664-11 ELECT	47MF	20% 25V
				C2912	1-163-229-11 CERAMIC CHIP 12PF		5% 50V
				C2914	1-164-489-11 CERAMIC CHIP 0.22MF		10% 16V
				C2916	1-164-004-11 CERAMIC CHIP 0.1MF		10% 25V



REF.NO.	PART NO.	DESCRIPTION	REMARK		
R2622	1-216-129-00	RES,CHIP	2.2M	5%	1/10W
R2901	1-216-017-91	RES,CHIP	47	5%	1/10W
R2902	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R2903	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R2915	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R2916	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2919	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2920	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2923	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2924	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2925	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2926	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2927	1-216-017-91	RES,CHIP	47	5%	1/10W
R2928	1-216-017-91	RES,CHIP	47	5%	1/10W
R2930	1-216-009-91	RES,CHIP	22	5%	1/10W
R2931	1-216-009-91	RES,CHIP	22	5%	1/10W
R2932	1-216-077-00	RES,CHIP	15K	5%	1/10W
R2933	1-216-017-91	RES,CHIP	47	5%	1/10W
R2934	1-216-017-91	RES,CHIP	47	5%	1/10W
R2935	1-216-017-91	RES,CHIP	47	5%	1/10W
R2941	1-216-017-91	RES,CHIP	47	5%	1/10W
R2942	1-216-017-91	RES,CHIP	47	5%	1/10W

## &lt;TRANSFORMER&gt;

T2601 1-416-762-11 INDUCTOR 10UH

## &lt;CRYSTAL&gt;

X2901 1-767-587-31 VIBRATOR, CRYSTAL (48MHz)