



6-2 DTMF SQUELCH



In order to contact a specific station, a DTMF code is transmitted prior to your voice signal. The DTMF code can be heard from the speaker while the DTMF signals are being emitted. Beforehand, one of the four DTMF pager modes must be set in the transceiver. Check to make sure the mode you want to select is indicated in the display.

- C appears: 3-digit pager mode (pages 13-14)
- D appears: 7-digit pager mode (pages 15-18)
- AD appears: 7-digit pager/auto answerback mode (pages 15-19)
- None of the above appear: DTMF squelch is cancelled

6-2-1 3-digit pager mode



C appears to indicate the transceiver is in 3-digit DTMF pager mode (code squelch). When you receive a DTMF code that agrees with your own DTMF code, the squelch opens.

Transmitting


While pushing the PTT, enter the receiving station's code. (Time between pushing keys must be within 2 secs.)

Receiving

When the transceiver receives an appropriate 3-digit DTMF code the squelch opens. At the same time a calling signal is emitted for 10 secs. Perform any other operation to stop this signal.

If no operation or action is performed within an additional 10 secs., the transceiver's squelch closes again.

<Ex.>



5-2 MONITOR FUNCTION


Pushing the MONI key is the same as rotating the squelch control completely counterclockwise. If nothing changes when pushing this key the operation has been disallowed by your Dealer.

5-3 LAMP FUNCTION

Push the LAMP key to activate the LCD backlighting. Pushing the key a second time or performing no operation for 5 secs. will turn the backlighting off. When the key lock function is activated, during scan or during any other operation, this function is still available. LAMP key remains active during the key lock (KL), scan, or any other operation.


5-4 LOW BATTERY INDICATION

B appears in the LCD when the battery is low.



5-5 KEY LOCK FUNCTION


Push the F key plus the LAMP/KL key to toggle between all keys locked and all keys unlocked.



KL appears during key lock function ON and all keys except for LAMP, MONI, F, and PTT are locked.

5-6 TRANSMIT OUTPUT POWER SELECTION

While pushing the F key, each push of the MONI/H/L key changes the transmit output power as illustrated below.



L appears when low output power is set.

NOTE: If KL does not appear or pushing the F key plus the H/L key does not change the output power, such operation has been disallowed by your dealer.