

## Selecting Functions and Options

Your phone offers a set of functions that allow you to customise your phone. These functions are arranged in menus and sub-menus, accessed via the two soft keys marked **...**. Each menu and sub-menu allows you to view and alter the settings of a particular function.

The roles of the soft keys vary according to the current context; the label on the bottom line of the display just above each key indicates its current role.

Example:



Press the left soft key to search for a name in the phonebook.

Press the right soft key to access the Voice Dialling feature.

### Selecting Functions and Options

To view the various functions/options available and select the one required, proceed as follows.

1. Press the appropriate soft key.

2. **To...**

**Then press the...**

Select the:

Left soft key.

- Function displayed
- or
- Option highlighted

View the next function or highlight the next option in a list

Right soft key or the key on the left side of the phone.

Move back to the previous function or option in a list

„ key on the left side of the phone.

Move back up one level in the structure

C key.

Exit the structure without changing the settings


☎/⊕ key.

In some functions, you may be asked for a password or PIN. Enter the required code and press **☎**.


## Selecting Functions and Options

## Example: Setting the Text Language


1. When the idle screen is displayed, press the **Menu** soft key to enter the menu facility.



2. Scroll through the menus until you reach the **Phone Settings** menu, by pressing the  $\rightarrow$  soft key (or the  $\rightarrow$  or  $\leftarrow$  keys on the left side of the phone).




3. To select the **Phone Settings** menu, press the **Select** soft key or  $\rightarrow$ .



## Selecting Functions and Options

4. To reach the Text Language sub-menu, scroll through the sub-menus until you reach the **Language** sub-menu(6.3), by pressing the  $\rightarrow$  soft key (or the  $\rightarrow$  or  $\leftarrow$  keys on the left side of the phone) and press the **Select** soft key or  $\rightarrow$ .



5. To view the languages available, press the **Select** soft key or  $\rightarrow$ . The current setting is highlighted within square brackets.



6. Scroll through the list of languages until the appropriate one is highlighted, by pressing the  $\rightarrow$  soft key (or the  $\rightarrow$  or  $\leftarrow$  keys on the left side of the phone).
7. Press the **Select** soft key to confirm your selection.
8. Press the **C** key three times to exit the menu structure.