
CTIN
J2
(CTRL) P1
FRONT
MAIN DIAL
5VL
MUP
MDN
GND
J1
RIT BOARD
FRONT W4
J2
MODE BOARD
FRONT W6
J502
TEN-KEY BOARD
FRONT W7
J503
FRONT W8
J504
SUB-LOGIC UNIT
MIC BOARD
FRONT W2
J506
J507
FRONT W5
PBT BOARD
J512
P758
J511
P1
SSP
SSPE
CHASSIS
SP
J508
FRONT W3
PHONE BOARD
J510
FRONT W1
KEY BOARD
J101
CFL+
CFL-
LCD
CHASSIS W14
J505
CHASSIS W10
CHASSIS W8
PLL UNIT
J751
4LO
J701
3LO
J351
1LOA
J651
1LOB
J81
2LO
J851
MKR
J801
SLO
(CTRL) P2
(PLL) P351
(PLL) P651
(PLL) P81
(PLL) P851
(PLL) P801
(PA) P1
J5
CHASSIS W11
J8
TUNER BOARD
J3
TUIN
J4
TUOT
P3
P4
RFRX
CHASSIS W7
J13
FILTER UNIT
W1
W2
W3
W4
W5
W6
W7
GND
L7
L3
L6
L4
L5
L2
L1