

# Overview

1

## Display Indicators

Reception strength/  
battery level.

## Fast Access Key

Can be assigned an im-  
portant phone number/  
function.

## Call Key

- Dial the displayed  
phone number or  
name.
- Accept calls.
- Display last calls in  
standby mode.

## Phonebook

Display Phonebook en-  
tries for easy calling.

## Ringer On/ Off

**Hold down:** Switch  
ringer on and off.

## Menu

Set the network and  
phone functions.

## Soft Keys

(see below)

## On/Off/End

**Press briefly:**  
End call or return to  
standby mode.


**Hold down:**  
Phone On/Off.

## Key Lock

**Hold down:** Activate/ de-  
activate lock.

## Internat. Dialling Code

Press until "+" appears,  
then press  
**+List** and select country.



## Soft Keys

The current functions are shown in the display as symbols or text above the keys. Different functions are available by pressing either the left or the right end of the keys.

In standby, the soft keys enable fast "name" dialling and menu access or access to a special service such as SIM service.

## 2 Precautions

## Introduction

All radio transmitters carry risks of interference with electronics in close proximity:



Mobile phones must be switched off at all times in an aircraft.



Do not activate near gas stations, fuel depots, chemical plants or blasting operations.



Avoid use in hospitals; medical electronics, e.g. pacemakers and hearing aids can be affected.



Minor interference may affect TVs, radios, PCs, etc.



Avoid touching the antenna unnecessarily while using the phone.



Do not hold the phone in your hand while driving ("Accessories", Seite 63)



Do not dismantle phone or battery.

Please note:



Use only specified batteries and chargers as others can damage the phone.



Unusable batteries should be disposed of in accordance with relevant legislation.



Only use ORIGINAL Siemens accessories to avoid damage to your phone.

### Your User Guide:

The following symbols are used:



Use the keypad to write numbers or letters.



Soft key for the function displayed above.



Press the soft key at the end indicated.



Black background indicates a soft key function.



Function depends on Service Provider; separate registration may be necessary.



Function only available in i version.

### Menu Control

The menus provide access to functions, network services and individual settings.

**Main Menu** (see also p. 21)

To reach the Main Menu, press the right soft key in standby mode.



Press.

### Submenu

In other situations, e.g. when the phonebook is open, a corresponding function or option menu may appear:

Press **Menu** or **Options**

### Go Back



A short press on this button takes you back one menu level.

# Contents

<b>Overview</b> .....	<b>1</b>	<b>Office&amp;Fun</b> .....	<b>22</b>
<b>Getting Started</b> .....	<b>5</b>	Internet .....	22
1. Install SIM Card .....	5	Appointments .....	24
2. Charge Battery .....	6	Calculator .....	25
3. Switch on .....	6	Currency Conv. ....	26
Emergency Call (SOS).....	6	Business Card .....	27
4. Enter PIN.....	7	Games.....	28
<b>Making Calls</b> .....	<b>8</b>	Chronometer.....	29
Dialling a Number.....	8	<b>Messages</b> .....	<b>30</b>
Ending a Call .....	8	Reading New Messages.....	30
When a Number is Busy .....	9	Creating a New Message .....	31
Redialling.....	9	Text Input With "T9" .....	32
<b>Incoming Calls</b> .....	<b>10</b>	Incoming / Outgoing.....	34
Answering Calls .....	10	Send Business Cards .....	35
Ending Calls .....	10	Setting.....	35
Unwanted Calls.....	10	Voice Message .....	36
Turning off Ringer .....	10	Information Services .....	38
<b>Phonebook</b> .....	<b>11</b>	<b>Records</b> .....	<b>40</b>
New Entry .....	11	Calls missed.....	40
Calling from Phonebook .....	12	Calls received.....	40
VIP Phonebook.....	12	Calls dialled .....	40
<Own Numbers>.....	12	Alarms missed .....	40
<New Entry> .....	12	<b>Profiles</b> .....	<b>41</b>
Phonebook Menu.....	13	<b>Audio</b> .....	<b>42</b>
Saving a Control Code.....	15	Ringer Setting .....	42
<b>Fast Access Keys</b> .....	<b>16</b>	Volume .....	42
Soft Key .....	16	Melodies .....	42
Speed Dialling Numbers .....	17	Vibration .....	42
<b>During a Call</b> .....	<b>18</b>	Call Screening .....	42
Volume Control .....	18	Service Tones .....	43
Call Waiting .....	18	Record Melody .....	43
Notebook .....	18	<b>Time/Charge</b> .....	<b>44</b>
Conference/Toggling .....	19	Charges.....	44
In Call Menu .....	20	Charge Setup .....	44
<b>Main Menu Information</b> .....	<b>21</b>	<b>Divert</b> .....	<b>45</b>
Main Menu.....	21	Divert .....	45
Menu Mode .....	21	Status Check.....	46
SIM Services (optional) .....	21	Clear all Diverts .....	46
		Reactivating Call Diversion.....	46
		Changing Phone Numbers .....	46

<b>Setup</b> .....	<b>47</b>
Menu Mode .....	47
Device .....	47
Security .....	49
Network .....	50
During Calls.....	52
FAX/Data Mode.....	53
Clock .....	54
Car Use .....	54
Head Set .....	54
<b>Fax/Data</b> .....	<b>55</b>
<b>Display Symbols</b> .....	<b>56</b>
<b>Tips on Use</b> .....	<b>57</b>
<b>Siemens Service</b> .....	<b>58</b>
<b>Troubleshooting</b> .....	<b>59</b>
<b>Specifications / Care of Phone.</b>	<b>62</b>
Licensing .....	62
Technical Specifications .....	62
Care of your SIM Card.....	62
<b>Accessories</b> .....	<b>63</b>
<b>Index</b> .....	<b>65</b>

# Getting Started

5


## 1. Insert SIM Card

Your Service Provider will supply a SIM card, containing all the key data about your line.


You may need to snap this out carefully from a credit card sized SIM.

If removing the battery, ensure the phone is switched off first.


- Press the snap lock in the direction indicated by the arrow (1).
- Lift off the battery cover (2).




- Slide out the SIM carrier (3), then turn it in the direction indicated by the arrow (4).



- Slide the SIM card into the carrier (5). Ensure the angled corner is positioned correctly and that contact is made.



- Turn the SIM carrier until the SIM card faces the phone (6).
- Slide the SIM carrier into the phone until it clicks into place (7).
- Insert the battery into the phone (see diagram below) and close the cover.




Older SIM cards (5 Volt technology) cannot be used. Please consult your Service Provider.

## Getting Started

### 2. Charge Battery

The new NiMH battery is not yet fully charged:

- Insert the charger plug into the socket on the phone.



- Plug charging unit into a mains power socket (ensure voltage range stated on charger is not exceeded).

The charging unit will heat up when used for longer periods. This is normal and is not dangerous.

-  When charging is in progress.
-  When charging is complete.

#### Charging time

The unit is fully charged after 2 hours. Variations in the power supply can lead to different charging times.

#### Usage time

-  A fully charged battery can provide up to 180 hours standby time 5 hours talk time.
-  Your display shows charge level.
-  A beep sounds when nearly empty.

If you experience a reduction in usage time, carry out the battery care function (p. 48).

The times specified above are average times. They may vary depending on personal usage and network conditions.

#### Making calls

The phone can be used during charging.

### 3. Switch on



**Hold** down to switch on or off.

### Emergency Call (SOS)

By pressing the **SOS** soft key you can make an emergency call on all networks even without a SIM card or PIN code.

This function must **only** be used in emergencies.

# Getting Started

7

## 4. Enter PIN

Your SIM card is protected with a 4-8 digit PIN code to prevent misuse.



Enter your PIN code (shown as a series of asterisks).

Correct any errors with 




Press the key on the right beneath the display (see figure).



It will take a few seconds to log on to the network.

When the name of the Service Provider appears on the display, the phone is in standby mode and is ready for use.



## Info

### Wrong PIN?

The SIM card will be blocked after the third incorrect PIN entry (see "Troubleshooting", p.59).

You can also switch on/off PIN control or change your PIN code (see p. 50).

### Network Connection



Indicates incoming signal strength.



A weak signal reduces call quality and there may be a risk to call continuity.

If the signal is too weak, move to a window or open space.

There is an antenna at the top of your phone. Do not interfere with it unnecessarily while making a call as this can impair the quality of your connection.

Your phone will automatically select another GSM network if you are abroad or outside your "home" network (see p. 50).

### SIM Services



This symbol is displayed when your SIM card supports special applications, such as banking (see p. 21).

### Problems with the SIM Card

If the message "Insert SIM Card" appears, you should check for faults (see p. 59).


# Making Calls

## Dialling a Number

The phone must be switched on (standby mode).



Dial the required number with **prefix** (international dialling code if appropriate).



 A short press clears the last digit, a long press the entire number.

 Save the number in the Phonebook, see p. 11.



Press. The number displayed is dialled.

## Ending a Call



Press. The call is ended.

You should also press this key if the person you called hangs up first.

## Info

Setting the date/time, see p. 54.

Setting the language, see p. 47.

## International Dialling

Many international dialling codes are already stored in your phone. To retrieve these:

 Press until a “+” symbol appears.

 Press.

 Select the required country from the list.

 Press. The international dialling code appears on the display.

 Add the national number (the first 0 is omitted in many countries).

 Press. The number displayed is dialled.

## Functions available while Making a Call:

 (see p. 19)

 (see p. 20)

## Easier Ways to Call

Easier, quicker and error-free dialling by:

- Redialling previous numbers.
- Automatically redialling busy numbers.
- Calling back unanswered/received calls (see p. 40).

or using the

- Phonebook (see p. 11)
- Fast access (see p. 16)

# Making Calls

9

## When a Number is Busy

The following functions are available if the number you dial is busy:

### Auto Redialling

**AutoDial** Press to repeatedly dial a number in progressive intervals for 15 minutes. No other number can be dialled in this period.

**End**

**Off** Press.

**or**



Press.

Any other use of the phone will clear this function.

### Reminder

**Prompt** Press for a reminder to dial the number again in 15 minutes (beeps and displays number).


## Redialling

The last numbers you called are stored.

From your standby display:



Shows a list of last calls.



Press again to redial the last call

**or** to redial a previous number:



Scroll to highlight required number.



Press to dial the number selected.

**Options** see p. 40.

See page 40 for details on other stored numbers:

- Calls missed
- Calls received

## Incoming Calls

### Answering Calls

To be able to receive calls, you must switch the phone on (standby mode).

When a call is received the display will show:



Press 

or



Press to answer the call.

### Ending Calls



Press.

### Unwanted Calls

**Reject**

Press for the caller to hear the busy signal.

**Divert**

This appears when "call diversion" is active (see p. 45).

or



Press for the caller to hear an announcement.

### Turning off Ringer



Hold down. The ringer is deactivated for the current call.

#### Info

- You can return calls you have received or missed (see page 40).
- An incoming call will interrupt any other use of the phone.
- Data, fax calls (see p. 53)
- Functions available while making a call:

**Hold**

(see p. 19)

**Menu**

(see p. 20)

# Phonebook

11

You can enter frequently dialed numbers with a name in the Phonebook. The number is then dialed by simply highlighting the name.

Important phone numbers can be added to the **VIP Phonebook**.

If a number is stored under a name, the name will appear on the display when a call is received from that number.

## New Entry




Enter the number and **prefix**.



Press.



Enter a name for the number (see also text entry, on the right).



Press.



The number can be dialed straight away.

or



End input and begin a new entry.

## Text Entry

Press number/ letter keys repeatedly. The cursor advances after a short delay.



Press once for "A", twice for "B", etc.



Press to erase the letter preceding the cursor, hold down to erase the whole name



Press to manually switch letter case. The first letter in each name is automatically written in UPPERCASE.



Press to switch between numbers and letters.



Press to create a blank.



Umlauts and numbers are displayed after the relevant letters.



Controls cursor position.

## Special Characters

Press the key repeatedly until the character appears.



Blank 1 € £ \$ ¥ □



+ 0 - . , : ? ¿  
! " ' ; \_



A - a \* / ( ) < = >  
%



A - 1 # @ \ & § Γ Δ  
ø Λ ≡ Π Σ Φ Ψ Ω

## Calling from Phonebook



Open the Phonebook.



Write the first letter of required name and/or scroll to highlight required name.



Dial the number selected.

## VIP Phonebook



Press twice to open the VIP Phonebook. Then proceed as above.

## <Own Numbers>

After selecting "Own Numbers" in the Phonebook up to six "own" numbers (depending on the SIM) can be entered in the Phonebook (for example fax numbers).

**Select** Display numbers.

Only part of the Phonebook menu is available for own numbers.

## <New Entry>

See page 11.

## Info

### Selection by Name in the Phonebook



Open the Phonebook.  
Use the digit keys to enter the first letter of the name required, e.g.



For **Paul**. The Phonebook scrolls to the first entry beginning with the letter "P".

### Extending Numbers

You can enter partial numbers in the Phonebook (e.g. a company number/PABX).

These partial numbers can be extended before dialling:



Open the Phonebook.



Select the (partial) number.



Open the menu, select **View Entry**. The Phonebook entry is displayed.



Add the extension number.



Dial.

or, conversely



Enter the (partial) number.



Open the Phonebook.



Select the extension number.



The extension number is added to the call number.



Dial.

# Phonebook

13

## Phonebook Menu



Open the Phonebook.



Write the first letter of required name and/or scroll to highlight required name.

### Options

The menu is displayed; now select the required function.

---

View Entry  
 Edit Entry  
 Delete Entry  
 VIP Entry  
 Picture  
 Location  
 Send as Text  
 Check Space  
 Delete Phonebook

---

## View Entry

### Edit Entry

The entry is displayed.



Change the number if necessary.



Confirm.



Change the name if necessary.



Confirm.

### Delete Entry

The entry is deleted from the Phonebook after confirmation.

## VIP Entry

Only designate important numbers as VIP entries to ensure fast access (p. 12).

## Picture

You can make entries in the memory with a "robot portrait" or an icon.

### RoboPortrait

Assemble a face. You can choose from 9 pictorial elements.



Mark the face part (top, middle, bottom).



Display three possible views.



The "robot portrait" is appended to the Phonebook entry.

### Add Picture

Select the required picture from the previous symbols.



Display the pictorial symbols.



Scroll through the possible pictures in groups of three.



The picture is appended to the Phonebook entry.

### Delete Picture

The picture is deleted from the entry.

Phonebook entries with pictures are not stored in the SIM (see also "Location", page 14).

# Phonebook

## Location

A new Phonebook entry can be stored as follows:

### in SIM card

Entries are automatically stored in your SIM card, enabling them to be transferred to another GSM Phone.

### in phone memory (phone)

Phonebook entries with pictures are stored here.

If your SIM card is full, entries will overflow into this memory,

### in restricted Phonebook

If you have a special SIM offering "Fixed Dialling Numbers", you can restrict calls to entries in this Phonebook. PIN2 is needed to change this (see page 50).

## Send as Text

The Phonebook entry can be sent as an SMS (see p. 31).

The recipient can immediately enter the number in their Phonebook.

## Check Space

You can check used and available capacity for:

-  SIM card
-  Special SIM card
-  Phone memory

## Delete Phonebook

You can select the Phonebook to be deleted. You will be asked to enter a security code (see page 50):

-  SIM card (PIN)
-  Special SIM card (PIN2)
-  Phone memory (phone code)

## Info

- Always enter the full number with the area code (e.g. 0171 for London).
- If you travel abroad often, you should enter all Phonebook entries with the international dialling code (e.g. +49 for Germany).
- When using the international dialling code the leading 0 of the area code is not used (e.g. 0171 817420 should be stored as +44 171 817420)

# Phonebook

15

## Saving a Control Code

You can store phone numbers and control codes (digits) together in the same way as a normal Phonebook entry. This is useful if you want to control an AnswerPhone remotely.



Enter the phone number.



Hold down until “+” appears (pause to establish connection).



Enter the control code (digits).

 You can hold down again to create a further pause of 3 seconds to ensure the digits are processed correctly on the receiver side.



Press.



Enter name.



Confirm and save in the usual way.

Alternatively, just save the Control Code (digits) and send it during a call (see page 18).

## Info

### Improved Phonebook Management

You can use the “SoftDataLink 3” accessory to create and manage your Phonebook entries via a PC/PDA (see “Accessories”, p.63).

### Service Provider Control

Your Service Provider may be able to add important service numbers to your Phonebook.

### Phonebook Restrictions

Please note that the use of your Phonebook can be restricted (normal for some business applications).

Incomplete phone numbers can be identified with a “?” in a restricted Phonebook. These numbers can be completed before dialling.

## Fast Access Keys

The left soft key and keys 2 to 9 (speed dialling numbers) can each be assigned an important phone number or one of the functions listed below.

The phone number can then be dialled, or the function can be started, at the touch of a button.

- **Phone Number** ..... (p. 11)
- **Write Message** ..... (p. 32)
- **Currency Conv.** ..... (p. 26)
- **Games** ..... (p. 28)
- **Calculator**  ..... (p. 25)
- **Internet**  ..... (p. 21)

### Soft Key



The left soft key can be used for fast access.

Your Service Provider may have already set a function on this key (e.g. access to "SIM Services").

This may be temporarily replaced with  / , for example, for access to a new message.

### Setting

When making initial settings:

**Name?** Press.

 Select function.

If you select **Phone Number** the Phonebook will be opened.

  Select a name by entering the first letter and/or scroll to the relevant entry, e.g. **Office**

or

If you select an application (e.g. **Games**), this is set directly on the soft key.

**Select** Press.

### Use

**Office** Press.

**OK** If a phone number is set on the fast access key, this is dialled or, alternatively, the application is started.

### Changing

**Office** Press.

**Change** Press.

Proceed as described above under "Setting".

# Fast Access Keys

17

## Speed Dialling Numbers

Digit keys 1 to 9 can be used as speed dialling numbers for fast access.

Digit key  should be used for the phone number for checking the mailbox.

## Setting

To set a digit key for the first time, e.g. 2:

 Press the digit key.

 Press.

 Select a function.

If **Phone Number** is selected, the Phonebook is opened for a number to be chosen.

 Select a name by entering the first letter and/or scroll to the relevant entry, e.g. **Office**

or

If you select an application (e.g. **Games**), this is set directly on the soft key.

 Press.

## Use

Either a stored phone number is dialled or a stored application is started. In standby mode:

 Press.

The setting for the 2 appears instead of the left soft key, e.g.:

 Press.

 Press.

or

 Press.

 Press.

## Changing

 Press the digit key briefly; the current setting will appear (e.g. **Games**).

 Press.

 Proceed as described under "Setting".

## During a Call

### Volume Control

**Menu** Press. The menu appears

Select **Volume Control**.

**+ -** Use the left soft key to adjust the handset volume.

### Call Waiting



During a call you can be advised that there is another call waiting. You may need to register for this service and set your phone (see page 52). You will hear a special tone during the call.



You have 3 options:

#### 1 Swap

**Swap** This accepts the waiting call and places the current call on hold.

Call swapping:  
You may swap back and forth as required.

#### 2 Reject Waiting Call

**Reject** Rejects the call; the caller hears a busy tone.

or

**Divert** If this is set, the call is diverted to the Answer-Phone or mailbox, for example (see p. 36).

#### 3 End Current Call, Answer New



Press to end the current call. The waiting call will ring.

**Answer** Answer the new call.

### Notebook

You can enter a phone number during a call (the person on the other end may hear your entry). This number can be stored or called after you have ended the call.

## During a Call

19

### Conference/Toggling

You can call an additional number during a call.

You can swap back and forth between both calls or link all callers together in a conference. A conference can include up to 5 participants.

During a call, explain your intention:



then press 

The current call is put on hold.

 /  Enter a phone number or select one from the Phonebook.



Establish the new connection.

3 options are now available:

#### 1 Swap



You may swap back and forth between the two calls as required.

If the current call is terminated you will be asked: "Return to call on hold?"



Return to the held call.



The held call is terminated.

#### 2 Conference



Press, select **Conference**.

A held call is joined (conference line for up to 5 subscribers).

#### 3 End Connection



Press. All calls are terminated.

Your Service Provider may not offer all the functions described.

## During a Call

### In Call Menu

The following functions are only available during a call.



The menu is displayed; now select the required function.

---

Volume Control  
Microphone off  
Conference  
Time/Cost  
Send DTMF tones  
Call Transfer  
MAIN MENU  
Call Status

---

### Volume Control



The left soft key is used to adjust the handset volume.

If Car Kit Comfort is used, this arrangement does not affect the usual setting.

### Microphone off

You can switch the microphone on or off. If it is switched off, the person on the other end will not be able to hear you.

### Conference (see page 19)

### Time/Cost

You can check current call time and cost (if programmed, see p. 44).

### Send DTMF tones

You may transmit control codes (digits) for controlling an Answer-Phone and other devices.

#### From the Phonebook

Establish a connection with the device, then:



Open the call menu and select **Send DTMF tones**.



Press. Select the name of the control code in the Phonebook

#### Manual Entry

After a connection is established



**OK** enter the digits for the control code.

### Call Transfer

Joins the original call to the second one. You are no longer connected to either call. This function may not be supported by all Service Providers.

### MAIN MENU

This is a fast way to access other menus, for example to check a message or a phone number (see also p. 21).

### Call Status

All held and active calls are listed (e.g. participants in a conference).

# Main Menu Information

21

## Main Menu

The Main Menu gives you access to important phone functions and settings. In standby mode, this is accessed with the right soft key:

**Menu** Open the Main Menu.

The Main Menu contains the following functions:

---

Usage Hints  
 (SIM Services)  
 (Games) (Internet **35j**)  
 Office & Fun  
 Messages  
 Records  
 Profiles  
 Audio  
 Time/Charge  
 Divert  
 Setup

---

All menu items open a submenu in which the required functions can be selected.



Press to go back one menu level until you reach standby mode.

The **Usage Hints** show menu access in abbreviated form from this point onwards (e.g.):

**Menu** → Audio → Volume

This means:

**Menu** Open menu, select **Audio**, then select **Volume**.

## Menu Mode

To make it easier for new users to learn how to operate the phone, the comprehensive Main Menu is reduced to the key functions (see also p. 47).

**Menu** → Setup → Menu Mode

## SIM Services (optional)

Your Service Provider can offer special applications through the SIM card, such as homebanking, stock market, etc.

If you are registered for one of these services, the service name will appear at the top of the Main Menu or directly above the left soft key.



Symbol of the SIM Service.

If there is more than one application, these are displayed in the "SIM Services" menu.

**Menu** → SIM Services

With the SIM Services menu your phone is future-proof and will support additions to your Service Provider's service. For further information contact your Service Provider.

## Games (Internet **35j**)

Fast access to games (p. 28)/ Internet (p. 21) from the Main Menu.

A different function may have been assigned to this menu item by your Service Provider.

Office & Fun contains the following functions:

---

(Internet<sup>35j</sup>)  
 Appointments  
 Calculator  
 Currency Conv.  
 Business Card  
 Games  
 Chronometer

---

## Internet

35j

You can surf the Internet and get the latest information. This information is made available in a special format adapted to the display options available in the phone. Internet access may require registration with your Service Provider.

## Settings

The connection must be set before initial access. If the settings have not already been made by your Service Provider, then the connection must be adjusted manually. It may be necessary to use the "Settings" menu in the browser for this purpose. Please check with your Service Provider.

## Internet Access

**Menu** → Office & Fun → Internet

The Service Provider's homepage appears after connection is established. This may contain different entries, depending on the Service Provider, e.g.



Menu selections are made by scrolling/digit entry

## Switch Key

The right soft key is set with functions from the current Internet page.

**Opt.** To display the various functions available, browse through them by pressing the right end of the right soft key.

Press to switch.

Press to select.

The assignment of the right soft key is always **Opt.**. This is used to display the browser menu.

# Office & Fun

23

## Browser Menu

### Options

The Browser menu is displayed:

- 
- 1 Home
  - 2 Mark Site
  - 3 Bookmarks
  - 4 URL
  - 5 EndConnection
  - 6 Reset
  - 7 Settings
  - 8 Help
  - 9 Version
- 

### Home

The first Internet site displayed after you establish a connection. This may be defined by the Service Provider.

### Mark Site

The current Internet page is added to the bookmark list.

### Bookmarks

Here you will find a list of your most frequently used Internet addresses (URL). To revisit a page, simply select the required entry.

### URL

- Show URL

(Uniform Resource Locator)

The current Internet address is displayed.

- Go to Page

Input option for selecting an Internet address directly.

### EndConnection

The Internet connection is ended.

### Reset

You can clear the list of previously visited pages.

### Settings

This menu contains functions for manually setting connection data. Check with your Service Provider for details.

### Help

Help with the current situation.

### Version

Displays the currently used browser version.

Your Internet browser is licensed from:



## Appointments

**Menu** → Office & Fun → Appointments

You can enter several different appointments for each day in the appointments list. When an appointment time is reached, you will hear an alarm (setting the clock see p. 54).



### Entering a New Appointment



Select <New Alarm>.

**Select**

Press.



Change the date and time as necessary.



Simply press to set an appointment with recurrent alarm.



Select the alarm:  
**Date, Daily, Weekly, Monthly, Yearly**

**Select**

Confirm selection.

**OK**

The default alarm type is **Memo**.

**Change**

Select a different alarm type or enter a short text.

## Alarm Types



**Memo**

Short note (max. 16 characters).



**Call**

Enter the phone number or select from ☎. This number is displayed with the alarm.



**Meeting**



**Birthday**

**Select**

A short note can be appended.

**OK**

Save the alarm entry.

## Info



Display indicates that an alarm is active.

- A total of 30 entries can be created.
- An alarm sounds even when the phone is switched off. It is deactivated by pressing any key. Press **Pause** to delay the alarm by 5 minutes.
- Setting: Alarm tone, see p. 42
- Setting: Clock, see p. 54.



When travelling by plane please note that alarms are activated even when the phone is switched off.

## Office &amp; Fun

25

## Editing an Alarm Entry



Select the required alarm.

**Options**

The following menu is displayed.

**View Alarm**  
**Modify Alarm**  
**Activate Alarm**  
**Deactivate Alarm**  
**Delete Alarm**  
**Clear List**

**View Alarm**

The selected appointment is displayed.

**Modify Alarm**

See "Entering a New Appointment"

**Activate Alarm/Deactivate Alarm**

A deactivated appointment can be reactivated, and vice versa.

**Delete Alarm**

An entered appointment is deleted from the list of appointments.

**Clear List**

All entered appointments are deleted.

## Calculator

35]

**Menu** → Office & Fun →  
**Calculator**



Enter the first number.  
 (  $\frac{\square}{\square}$  ) sets the decimal point).



Press the right end of the left soft key repeatedly until the required calculator function is displayed.



Repeat the procedure with other numbers.



The result is displayed.

## Additional Functions



Press the right end of the left soft key repeatedly until the required function is displayed:



Change operational sign + and - .



Conversion to percentage.



Saves the number displayed.



Retrieves the number stored.



Exponent (one digit only).

**Info**

corresponds to soft key =



corresponds to soft key \*

## Currency Conv.

**Menu** → Office & Fun → Currency Conv.

You can use the currency converter to calculate any combination from three different currency rates.

### Entering a new Currency Pair

Before using this function for the first time, you must set the currencies and exchange rates (max. 3).

If a currency pair has not yet been entered:

**Change** Press, then select **Own into Foreign**.

 / **OK** Enter the symbol for your own currency, e.g. DM.

 / **OK** Enter the symbol for the foreign currency, e.g. € (Euro)

 / **OK** Now enter the relevant exchange rates, e.g. DM = 1, then € = 0.491.

**OK** Confirm.

## Edit Exchange Rates



Select the required pair from the list:

**Options**

Press. The following menu is displayed.

---

**Convert**  
**Edit Entry**  
**New Entry**  
**Delete Entry**

---

**Convert**



Enter the amount to be converted.



Start conversion to other currency.

**Repeat**

Make a new entry.

**Edit Entry**



For example, to alter the exchange rates, proceed as for a new entry.

**New Entry**



Enter currencies and exchange rates as before.

**Delete Entry**

The highlighted entry is deleted after confirmation.

# Office & Fun

27

## Business Card

35i

**Menu** → Office & Fun → Business Card

You can create your own business card and send it as a message via SMS.

If a business card has not yet been created, you will be prompted to make an entry.

/ **OK**

Entries are made as follows:

---

<First name>  
 <Name>  
 <Company>  
 <email (Office)>  
 <email (private)>  
 <Phone (Office)>  
 <Phone (private)>  
 <City>  
 <Postcode>  
 <Street>

---

### Info

- The content and sequence for the business cards corresponds to the international standard (vCard).
- When sending a business card note that no more than 160 characters can be sent via SMS.

## Business Card Menu

### Options

Press. The following menu appears.

---

**Send as Text**  
**Edit Text**

---

### Send as Text

Send via SMS (see page 35).

### Edit Text

Proceed as for a new entry.

# Office & Fun

## Games

**Menu** → Office & Fun → Games:

The following games are available

Wayout  
Reversi  
Quattropoli  
Minesweeper

## Wayout

Find the way out of a 3-dimensional labyrinth.

**Options** Provides tips on how to play the game, shows the highest score and allows you to set the level of difficulty.

**Start** Start game.


## Reversi

Try to obtain as many counters as possible by "trapping" your opponent's counters.

**Options** Provides tips on how to play the game, allows you to define who begins and set the level of difficulty.

**Start** Start game.

**Controls for Wayout and Reversi:**



## Quattropoli

Drop the counters into a field from above. The object of the game is to be the first to have four counters in a row (horizontal, vertical, diagonal).

**Options** Provides tips on how to play the game, allows you to define who begins and set the level of difficulty.

**Start** Start game.

**Controls:**




## Minesweeper

Find all the fields with no mines.

**Options** Provides tips on how to play the game, allows you to set the playing field and shows the highest score.

**Start** Start game.

**Controls:**



**Digit** Shows the number of mines in the surrounding fields.

**\* Δ** Uncovers a field.

**## →** Mark a field that you suspect contains a mine.

**0 + , 5JKL** Uncover if the number of mines and hits is equal.

# Office & Fun

29

## Chronometer

**Menu** → Office & Fun → Chronometer

The following menu is displayed:

---

**Alarm Clock**  
**Stopwatch**  
**Countdown**

---

### Alarm Clock

You hear a beep at the set time.

#### On/ Off

**Change** Press to activate/  
deactivate.

**OK** After activation the time  
can be changed.

 / **OK** Change the alarm time  
(correct with ).

- Setting:  
Beep, see p. 42
- Setting: Clock, see p. 54.

## Stopwatch

Displays time to 100th second.

 Start/stop stopwatch.

 Display interim time. Last  
time is stored.

**Return** Reset to zero.

**Options** Press. The following  
functions are available:

### Save Entry

The current entry can be assigned a  
comment and saved.

### Edit Entry

The comment can be changed.

### Delete Entry

The current entry is deleted.

### Stopwatch List

A list with the relevant entry date is  
displayed.

### Clear List

The list is deleted.

## Countdown

A set period elapses. The last 3  
seconds are indicated by a beep. A  
special beep sounds at the end.

**Change** The period can be entered.

**Start** Starts the counter.

# Messages


You can use your phone to receive and send written messages (SMS) and to receive voice messages and info services.

**Text entry with "T9"** enables you to write long messages very quickly (page 32).

## Reading New Messages




Indicates a new message on the display.



Press.

The message is displayed.

- Line 1: Date and time  
 Line 2: Phone number/ name of sender  
 Line 3: First line of message



Scroll.

## Deleting a Message

At the end of the message you will be asked whether you want to delete this message.

You should always delete messages when possible as the capacity of the SIM card is limited. If it is full ...



... the message symbol flashes and **no more** messages are received.

## Reading old Messages

Saved messages can be selected and then read in the incoming or outgoing list (see p. 34).

## Info

**Options** Access the message menu with further functions (see p. 34).

- A phone number/name inversely displayed in the message can be:



Stored in the Phonebook.



Called.

- New messages may be displayed immediately on receipt (depending on the network).

# Messages

31

## Creating a New Message

**Menu** → **Messages** → **Write Message**  
→ **Create New**



Create the message  
(for text entry see  
page 32).



Open the Text menu.

Select **Send Text**.

## Adding a Phone Number



Enter a phone number or  
select one from the  
Phonebook.

## Send



The message is transferred to the Service Centre for transmission. If the Service Centre's phone number is not stored (p. 35), it must be entered each time a message is sent.

### Set Message Type / Validity Period

The **Variable** setting can be used to change the message type or validity before each call (see p. 35).

## Text Menu

The Text menu offers additional word processing functions, such as:

---

**Send Text**  
**Save Text**  
**Insert Picture**  
**T9 Text Input**  
**T9 Language**  
**T9 Info**  
**Insert Newline**  
**Clear Text**

---

### Send Text

Enter the recipient's phone number or select this from the Phonebook and send.

### Save Text

The text is saved.

### Insert Picture

Symbols can be added to the message. These will only be reproduced on phones that support this function.

### T9 Text Input

Activate or deactivate (see p. 32).

### T9 Language

Select the language you want to use for the message.

### T9 Info

User information.

### Insert Newline

A line break is entered.

### Clear Text


The text field of the editor is cleared.

# Messages

## Text Input With "T9"

"T9" deduces the correct word from the individual key entries by making comparisons with a comprehensive dictionary. Because the display is constantly changing during input, it is best to write a whole word without looking at the display.

## Writing a Message



You simply press the key under which the relevant letter is located **once**, e.g. for "off":

**(6 MND)** + **(3 DEF)** + **(3 DEF)** = 3 x

This is how to end a word:

**(1 00)** Blank.

**(0 +)** Press repeatedly for full stop or comma.

**(▶)** Cursor right.

## Corrections

If the word displayed is not the one you want, then you should try the next one. To do this:

**(1 2 3)** Press. If the word still is not correct, press

**(1 2 3)** again to enter the word **manual**. This word will be automatically added to the dictionary.

## Info

**(◀) (▶)** In T9 mode the cursor jumps from word to word.

**(\*) (Δ)** Switch: Uppercase and lowercase.

**(#) (◀)** Switch: Numbers and letters.

Specific national special characters are automatically used by "T9".

T9 Text Input is a registered trademark and a patented technique from Tegic Communication, Inc..

## Special Characters

Press the key repeatedly until the character appears

**(1 00)** Blank **1 € £ \$ ¥ □**

**(0 +)** **+ 0 - . , : ? ¿ ! i " ' ; \_**

**(\*) (Δ)** **A - a \* / ( ) < = > %**

**(#) (◀)** **A - 1 # @ \ & § Γ Δ † Λ ≡ Π Σ Φ Ψ Ω**

# Messages

33

## Preformatted Messages

The phone contains a number of preformatted messages that only need to be supplemented with the correct time and date.

In standby mode:

**Menu** → **Messages** → **Write Message**, then select the required message:

---

Create New (page 31)  
**Late**  
**Appointment**  
**Anniversary**

---

The cursor appears at the first input point, e.g. in the case of "Late".



Complete the message.



Jump to the next input point.



Enter the phone number or select from the Phonebook.

## Info

- A message is confirmed as sent by the phone with the text "Message Sent". The message is stored in the outgoing list and can be selected and re-read there.
- The "Message sent" text only indicates that the message has been transferred to the Service Centre. The latter now tries to deliver the message within a certain period (see "Validity Period", p.35)
- If the phone was unable to send the message, a retry option is available. If this attempt also fails, then check the phone number of the Service Centre, see p. 35.
-  can be used instead of **Send**
- You can also edit your messages using a PC (see "SoftDataLink 3.0", p.63).
- You can edit messages you receive (see "Edit Message", p.34) and store them or send them as your "own" messages.

## Forward Message

If the message appears on the display:



Press (if no phone number is highlighted).



Enter phone number or select from Phonebook.



Press.

# Messages


## Incoming / Outgoing

Your messages are stored in the incoming and outgoing lists. The number of messages stored is displayed after the relevant function. These can be read, changed and reused.

**Menu** → **Messages** → **Incoming 3 new**  
or **Outgoing 3 new**



The messages appear in chronological order; you can scroll and read as required.



Press 

Highlighting messages in:

### Incoming:

-  Read.
-  Unread.

### Outgoing:

-  Not sent.
-  Sent.

## Message Menu

A message is displayed.

**Options** Select a function.

---

**Reply** (incoming only)  
**Delete Message**  
**Edit Message**  
**Send Message**  
**Capacity**  
**Status Report** (outgoing only)

---

### Reply

**Write Message, Edit Text,**  
**Answer is YES/Answer is NO,**  
**Please Call Back, I'll be late**

The text of a received message can be changed, supplemented or combined with one of the standard reply texts to form a new message.

### Delete Message

The message is deleted.

### Edit Message

The message is displayed in the editor for changes.

### Send Message

Enter a phone number or select one from the Phonebook, then send.

### Capacity

Displays the maximum number of messages and the number of messages already stored.

### Status Report

Subsequent request for a report on the message read.

# Messages

35

## Send Business Cards 35i

**Menu** → **Messages** → **Send Bus. Card**  
 /  Enter phone number or select one from Phonebook and send as a normal message. For creating business cards see p. 27.

Up to 160 characters can be transmitted as SMS.

## Setting

The phone number of the Service Centre can be entered here and other settings can be made.

**Menu** → **Messages** → **Message Setup**, then select one of the following functions

---

**Service Centre**  
**Message Type**  
**Validity Period**  
**Status Report**  
**Direct Reply**

---

## Service Centre

Enter or change the Service Centre phone number supplied by the Service Provider.

## Message Type

Select a message type for sending to special terminals. The different message types (e.g. e-mail) may be assigned to different Service Centre phone numbers. Contact your Service Provider for details.

The current setting is displayed after the function has been called up. To change the setting:

**Change** Select the required type.

---

**Variable**  
**Standard text**  
**Telex**  
**Fax**  
**Email**  
**X400**  
**New**

---

## Variable (default)

The message type has to be confirmed each time before it is sent.

## Standard text

All messages are transferred as normal SMS messages.

## Telex, Fax, Email, X400

Special types of messages.

## New

You may need to obtain the code number from the Service Provider.

## Validity Period

Select the period in which the Service Centre is to attempt to deliver the message:

**Variable, 1 hour, 12 hours, 1 week, Maximum, New.**

## Status Report

You will receive confirmation of whether or not a message you have sent has been delivered. This service may be subject to a charge.

## Direct Reply

The answer to your message is handled via your Service Centre (contact your Service Provider for details).

# Messages

## Voice Message



The Service Centre provides you with an external answering service (mailbox). Calls you cannot answer or do not wish to answer are diverted to this mailbox. The caller can leave a voice message for you there.

The voice mail service may be part of your Service Provider's user package. Otherwise, you will need to register and the settings must be made manually.

The following descriptions may vary, depending on the Service Provider.

## Setting Voice Mail

You will receive two phone numbers from your Service Provider and these are entered as follows:

### 1 Mailbox Number

This is the phone number you call to listen to your voice mail. To set this:

**Menu** → **Messages** → **Voice Message**

 /  Enter the phone number or select it from the Phonebook

**OK** Confirm.

### 2 Divert to Mailbox

Calls will be diverted to this phone number for your mailbox.

A call is always diverted on the basis of a condition (see p. 45). The most frequently used condition, "unanswered calls", has been used in the following example. To set:

**Menu** → **Divert** → **All Unanswered** → **Set**

 Enter the phone number.

**OK** Register call forwarding to the mailbox on the network. Call diversion will be confirmed after a few seconds.


# Messages

37

## Listening to Voice Mail

A new voice mail will be displayed as follows:

 Appears on the display (with a beep)



 Press

You call your mailbox and play back your messages.

**or**



Appears on the display (with a beep).



A written message informs you that a new voice mail has been received.

Call your mailbox.

**or**

You receive a call with an automatic announcement.

## Info



Set the mailbox phone number on the key indicated (see "Speed Dialling Numbers", p.17).

- It may be necessary to call a different mailbox number when outside your home network.
- If a password (digits) is required to access your mailbox, then you can store this in the Phonebook along with the phone number (see page 15).

# Messages

## Information Services

Your Service Provider may offer Cell Broadcast where specific local information is broadcast, e.g. weather and traffic services. Different topics are covered by the various Service Providers.

If "Cell Broadcast" is active, you will receive messages on the active topics in your "Topic List".

**Menu** → **Messages** → **Cell Broadcast**

---

**Broadcast**  
**Read New CB**  
**Set Topics**  
**Auto Display**  
**Topic Index**  
**CB Language**

---

## Broadcast

You can activate and deactivate the CB service. The operating time of the phone will be reduced if the CB service is activated.

## Read New CB

All unread CB messages are displayed (across the whole display).

## Set Topics

You can add 5 topics to this personal list by selecting them from the Topic Index (see p. 39) or entering them yourself with the name and channel number. Depending on the SIM card, other channel numbers without names may be possible.

## New Topic

Select **<New Topic>**.

- If there is no Topic Index as yet (see p. 39), then

 / **OK** Enter the topic and the channel number.

**Select** Press.

- If the Topic Index has already been transmitted, then

 select a topic.

**Select** Press.

## Selection from a List

You can edit entries in the topic list.

 Select a topic.

**Options** Select the required function.

## View Topic

If a message exists for the selected topic, then it will be displayed.

## Activate Topic/Deactivate Topic

## Edit Topic

You can change the name and channel number.

## Delete Topic

The topic is deleted from the list after confirmation.

## View Topic ID

The channel number is displayed.

# Messages

39

## Auto Display

CB messages are displayed in standby mode and long messages are automatically scrolled.

 / **View CB** Press.

Switches to "Full page view".

Automatic display can be set for all messages or only for new messages, or can be deactivated.

A beep can be set for this purpose (see p. 42).

## Topic Index

The list of topics currently provided by your Service Provider is displayed for selection purposes.

If no list appears, then the IDs can be entered manually (see p. 38). Please consult your Service Provider for further details.

## CB Language

You only receive Cell Broadcast messages in the selected language. "All Languages" means that messages are received in all languages.

## Info

### Displays



Topic activated



Topic deactivated



New messages received on the topic



Messages on the topic already read.

Phone numbers in inverse display can be



dialled.



stored in the Phonebook.

## Records

The phone records the phone numbers of the most recent calls, enabling you to call back.

**Menu** → **Records**, then select the call list.

**Calls missed**  
**Calls received**  
**Calls dialled**  
**Alarms missed**



Scroll and select a phone number from the list.



The highlighted phone number is dialled.

### Calls missed



The phone numbers of calls you have received but not answered can be recorded for call back purposes. (Providing the network supports the “Caller Identity” feature). Please note that the caller may have left a Voice Mail (see p. 36).

### Calls received



Numbers can only be listed if the network used supports the “Caller Identity” feature.

### Calls dialled

Fast access to the last phone numbers you dialled. In standby mode:



Press.

### Call List Menu

The Call List Menu can be called up if an entry is highlighted in the display.

**Options** Select the required function:

**View Entry**  
**Edit Number**  
**Save Number**  
**Clear List**

#### View Entry

The phone number, name (if available) and time of the call are displayed.

#### Edit Number

A phone number can be edited and then dialled or transferred to the Phonebook (see p. 11).

#### Save Number

A phone number can be transferred to the Phonebook (if not already contained there).

#### Clear List

The complete Call List is deleted after confirmation.

### Alarms missed

Appointment alarms you have failed to respond to are listed and can be displayed and edited (see also p. 24).

# Profiles

41

You can store individual settings for certain functions in a personal profile, or select one of three standard profiles.

If, for example, the phone is used by different users, each one can activate their settings by selecting their own profile.

**Menu** → **Profiles**, then select the required profile:



## Standard Profiles

You can choose between the following "Situations":

Normal  
Quiet Environm.  
Noisy Environm.



Scroll and select the required profile.

**Options**

The Profile Menu is displayed.

## Personal Profiles

To set your personal profile:



Scroll to: **<Empty>**

**Options**

The Profile Menu is displayed.

## Profile Menu

Activate Profile  
Change Settings  
Rename

### Activate Profile

A selected profile is activated.

▶ Profile activated

### Change Settings

A list of adjustable functions is displayed:

Ringer Setting	p. 42
Volume	p. 42
Melodies	p. 42
Vibration	p. 42
Call Screening	p. 42
Service Tones	p. 43
Key Tone	p. 47
Expert Mode	p. 48
Big Letters	p. 48
Bitmap Style	p. 48

Select the required function and adjust the settings in the usual way. When a setting is complete, you will automatically return to this selection list.

All settings are stored in the current profile.

### Rename

You can give the selected profile a new name (this does not apply to the standard profiles).



→ **Audio**,  
then select one of the  
following functions:

---

**Ringer Setting**  
**Volume**  
**Melodies**  
**Vibration**  
**Call Screening**  
**Service Tones**  
**Record Melody**

---

## Ringer Setting

The ringer can be activated and deactivated or reduced to a short signal.



Display if ringer is deactivated.



Ringer on/off

## Volume

The volume can be set differently for a variety of signals:

---

**Any Call**  
**Call**  
**VIP-Call**  
**Alarm**  
**Message**  
**Cell Broadcast**

---



Display for increasing volume.

## Any Call

If two independent phone numbers are registered for your phone, you have the following choice:

---

**Both Lines**  
**Line 1**  
**Line 2**

---

## Melodies

You can also set a melody instead of a signal (same procedure as for volume).

A variety of melodies are provided, or you can compose your own melody (see p. 43).

## Vibration

If you do not wish to disturb those around you, you can activate the vibrator instead of the ringer. This can also be activated in addition to the ringer (e.g. in a noisy environment).

## Call Screening



Only those calls with phone numbers stored in the Phonebook or VIP Phonebook are signalled acoustically.

Other calls only appear on the display. If you do not answer these calls, they will be diverted to your mailbox (if activated, p. 36).



Display when active.

# Audio

43

## Service Tones

The following service and alarm tones can be activated or deactivated:

---

All  
Welcome/£.bye  
Network found  
Warnings  
End of Menu

---

## Record Melody

You can compose a melody of your own and then use it in the same way as the melodies provided (see p. 42).



Keys 1 to 8 correspond to the notes C, D, E, F, G, A, B and C.

If you hold down the keys, the length of the note will change.

From 1/16 to 1/8, 1/4 etc.



Insert a pause.



Change octaves.



Change to semi-tones.



Correction.

**Save Melody** Save the melody you have composed.

**Playback** Listen to the melody you have composed.

## Time/Charge

You can display the charge details and duration of calls as you speak, as well as setting a unit limit for outgoing calls.

**Menu** → **Time/Charge**,  
then select a function:

---

**Charges**  
**Charge Setup**

---

### Charges



When you have adjusted the settings (see below) you can display the details of the following calls:

---

**Last Call**  
**All Calls out**  
**All Calls in**

---



Scroll and select the required call.

**Select** Display the data.

After the data has been displayed, you can:

**Clear** Clear the display.

**Options** If a restriction exists (see right) then the remaining credit or time is displayed.

### Charge Setup

#### Currency

Enter the currency in which charge details are to be shown.

#### AdviceOf Charge



If your network supports charge detail display, then the current units are shown.

If you have set the charge per unit, then the costs incurred are displayed.

It may be necessary to register separately for this service.

#### Personal Rate

Enter the charges per unit/period.

#### Charge Limit



Special SIM cards allow you or the Service Provider to define a credit/period after which the phone is blocked for outgoing calls (PIN2 required).

**Change** Press.



**OK** Enter the number of units.

Then confirm the credit or reset the counter.

#### Combined In/Out

Display the call time/ charge details for all calls.

#### Charge Incoming

Display the charge details for incoming calls if this is billed separately.

#### Auto Display

The length of call and charge details are displayed after every call.

# Divert

45

This network function diverts calls to your mailbox or to other numbers chosen by yourself. This means that you are always reachable.

**Menu** → **Divert**,  
then select a function:

---

**All Unanswered**  
**All Calls**  
**Specific Divert**  
**All Calls**  
**All Fax Calls**  
**All Data Calls**  
**Status Check**  
**Clear all Diverts**

---

## Divert

The most common condition for call diversion is:

**unanswered calls.**

This and other conditions are set in the same way:

**Menu** → **Divert** →  
**All Unanswered** → **Set**

If a phone number is not yet entered to which calls are to be diverted:

 /  Enter the phone number.

**OK** Confirm.

or

 Press if offered, to divert to your mailbox.

After a short pause the setting is confirmed by the network.

## Divert Conditions

### All Unanswered

This covers the key conditions (see also below):

- If not Reachable
- If no Reply
- If Busy

### All Calls

All calls are diverted.

 Symbol in display.

## Specific Divert

Different call types can be diverted to different phone numbers with the following conditions.

### - If not Reachable

Call diversion if the phone is deactivated or out of range.

### - If no Reply

A call is only diverted after a delay. The period can be set in intervals of 5 seconds up to a maximum of 30 seconds.

### - If Busy

Calls are diverted when a call is in progress.

### All Fax Calls

Fax calls can be diverted to a phone number with a fax connection.

### All Data Calls

All data calls can be diverted to a phone number with a PC connection.

## Status Check

A check is made in the Service Centre to see which call diversions are set.

If you wish to check a certain call diversion, including the number, then first select the condition, followed by **Status Check**.

After a short pause the network will transmit and display the current situation.

-  Indicates a set condition.
- ?
- Indicates an unknown status (e.g. new SIM card).

### Info

Please note that call diversion is stored in the network and not in the phone (e.g. when the SIM card is changed).

## Clear all Divertss

All set call diversions are deleted.

## Reactivating Call Diversion

The last call diversion destination was stored.

Proceed as with **Divert**.

The stored phone number is displayed.

 Confirm.

## Changing Phone Numbers

Proceed as with **Divert**. When the stored phone number is displayed

-  Delete the phone number.
-  /  Enter the new phone number
-  Confirm.

# Setup

47

## Menu Mode

**Menu** → **Setup** → **Menu Mode**

To make it easier for new users to learn how to operate the phone, the comprehensive Main Menu is reduced to the key functions (see also p. 21).

These functions can now be called up directly (without intermediate steps).

---

**Calls dialled**  
**Calls missed**  
**Voice Message**  
**All Unanswered**  
**Incoming Messages**  
**Write New Msg**  
**All Serv. Tones**  
**Volume for all Calls**  
**Melody for all Calls**  
**Profiles**  
**Menu Mode**

---

The **Menu Mode** function returns you to the comprehensive Main Menu.

## Device

**Menu** → **Setup** → **Device**,  
then select a function.

## Language

You can select the required language for the display texts. If "Automatic" is set, the language used by your Service Provider is used.

If a language happens to be set that you do not understand, you can reset the phone to the language used by the Service Provider by making the following entry:

\*#0000# 

## Keys

### Any Key Answer

You can answer incoming calls with any key (except .

### Auto Key Lock

This activates automatically when no key has been activated for one minute. This prevents accidental activation of the phone keys, although you can still be reached and can make emergency calls.

This lock can also be activated and deactivated with the keypad.

 Hold down.

### Key Tone

You can set the type of acoustic key tone:

**Key Click, Key Tone, Key silent**

## Display

### Illumination

Display illumination can be activated and deactivated (to prolong standby time).

### Big Letters

You can change the size of the letters shown on the display.

### Bitmap Style

You can choose from one of three styles for the graphics/animations on the display.

### Own Greeting

You can write a greeting that will appear when the phone is activated.

 Press to activate and deactivate.

 Press to change.

 Delete existing greeting and write a new greeting.

 Confirm your change.

### Animation

You can deactivate the animation in the display.

## Status

### Master Reset

The phone is reset to default values (does not apply to SIM card and network settings).

See also page 57 "Reset".

### Phone Identity

The phone identity number (IMEI) is displayed. This information is helpful for service purposes.

### Expert Mode

Fast activation and deactivation of functions, bypassing intermediate queries and displays.

### Fast Search

You can speed up network reconnection if this function is activated. This reduces usage time.

### Erase Records

(Phone code p. 49)

The following lists are deleted (see also p. 40):

- Calls missed
- Calls received
- Calls dialed
- Alarms missed

## Battery Care

This function can be used to regenerate the NiMH battery when the usage time begins to decrease (elimination of the memory effect).

Connect the phone as for charging (see page 6).

 → Setup → Device → Battery Care.

The battery is now fully discharged and recharged. Depending on the initial status, this can take between 3.5 and 5 hours.

Phone calls cannot be made during this procedure. The clock setting will be preserved.

# Setup

## Security

The phone and SIM card are protected from misuse by several security codes.

Your **SIM card** is protected by a **PIN** (Personal Identification Number).

A **PIN 2** is required for the additional functions available with a special SIM card.

A code (**PUK**) is also provided for unlocking the SIM card if you have forgotten the PIN.

Your **phone** is protected by the **phone code**, which you can enter yourself when making the first security setting (4 - 8 digits).

**Keep these confidential numbers in a safe place where you can access them again if required.**

**Menu** → **Setup** → **Security**,  
then select a function:

## Babysitter

(Phone code)

Calls are limited to **one** phone number, which is dialed with the right soft key.

 / **OK** Enter the phone number and name.

or

 / **OK** Select a number from the Phonebook.

### Ending the Function:

 Hold down (phone code is requested).

## Allow only

(PIN 2/phone code)

Dialling options are limited to numbers in the Phonebook; new entries cannot be made. If only local codes are entered, the relevant phone numbers can be added to these before dialling.

Depending on whether the Phonebook is stored on the SIM card or in the phone, the PIN 2 or the code will be requested before changes can be made.

## Allow last 10 numbers

(Phone code)

Calls are limited to the call list of the "selected numbers".

This call list can be filled with specific phone numbers for this purpose:

Delete the call list (p. 40), then create "new entries" by dialling phone numbers and hanging up before a connection is made:

 or  ,  followed by .

## Loan Phone

(Phone code)

You can limit the use of the phone by others.

The following general locks are set with "Loan Phone":

- **Prevent newSIM** active (see p. 50)
- Charge detail counter cannot be deleted
- Charge rate cannot be changed

## PIN Control

The PIN is normally requested each time the phone is switched on. You can deactivate this control here, but this would risk unauthorised use of the phone by a third party. Some Service Providers do not permit this function.

## Codes

### Change PIN

You can change the PIN to any 4 - 8 digit number (i.e. a number you may find easier to remember).

**Menu** → **Setup** →  
**Codes** → **Change PIN**



Enter the current PIN.



Press.



**OK** Enter the new PIN



**OK** Enter the new PIN again.

### Change PIN 2

You can change PIN2 to any 4 - 8 digit number (only displayed if PIN2 is available).

Proceed as described under **Change PIN**.

### Change Phonenumber

You can change the phone code to any 4 - 8 digit number.

Proceed as described under **Change PIN**.

## Prevent newSIM

This prevents your phone from being used with another SIM card.

## Network

**Menu** → **Setup** → **Network**,  
then select a function:

### Line



This function is only displayed if supported by the Service Provider. Two independent phone numbers are registered for the phone.

### Select line

Select the currently used phone number.

If this is changed frequently, it is more convenient to make the selection using the soft key (see p. 16).

**Left Arrow** › Display the active phone number.

### Lock Line

(Phone code, p. 49)

You can restrict usage to one phone number.

### Info

Special settings can be made for each phone number (e.g. melody, call diversion, etc.). Switch to the required phone number first.

To switch the lines (in standby mode):



Press, then:



Press.

# Setup

51

## Configuration

### Network Info

The list of currently available GSM networks is shown.



Marks the Service Providers not permitted by your SIM card.

### Change Network

Network search is restarted. This is useful if you are not in your home network or if you wish to register in another network.

If "automatic network" is activated, the next network is selected in the order of the list of your "preferred Service Providers".

Otherwise, a different network can be selected manually from the list of available GSM networks.

### Auto Network

Activate or deactivate, see also "Select Network" above.

### Operator List

A list of all known GSM Networks worldwide and their respective codes is displayed.



Select an entry.



Press.

A new Network can be added to the list (enter the national code and network code).



Select <Empty>.



Press.



/ OK Make an entry.

### Preferred Network

The Networks you prefer after your home Network are displayed in this list (e.g. if there are several networks that differ in price).

When this function is activated, your home Network is displayed first.



Display list of preferred Networks.

- New entry:



Select <Empty>.

Select an entry from the list of Networks.



Confirm.

- Change/delete old entry:



Select existing entry.



Select a different entry from the list of Networks.



Confirm.

or



Delete the entry

## Barring



Barring restricts the usage of your phone (not supported by all Service Providers). Security takes the form of a four-digit password supplied by your Service Provider. You must be registered separately for each barring.

### All Calls out

All outgoing calls, except emergency number 112 and 999, are barred.

### Out International

Only national calls can be made.

### Out Internat. excl. Home

International calls are not permitted. However, you can make calls to your own Service Provider when abroad.

### All Calls in

The phone is barred for all incoming calls.

### InWhen Roaming

You receive no calls when outside your home network. This means that no charges are incurred for incoming calls.

### Status Check

The following information may be displayed after a status check:



Barring set



Barring not set



Status unknown (e.g. new SIM card).

### Clear all Barring

All barrings are cleared.

## During Calls

**Menu** → **Setup** → **During Calls**, then select a function:

### Call Waiting



If you are registered for this service, you can check whether it is set and activate or deactivate it (see also p. 18).

### Conceal ID



When you make a call, your phone number appears on the recipient's display (depending on the called party's Service Provider). To suppress this display on the destination phone, you can activate "Conceal ID" mode for the next call or all subsequent calls. You may need to register separately with your Service Provider for this function.

### Minute Beep

During a call you hear a beep every minute as a reminder of the time elapsed.

# Setup

53

## FAX/Data Mode

**Menu** → **Setup** →  
**FAX/Data Mode**,  
then select a function:

You can use the phone and a connected PC to send and receive faxes and data (see also p. 55).

### Prerequisites:

The use of fax and data services must be enabled.

Depending on the network, there are several types of fax/data reception, so you should check with your Service Provider.

### Self Test

PC connection is checked.

### Send Speech/FAX

If this function is activated, the following soft key is available for 2 seconds after the connection is established:

**Sp/Fax** Press. You can now switch from speech to fax mode during a call in order to send a fax.

Otherwise, the call is treated as a normal call.

## Receive Speech/FAX

(**Only** if the phone numbers for speech and fax reception are identical).

Switch to fax mode during a call.

### Receive FAX/Data

(**Only** if the phone numbers for speech and fax reception are identical).

When this function is switched on and the connection to the PC is active, **only** fax or data calls can be received. The PC automatically accepts the fax or data call, depending on which communication program is active.

When this function is switched on voice calls can only be accepted if the connection to the PC has previously been interrupted.



# Setup

## Clock

**Menu** → **Setup** → **Clock**,  
then select a function:

### Time&Date

The clock must be set correctly during start-up.

**Change** Press.

 / **OK** First the date (day/month/year), then the time (24 hour clock plus seconds).

The clock must be reset if the battery is removed for longer than 30 seconds.

### Format Date

Date format setting:  
**DD.MM.YYYY** or **MM/DD/YYYY**

### Auto Display

The time display can be switched on or off.

### Auto Phone off

The phone switches off at the set time.

#### Set

**Clock** Press.

 Enter the time (24 hour clock)

**OK** Confirm.

#### Deactivate

**manual** Press.

**OK** Confirm.

## Car Use

**Menu** → **Setup** → **Car Use**,  
then select a function:

### Auto Answer

Calls are answered after the 3rd signal tone if the phone is connected to the "Portable", "Comfort" or "Professional" Car Kit. Depending on the installation, the ignition may need to be switched on for this.

 Indicator on the display.

### Auto Power Off

The phone is powered by the car's power supply and is switched on and off with the ignition. The time between the switching off of the ignition and the deactivation of the phone can be adjusted.

## Head Set

**Menu** → **Setup** → **Head Set**

Calls are answered after the 3rd signal tone if the headset is connected

#### Info

##### Headset (p. 63)

To change to hand-held mode during a call (phone connected to headset)

 Press to switch on and off.

##### Car handset (p. 64)

Phoning with a car handset.

# Fax/Data

55

## Technical Information

### Fax/ Data Prerequisites

Fax and data services must be enabled.

Depending on the network, there are several different types of fax/ data reception, so you should check with your Service Provider.

Your PC must have appropriate software installed for data/fax communication.

### Connecting Units

A data cable (see p. 63) is used to connect the phone to the PC's serial port.

### Setting the PC

Your phone has an integral modem. You will need to install a standard modem in your PC's operating system:

- Standard modem with 19 200 bit/s
- Fax Class 1 modem, max. 9 600 bit/s

### Sending Fax or Data

- During a call

First set the **Send Speech/FAX** function (p. 53) and then start your PC's communication program.

- Fax only

Start your PC communication program. Enter the required destination phone number.

## Receive Fax or Data

Before you receive data/faxes, establish the connection between the phone and the PC and start the communication program on your PC.

The phone display will indicate the type of call (fax or data) and you will hear a special signal tone.

## Ending Transmission

Transmission is normally ended with the PC software. If necessary:



Press.

## Technical Data

### Modem Driver

Conforms to V.25 command set.

### Data transmission speed

Conforms to the ITU-T standard of V.22bis (transfer at 2400, 4800 and 9600 bit/s).

### Facsimile

Facsimile operation at 2400, 4800, 7200 and 9600 bits/s. Conforms to Service Class 1

## Display Symbols

The following symbols are displayed during operation:

### Display Indicators

	Incoming signal strength.
	Battery being charged.
	Battery indicator.
	All calls diverted.
	Ringer off.
	Short beep only.
	Call Screening. Only "known" calls will ring.
	Alarm set.
	Keypad locked.
	Low-level encryption.
	Indicates UPPER/ lower case.
	Phonebook in SIM card,
	Phonebook in phone,
	Restricted Phonebook.
	Service/number barred
	Phone number 1 or 2 active.
	Menu function active.
	Indicates an unknown status of network feature.
<b>DATA</b>	Receive only data.
<b>FAX</b>	Receive only fax.
	Automatic call answering active

### Organizer Icons

	Memo.
	Meeting.
	Call.
	Birthday.
	Calculator functions.
	Calculator memory.
	Recurring alarm.

### Soft Keys

	Short press clears last character, long press clears entry.
	Message received. Press to read it.
	Voice mail received. Press to hear it.
	Unanswered call. Press to see identity.
	SIM services.
	Switch to handset.
	Save in Phonebook.
	Vertical scrolling.
	Horizontal scrolling.

# Tips on Use

57

## Deactivate Ringer



**Hold down in standby mode.** All signal tones are activated/deactivated temporarily or reduced to a short tone.



**Hold down for incoming calls.** The signal tone for the current call is deactivated.

## Activate/Deactivate Key Lock



**Hold** down in standby mode.

## Softkey



Press until number is dialed. "OK" is skipped over in this case. Can also be implemented for fast access keys.

## International Prefix



Press the key until the "+" sign appears.



Press and select country.

## Call Mailbox



This digit key is reserved for the mailbox (see page 37).

## Send Messages



Press this key instead of **Send**.

## Phonebook

### International Prefix

An international prefix e.g. +49 for Germany should always be assigned to all numbers. You can then make calls from abroad without difficulty.

### Name Search

If there are several entries for one letter, it is sometimes advisable to jump to the next letter and then scroll backwards.

### Name Assignment

For example, assigning several numbers to one person:  
Carol O (for Office)  
Carol H (for Home)

## Redialling

Redials the last number dialed.



Press twice.

## Reset phone

All phone settings are reset to the default status.

Enter **\*#9999#** and press . SIM card and network settings are unaffected.

# Siemens Service

Worldwide support from Siemens Partners is just a phone call away. Alternatively, use the Internet

Internet: <http://www.siemens.com/cd.service>

Abu Dhabi .....	Siemens Service Centre..	02 71 35 00	Malaysia .....	Hello service .....	0 32 41 59 93
Egypt .....	Siemens .....	23 31 31 29	Morocco .....	SETEL S.A .....	2 35 24 09
Australia .....	Siemens .....	18 00 62 24 14	Mauritius .....	Ireland Blyth .....	2 11 62 13
Bangladesh .....	Siemens .....	0 17 52 74 47	Netherlands .....	Siemens .....	0 70 3 33 31 00
Belgium .....	Siemens .....	0 78 15 22 21	Norway .....	Siemens .....	22 63 33 14
Brunei .....	DST .....	0 21 51	Austria .....	Siemens .....	01 17 07 50 04
Bulgaria .....	Omnitel .....	02 73 94 88	Oman .....	Siemens Service Centre .....	79 10 12
China .....	Siemens .....	0 21 50 31 81 49	Pakistan .....	Siemens .....	02 15 67 35 65
Germany .....	Siemens .....	0 18 05 33 32 26	Philippines .....	Siemens .....	28 14 98 88
Croatia .....	Siemens .....	016 10 53 81	Poland .....	Siemens .....	08 00 22 09 90
Denmark .....	Siemens .....	35 25 86 00	Portugal .....	Siemens .....	0 14 17 83 93
Dubai .....	Siemens Service Centre..	04 69 97 20	Russia .....	Siemens .....	8 09 57 37 18 01
Finland .....	Siemens .....	09 22 94 37 00	Saudi Arabia .....	Arabia Electric .....	0 26 65 50 58
France .....	Siemens .....	01 56 38 42 00	Sweden .....	Siemens .....	0 87 50 99 11
Greece .....	Siemens .....	0 16 86 43 89	Switzerland .....	Siemens .....	0 12 12 00 90
Hong Kong .....	Siemens .....	22 58 36 36	Singapore .....	Siemens .....	8 45 48 18
Iceland .....	Smith & Norland .....	5 11 30 00	Slovak Rep.. .....	Siemens .....	07 59 68 22 66
India .....	Siemens .....	1 16 92 39 88	Slovenia .....	Siemens .....	06 11 74 63 33
		1 16 92 55 89 (ISDN)	South Africa .....	Siemens .....	08 00 11 40 50
Indonesia .....	Dian Graha Elektr. ....	02 14 61 50 81	Spain .....	Siemens .....	9 02 11 50 61
Ireland .....	Siemens .....	18 50 77 72 77	Taiwan .....	Siemens .....	02 25 18 65 04
Italy .....	Siemens .....	02 69 89 36 91	Thailand .....	Siemens .....	26 79 17 77
Jordan .....	F.A. Kettaneh .....	0 79 55 96 63	Czech. Rep.. .....	Siemens .....	02 24 19 92 59
Kuwait .....	NGEECO .....	4 81 87 49	Turkey .....	SIMKO .....	021 22 52 88 35
Lithuania .....	Siemens .....	7 50 11 14	Great Britain .....	Siemens .....	09 90 33 44 11
Lebanon .....	F.A. Kettaneh .....	01 44 30 43	Hungary .....	Siemens .....	06 14 71 24 44
Latvia .....	Siemens .....	8 22 39 15 55	Vietnam .....	Opticom .....	0 90 45 67 89
Luxembourg .....	Siemens .....	43 84 33 99			

# Troubleshooting

If you encounter problems using your phone, please try to find a solution using the "Troubleshooting" table below. If the problem persists, contact your Service Provider or Siemens Service (see p. 58).

Problem	Possible Causes	Possible Corrective Measures
Unable to switch phone on	On/Off key not pressed long enough	 Press on/off key for at least 2 seconds
	Empty battery.	Charge battery. Check charging indicator in display.
	Battery contacts dirty.	Clean contacts.
	Battery totally discharged.	Charge battery for half an hour, detach the charging cable briefly, then charge as normal.
Standby time insufficient	Frequent use of organizer/games.	Restrict use if necessary.
	Memory effect	Carry out battery care function (see p. 48)
	Economy power mode not activated.	Activate economy power mode (see p. 48).
	Display illumination active.	Switch off display illumination (see p. 48).
	Keys pressed unintentionally (illumination!)	Activate key lock.
Charging error (no charging display)	Battery totally discharged.	Charge battery for half an hour, detach the charging cable briefly, then charge as normal.
	Temperature exceeds -10 °C to +45 °C range.	Make sure the ambient temperature is right, allow time, then charge again.
	Contact problem.	Check mains socket and connection to phone. Check battery contacts and clean if necessary, then insert the battery again.
	No mains power	Connect to a different mains socket or check the mains supply.
	Charger defective	If the charger does not warm up, replace it.
	Wrong charger	Only use Original Siemens accessories.
	Battery defective.	Replace battery.
SIM error	SIM card not correctly inserted	Make sure that the SIM card is inserted correctly. The card carrier must engage (see p. 5).
	SIM card contacts dirty	Clean the SIM card with a dry cloth.
	SIM card has wrong volt rate	Only use 3 volt SIM cards
	SIM card damaged.	Make visual check. Return SIM card to Service Provider.

# Troubleshooting

Problem	Possible Causes	Possible Corrective Measures
No connection to network	Signal weak.	Move higher, to a window or open space.
	Outside GSM coverage.	Check Service Provider coverage map.
	SIM not valid	Contact Service Provider for replacement SIM
	New network not authorised	Try reselecting manually or try a different network (see p. 51)
	Barring set. Network overloaded	Check barring (see p. 52) Try again later.
Phone loses network	Signal too weak.	Reconnection or connection to another Service Provider is automatic (see p. 50). Switching off and on may accelerate this.
Calls not possible	Dialling error.	Redial
	2nd line set.	Set different call line. (see p. 50)
	New SIM fitted.	Check for new restrictions.
	Charge limit reached.	Call your Service Provider or use PIN 2 to reset (see p. 44).
Certain calls not possible	Call restrictions set.	Restrictions may be set by your Service Provider. Check restrictions (see p. 50).
	Phone number has more than 20 digits	Check phone number.
Cannot save in Phonebook	Call restriction set.	Check restrictions (see p.49).
	Phonebook is full.	Delete some Phonebook entries (see p. 14).
Cannot change Phonebook	SIM restriction set	Call ServiceProvider.
Cannot find Phonebook	SIM has been changed	Refit original SIM.

# Troubleshooting

Problem	Possible Causes	Possible Corrective Measures
Voice Mail not working	Divert not set.	Set divert (see p.45).
"✉" flashing	Message store full.	Delete messages to make room (see p.30).
Cannot send a message	Service Providers do not support this service.	Check with Service Provider.
	Service Centre phone number incorrect or not set.	Set Service Centre (see p.35).
	SIM card contract does not support this service.	Contact Service Provider.
	Service Provider overloaded	Try again.
	Destination does not have a compatible phone.	Check with Service Provider.
Cannot set a function	Not supported by Service Provider or registration required.	Contact Service Provider.
Charge counter not working	Charge unit pulse not transferred.	Contact Service Provider.
PIN error	3 incorrect entries.	Enter the MASTER PIN (PUK) provided with the SIM as instructed. If you have lost the MASTER PIN or PIN, contact the Service Provider.
Phone CODE error	3 incorrect entries.	Contact Siemens Service (see p. 58).
Service Provider CODE error	No authorisation for this service.	Contact Service Provider.
Too few/too many menu entries	Functions may have been added or removed by the Service Provider using the SIM card	Check with the Service Provider.
Fax function unavailable	Incorrect settings in PC.	Check settings (see p. 53).
	No authorisation for this service.	Contact Service Provider.
Accidents		
Severe shock	Remove and refit the battery and SIM. Do not dismantle.	
Immersion in water	Dry immediately with cloth; do not heat. Dry connector contacts thoroughly. Remove and dry the battery and SIM. Stand unit upright in an air current. Do not dismantle.	

## Specifications / Care of Phone

### Licensing

Your phone is authorised for use on GSM networks with its IMEI number and complies with the following EU directives:

- 89/336/EEC "Electromagnetic Compatibility"
- 98/13/EC, CTR 19 and CTR 20 "Telecommunication Terminal Directive"
- 98/13/EC, CTR 31 and CTR 32 "Telecommunication Terminal Directive"
- 73/23/EEC "Low Voltage Directive" as amended by 93/68/EEC



### Technical Specifications

- GSM Class 4 (2 Watt)  
Frequency range  
880 - 960 MHz
- GSM Class 1 (1 Watt)  
Frequency range  
1710-1880 MHz

Weight : 110 g  
Size : 118 x 46 x 21 mm  
(88 ccm)

Operating voltage: 3.6 V  
Power consumption:  
max. 400 mA

Operating temperature:  
0°C to 45°C

Standby time : up to 180 hours  
Talk time : up to 5 hours

### Care of your SIM Card

- The SIM card should be treated with the same care as a cheque guarantee card. Do not bend or scratch it or expose it to static electricity.
- Clean the card with a damp cloth or anti-static wipe without chemical cleaning agents.
- Protect the phone from shocks and moisture. Never leave your phone in direct sunlight (max. 55°C)
- Remove the battery if you are not going to use the phone for extended periods of time.

#### Phone ID

You are advised to write down the following details (to help recovery of your phone or SIM card):

No. of SIM card (on the card)

.....

15-character phone serial number  
(under the battery):

.....

Service Provider's Customer  
Service number:

.....

#### Loss

If your phone and/or SIM card are lost or stolen, call your Service Provider immediately to prevent misuse.

## Accessories

63

### Spare Battery

L36880-N4001-A100 (NiMH, 500 mAh)

L36880-N4001-A101 (Li-Ion, 600 mAh)

### Travel Charger

L36880-N4001-A103 (EU)

L36880-N4001-A104 (UK)

Similar to standard charger but automatically enables worldwide voltage range 100 - 240 V.

### Desktop charger

L36880-N4001-A102



This convenient stand enables the battery in the phone and a spare battery to be charged at the same time. Can be used together with the original charger or the travel charger.

### Headset (PTT)

L36880-N4001-A123



Offers freedom of movement when on the move or in your car, includes PTT (Push To Talk) key for convenient operation.

### Belt Clip

L36880-N4001-A113



The phone can be fastened securely and simply to your belt.

### Case

L36880-N4001-A119

This attractive case protects against dirt and environmental surroundings.

### SoftDataLink 3.0

L36880-N4001-A122

This software includes the following functions for Windows® 95/98/NT/CE, Palm III™/V™ and Psion® Series 5:

- Sending, receiving and writing messages (SMS)
- Convenient Phonebook and Organizer administration
- Composing ring tones

### Data Cable

L36880-N3101-A102

For connecting the phone to the RS-232 port of a PC.

## Accessories



Ensure that vehicle functions (e.g. Airbag) are not obstructed when installing car accessories.

### Cradle

L36880-N4001-A109

For connecting the Car Charger, Portable Car Kit and Headset.

### Antenna Cradle

L36880-N4001-A110

The cradle with connector for an external antenna eliminates radiation and interference risks and offers improved reception. For connecting the Car Charger, Car Headset and Car Kit Portable.

### Car Charger Cable

L36880-N4001-A108

This fits standard cigarette lighter sockets (12/24 Volt). It can be used together with the Antenna Cradle.

### Car Kit Portable

L36880-N3015-A117



Hands-free kit with integral loud-speaker and microphone and auto talk feature. It simply plugs into the standard cigarette lighter socket, enabling easy movement between vehicles. It can be used together with the Antenna Cradle.

### Car Kit Comfort

L36880-N4001-A111



This ensures safe and relaxed communication with high speech quality (full duplex and digital technology) whilst driving.

### Car Kit Professional Voice

L36880-N4001-A124 (English)

L36880-N4001-A125 (German)



Voice Control

State of the art Voice Recognition System for safe and convenient calling. Contains everything needed for installation in a car.

### Data Cable Professional

L36880-N3101-A112

For connecting Car Kit Professional Voice to the serial data cable for data applications.

### Car Handset

L36880-N3015-A123

The handset enables optimum confidentiality when connected to Car Kit Comfort or Car Kit Professional Voice.

## Index

**A**

Accessories .....	63, 64
Add picture .....	13
Advice of Charge .....	44
Alarm clock .....	29
Answering/ending calls .....	10
Appointments .....	24
Audio .....	42
Auto Power Off .....	54

**B**

Babysitter .....	49
Barrings .....	52
Battery Care .....	48
Big letters .....	48
Bitmap style .....	48
Bookmarks .....	23
Browser .....	23
Business card .....	27

**C**

Calculator .....	25
Call diversion .....	45
Call lists .....	40
Call Menu .....	20
Call transfer .....	20
Call waiting .....	18
Calls	
answering .....	10
ending .....	10
rejecting .....	18
several simultaneously .....	19
Car accessories .....	64
Car use .....	54
Care of phone .....	62
CB services .....	38
Change PIN .....	50
Charge battery .....	6
Charger .....	6
Charging time .....	6
Chronometer .....	29
Clock setting .....	54

Codes .....	50
Conceal ID .....	52
Conference .....	19
Control codes (DTMF) .....	15, 20
Countdown .....	29
Currency converter .....	26

**D**

Data communication .....	53
Default status .....	57
Default values .....	48
Deleting messages (SMS) .....	34
Dialled numbers .....	40
Display .....	48
Display symbols .....	56
Divert to mailbox .....	36
DTMF code	
send .....	20

**E**

Emergency call (SOS) .....	6
Extending numbers .....	12

**F**

Fast access .....	16
Fax .....	53

**G**

Games .....	28
Greeting .....	48

**H**

Headset (accessories) .....	54, 63
Home network .....	51

**I**

Illumination .....	48
IMEI number .....	48, 62
Incoming/outgoing messages .....	34
Information channel .....	38
Information services .....	38
International dialling code .....	8
Internet .....	22

**L**

Language setting .....	47
Last 10 numbers dialled .....	49
Licensing .....	62
Loan phone .....	49
Loss of phone/SIM card .....	62

**M**

Mailbox .....	36
Mailbox phone number .....	36
Main menu .....	21
Melody .....	42
Menu, scope .....	47
Messages (SMS)	
forwarding .....	33
preformatted .....	33
reading new .....	30
setting .....	35
writing .....	31
Microphone on/off .....	20

**N**

Network info .....	51
Notebook .....	18

**O**

Own greeting .....	48
Own numbers .....	12

**P**

Phone code .....	49
Phone ID (IMEI) .....	48
Phone memory .....	14
Phone number restrictions .....	15
PhoneBook	
new entry .....	11
restrictions .....	15
PIN	
entry .....	7
error .....	61
Preferred network .....	51
Prefix .....	8

Preformatted messages .....	33
Prevent new SIM .....	50
Profiles .....	41
PUK .....	49

**R**

Record melody .....	43
Redial list .....	9
Redialling .....	9
Reminder .....	9
Reset settings .....	57
Ringer off .....	10
Ringer setting .....	42
RoboPortrait .....	13

**S**

Second phone number .....	50
Security .....	49
Select line .....	50
Send/receive fax .....	53
Service Provider control .....	15
Service tones .....	43
Settings .....	47
Show URL .....	23
Siemens Service .....	56
Signal tone, ringer .....	42
SIM Services .....	21
SMS (messages) .....	30
Special characters .....	11, 32
Specifications .....	62
Speed dialling numbers .....	17
Standby .....	7
Stopwatch .....	29
Swapping calls .....	18
Switch On/Off .....	6

**T**

Talk time .....	6
Technical specifications .....	62
Text Entry .....	11
Text input .....	32

**Index**

67

Text input with "T9" .....	32
Text menu .....	31
Time/Change .....	44
Tips on use .....	57
Toggling .....	19
Total charge .....	44
Troubleshooting .....	59

**U**

Upper and lower case letters	11, 32
Usage time (battery) .....	6

**V**

Vibrator alarm .....	42
VIP Phonebook .....	12
Voice mail (mailbox)	
playback .....	37
setting .....	36
Volume .....	42

**W**

Written messages .....	30
------------------------	----

# Notes

# Notes