General Information

1995

CRT: 37SX110Y22-DC05 **Remote Control:** Remcon 1498

Door Flap: 21997150105S

Door Catch: 70239120102 **Main Power Button:** 29297150101S

Specifications

System:		PAL-I
Destination:		UK
Channel Coverage:		UHF 21 - 69 CH
Frequency Range:		UHF 470 - 862Q MHz
Scanning:		
Lines:		625 lines
Horizontal:		15625Hz
Vertical:		50Hz
IF Frequenc	:y:	
Video:		39.5MHz
Sound:		33.5MHz
Chroma:		35.07MHz
Vision/Sound Separation:		6.0MHz
Sensitivity:		UHF 80dBuV
Output Power:		Max. 900mW
(Audio)		10% THD 700mW
CRT:		iagonal, 22.5mm neck
	diamete	er 90° deflection angle
Speaker:	50	0mm x 90mm, 16 ohm

Service Adjustments

Colour Television Alignment Instructions

Please Read Before Attempting Service

- Never disconnect any leads while receiver is in operation.
- Disconnect all power before attempting any repairs.
- 3: Do not short any portion of the circuit while power is on.
- For reasons of safety, all parts replaced should be identical, (for parts numbers see parts list)
- Before alignment the set must be pre-heated for 30 minutes or more and erase magnetism thoroughly from CRT front chassis frame by Degaussing coil.

Test Equipment

Antenna Impedance

Power Consumption:

- VIF Sweep Generator
- SIF Sweep Generator
- Colour Bar/Dot/Cross Hatch Generator
- DC Power Supply (14V)
- Oscilloscope
- Vacuum Tube Voltmeter
- Voltage Meter
- High Voltage Meter
- Ampere Meter (0.5 Class, DC 3mA Max)

- Demagnetising Coil
- Phillips Pattern Generator
- Frequency Counter
- Continuous Waveform Generator


Tank Coil Alignment

Preparation Step (see fig. 2.)

- Connect OUTPUT lead of VIF Sweep Generator between SA101 pin 4 and GND (80dB).
- Connect lead of FROM DET between TP106 and GND.
- Supply DC +14V to (+) lead of D408. Apply a +5.2V DC dummy AGC bias
- voltage to TP104.

AGC BIAS SUPPLY

DC +12V (+) lead wire to 0408






Fig 2.


75 ohm

70 watts

Fig 1.

Alignment Step (see fig. 3)

- Set output level to 6Vp-p.
- Adjust T105 to obtain maximum amplitude of response cause at 39.5MHz as in fig. 3.



VIF Alignment

Preparation Step (see fig. 2)

- Connect output lead of VIF Sweep Generator between tuner test point TP and tuner case.
- Connect resistor (100 Ohm) between TP101 and TP102.
- Connect lead of FROM DET between TP106 and GND.

- Short Q301 base to GND and set S102
- to OFF mode. Supply DC +14V to QUAS lead of
 - Supply RF AGC bias voltage to TP104

Alignment Step

- Adjust AGC bias voltage for maximum amplitude of waveform
- Adjust level of Sweep Generator to achieve 300mV output.
- increase the output level of Sweep Generator into 20dB.
- Adjust AGC bias voltage to achieve 300mV output (on Oscilloscope)
- Adjust tuner converter coil to obtain the waveform as in fig. 4.




Fig 4

AFC Alignment

Preparation Step

- Connect FR AGC 5.2V bias voltage at
- Remove the damping resistor (100 ohm) at TP101, TP102.
- Connect output lead of Sweep Generator to the tuner point TP and tuner case, (70dB),
- Increase the output level of Sweep Generator in 10dB.
- Connect lead of FROM DET between TP107 and GND.
- Supply DC +14V to QUAS lead of

Alignment Step

- Adjust the AGC bias to achieve 3Vp-p
- Adjust T106 so that the picture carrier 39.5 MHz is as centred as in Fig. 5.




Fig 5.

SIF Alignment

Preparation Step (see fig. 6)

- Connect output lead of SIF Sween Generator between TP106 and GND
- Connect lead of FROM DET between TP105 and GND.
- Supply DC +14V to QUAS lead of




Fig 6.

Alignment Step

- Adjust output of Sweep Generator to achieve 6Vp-p between markers of
- 2: Adjust T104 so sound carrier is centred as in Fig. 7.




Fig 7.

Colour Demodulator Alignment, **Delay Line Alignment**

- Receive Phillips pattern.
- Set Contrast control to minimum position.
- Set Colour control to maximum position
- Connect oscilloscope to TP301 (B-out).
- Adjust CT301 to obtain the waveform as in fig. 8. Adjust VR301 to obtain the waveform
- as in fig. 8. Adjust T301 to obtain waveform as in

Reduce the difference to

minimum (Adjust CT301)

Fig 8.

B+ Adjustment

- Connect the Digital Voltmeter to
- Adjust semi-fixed resistor VR901 for the reading of DC 112.25V ± 0.25V.

Horizontal Circuit Adjustment

- Receive Monoscope pattern input signal 80dBuV.
- IC301 (pin 28, 29) short by 1K ohm
- Adjust VR303 to obtain the picture running at centre
- Remove the 1K ohm resistor.

Vertical Circuit Adjustment

- Receive the Monoscope pattern.
- Connect the Frequency Counter between V-DEFLECTION YOLK and GROUND.
- Connect the lead wire from TP106 to GND
- 4: Adjust V-HOLD (VR304) to the reading 44Hz.
- 5: Remove the lead wire from TP106 to GND
- Adjust V-SIZE (VR401) control to obtain a normal picture.

White Balance Adjustment

- Receive a black and white picture signal.
- Turn the red, green and blue LOW-LIGHT (VR501, VR502, VR504) controls to middle position and turn the DRIVE (VR503, VR505) controls to the middle position
- Turn the SCREEN control on the FBT to minimum position.
- Set the Sub-brightness (VR305) control to middle position, then set the Contrast, Brightness and Colour control to minimum position
- CN403 (pin 1, 2) with Join together.
- Connect voltmeter between (R508) and ground, and adjust Brightness control to the reading of DC 130V (±2V). If DC 130V cannot be obtained adjust the Sub-brightness control
- Slowly turn the SCREEN control clockwise to the point where a horizontal line just illuminates.
- Adjust VR501 to get a red horizontal line on CRT.
- Adjust VR502 to get a yellow horizontal line on CRT.

Reduce the difference to

minimum (Adust 1301)

- Adjust VR504 to get a white horizontal line on CRT.
- Take the Joiner out of CN403. Adjust Drive (VR503, VR505) controls

to obtain a uniform white picture

On Screen Adjustment

deflection yoke.

Focus Adjustment

RF AGC Alignment

2:

middle position

Set Contrast control to maximum

position and Brightness control to

Adjust Focus control (on the FBT) to

obtain a sharpest and clearest picture

Receive the signal of BAND-II (VHF

Set the input field strength in 62 ± 3

point where noise has disappeared

Receive Monoscope pattern.

Set controls as follows:

Colour Purity Adjustment (see fig. 9)

Note: Before all adjustments described

HEIGHT. B+ VOLTAGE and FOCUSING

are attempted, V-HOLD, H-HOLD, V-

ADJUSTMENT must be completed.

South

minutes.

roughly.

yoke towards you.

counterclockwise

Adjust RF-AGC control (VR101) to the

BRIGHTNESS Control - MID position.

Adjust the SUB-BRIGHTNESS control

CONTRAST Control - MID position.

(VR305) to get the nine step of the

grey scale in the Monoscope pattern.

Place the TV receiver facing North or

Fully degauss the TV receiver by using

Plug in TV receiver and turn it on.

Operate TV receiver for over 30

Receive a crosshatch pattern and

Loosen the clamp screw of the

Fully turn the red and blue Drive

Adjust the purity magnets so that

(VR503, VR505) controls

adjust the static convergence control

deflection yoke and pull the deflection

green field is obtained at the centre of

Slowly push the deflection yoke toward

bell of CRT and set it where a uniform

an external degaussing coil.

COLOUR Control - MID position.

HIGH) Channel and set the AFC

switch to ON position.

Sub-Brightness Alignment

Receive the Monoscope pattern.

green field is obtained

Adjust on SCREEN (VR601) for adjust the lettering to centre of CRT.


Tighten the clamp screw of the

Teletext Picture Alignment

- Receive a pattern with a Teletext
- Select a Teletext page.
- Connect DC voltage meter to TP303 (IC001 pin 28) and GND.
- Adjust T001 to obtain 2.5V ± 0.05V.

Convergence Adjustment (see fig. 9)

Receive a dotted pattern.



Service Adjustments Cont'd.

- Unfix the convergence magnet clamper and align red with blue dots at the centre of the screen by rotating (R, B) static convergence magnets.
- Align red/blue with green dots at the centre of the screen by rotating (RB-G) static convergence magnet.
- 4: Fix the convergence magnet by turning the clamper.
- Remove the DY wedges and slightly tilt the deflection yoke horizontally and vertically to obtain the good overall convergence.
- 6: Fix the deflection yoke by wedges.
- 7: If purity error is found, follow PURITY ADJUSTMENT instructions.

