


8 Exploded View and Parts List


8-1 Front Cover & CRT Ass'y

NO	DESCRIPTION	CODE NO	SPECIFICATION	Q'TY	REMARK
1	UNIT-C/FRONT	BH75-10508Q	CKG7507LXX	1	NON MULTI-MEDIA
		BH75-10508R	CKG7507LMX	1	MULTI-MEDIA
		BH75-10508S	CKG7507TXX	1	NON MULTI-MEDIA, TCO
		BH75-10508T	CKG7507TMX	1	MULTI-MEDIA, TCO
2	ASS'Y-LED PCB		CKG7507	1	
3	KNOB-VR	BH64-10392A	ABS HB 1V16	2	
4	ASS'Y-VR PCB		CKG7507	1	
5	SCREW TAPITE	6003-000015	BH,D3,L8	1	
6	ASS'Y-FUNTION PCB		CKG7507	1	
7	CRT-COLOR	BH03-10335B	17",0.28	1	
8	ASS'Y-CDT GROWND		CKG7507	1	
9	CABLE-TIE	BH65-10100A	NYLON66,L150	2	
10	ASS'Y-D COIL		CKG7507	1	
11	UNIT/BRKT	BH75-10422L	CKG7507	1	
12	SCREW-ASS'Y TAPT	6006-001010	WPP,BH,D5,L25	4	




8-2 Chassis & Stand Ass'y

NO	DESCRIPTION	CODE NO	SPECIFICATION	Q'TY	REMARK
19	ASS'Y-CDT PCB	BH98-20004K	CKG7507	1	
20	LOCKER-WIRE	BH64-30002A	NYLON66	2	
21	ASS'Y-PCB	BH98-10010B	CKG7507	1	
22	SCREW-TAPTITE	6003-000010	BWH,D3,L10	7	
23	SCREW-TAPTITE	6003-000009	BH,D4,L16	4	
24	BRKT-PCB	BH70-10514A	SECC T1.0	1	
25	SCREW-TAPPING	6002-000129	FH,D3,L8	2	
26	SCREW TAPTITE	6003-000015	BH,D3,L8	3	
27	SHAFT-POWER	BH72-60447A	ABS+PC 1V01	1	
28	BRKT-PCB BOTTOM	BH70-10419A	SECC T1.0	1	
29	SCREW TAPTITE	6003-000015	BH,D3,L8	4	
30	UNIT/STAND-ASS'Y	BH75-10605A	CKG7507	1	
31	BRKT-VIDEO	BH70-10414A	SECC T0.8	1	
32	ASS'Y-VIDEO PCB	BH98-20004K	CKG7507	1	
33	SCREW-TAPTITE	6003-000010	BWH,D3,L10	2	
34	SHIELD-VIDEO	BH71-10406A	A1050S H14 T1.6	1	
35	SCREW-TAPTITE	6003-000015	BH,D3,L8	7	



8-3 Rear Cover Ass'y

NO	DESCRIPTION	CODE NO	SPECIFICATION	Q'TY	REMARK
13	UNIT/SHIELD-ASS'Y	BH75-10605A	CKG7507	1	
14	SCREW-TAPTITE	6003-000015	BH,D3,L8	12	
15	CAP-SCREW	BH72-60448F	ABS HB 1V16	2	
16	COVER-REAR	BH72-60443S	ABS HB 1V16	1	NON MULTI-MEDIA
		BH72-60443V	ABS HB 1V16	1	MULTI-MEDIA
17	SCREW-TAPTITE	6003-000009	BH,D4,L16	4	
18	COVER-REAR TOP	BH72-60444E	ABS HB 1V16	1	



Memo